Pictorial index

Search by illustration

1	For safety and security	Make sure to read through them	
2	Instrument cluster	How to read the gauges and meters, the variety of warning lights and indicators, etc.	
3	Operation of each component	Opening and closing the doors and windows, adjustment before driving, etc.	
4	Driving	Operations and advice which are necessary for driving	
5	Audio system	Operating the audio system	
6	Interior features	Usage of the interior features, etc.	
7	Maintenance and care	Caring for your vehicle and maintenance procedures	
8	When trouble arises	What to do in case of malfunction or emergency	
9	Vehicle specifications	Vehicle specifications, customizable features, etc.	
	Index	Search by symptom	
	IIIUGA	Search alphabetically	

your information8		Multi-information display	
•		` '. '	120
			128
orial index12	_		120
For safety and security		•	
For safe use	3-1.	•	
Before driving32		Keys	130
For safety drive34	3-2.	Opening, closing and long the doors	ocking
		Side doors	136
		Back door	146
	A 5	Glass hatch	153
	77	Smart entry & start	
for children56		system	159
Child restraint systems57	3-3.	Adjusting the seats	
Installing child restraints70		Front seats	175
Exhaust gas precautions82		Rear seats	
Theft deterrent system \	. 1 1	Driving position memory	193
Engine immobilizer	+/(ω	Head restraints	197
system83 Double locking system89	3-4.	Adjusting the steering and mirrors	wheel
		Steering wheel	200
- Farmas	i():	Inside rear view mirror	203
Instrument cluster		Outside rear view mirrors	205
Instrument cluster	3-5.	Opening and closing the windows and moon ro	
		Power windows	208
		Moon roof	
•			
(Type R) 115			
	ding this manual	Search 10 10 10 10 10 10 10 1	to search

4 Driving	4-4. Refueling Opening the fuel tank cap	
4-1. Before driving Driving the vehicle218 Cargo and luggage230 Trailer towing	Oruise control	1
(with towing hitch)233 4-2. Driving procedures Engine (ignition) switch	306 Toyota parking assist-sensor324 Rear view monitor	2
(vehicles without a smart entry & start system)246 Engine (ignition) switch	cyctom 224	3
(vehicles with a smart entry & start system)249 Automatic transmission257	Driving assist systems 372 BSM (Plind Spot Manitor) 378	4
Manual transmission264 Turn signal lever269 Parking brake270	• The Blind Spot Monitor function	5
Diesel Particulate Filter system (diesel engine only)271	Traffic Alert function 387 PCS (Pre-Crash Safety system)	6
4-3. Operating the lights and wipers Headlight switch274		7
Fog light switch287 Windshield wipers and washer289		8
Rear window wiper and washer295 Headlight cleaner switch296		9

5	Audio system	5-7.	"SETUP" menu Using the "SETUP" menu
			("Bluetooth*" menu) 445 Using the "SETUP" menu
5-1.	Basic Operations		("TEL" menu) 449
	Audio system types406	5-8.	Bluetooth [®] Audio
	Steering wheel audio switches407		Operating a Bluetooth®
	AUX port/USB port408		enabled portable
5-2.	Using the audio system		player 453
	Optimal use of the audio	5-9.	Bluetooth® Phone
	system409	4	Making a phone call 455
5-3.	Using the radio		Receiving a phone call 457
	Radio operation411	- 48	Speaking on the phone 458
5-4.	Playing an audio CD and MP3/WMA discs	5-10	.Bluetooth [®] Bluetooth [®] 460
	CD player operation415	6	Interior features
5-5.	Using an external device		interior reatures
	Listening to an iPod423		
	Listening USB memory device430	6-1.	Using the air conditioning system and defogger
	Using the AUX port437	+ 10	Front manual air
5-6	Using Bluetooth® devices		conditioning system 466
0-0.	Bluetooth® audio/phone438		Front automatic air
	Using the steering		conditioning system 472
	wheel switches443	5():	Rear manual air conditioning system 481
	Registering a Bluetooth®		Rear automatic air
	device444		conditioning system 483
			Power heater486
			Heated steering
			wheel/seat heaters/seat
			ventilators488

^{*:} Bluetooth is a registered trademark of Bluetooth SIG, Inc.

6-2.	Using the interior lights Interior lights list492	7 Maintenance and care	
	Personal/interior lights main switch493 Personal/interior lights493	7-1. Maintenance and care Cleaning and protecting	
6.2	Lounge illumination control switches494 Using the storage features	the vehicle exterior 526 Cleaning and protecting	1
b-3.	Using the storage features	the vehicle interior 530	
	List of storage features496Glove box497Card holder498	7-2. Maintenance Maintenance	2
	 Console box498 Cup holders/bottle holders/door pockets500 	requirements 533	3
	Auxiliary boxes503	\sim 1 1	
	Luggage compartment features505	9 316	4
6-4.	Using the other interior features		5
	Other interior features509		
	• Cool box509		
	• Sun visors511 • Vanity mirror511	$\lambda \Delta$:تلفن شبانه روزی	6
	Conversation mirror512		
	• Clock513 • Power outlet514		7
	A = = = = = = = = = = = = = = = = = = =		
	• Coat hooks517	OS.com	
	Assist grips518		8
	• Ashtray519		
	ERA-GLONASS520		
			9

7-3.	Do-it-yourself maintenance Do-it-yourself service precautions536	8-2.	Steps to take in an emergency If your vehicle needs
	Hood539		to be towed617
	Engine compartment540 Tires565 Tire inflation pressure581 Wheels583 Air conditioning filter586 Wireless remote control/electronic key battery588 Checking and replacing fuses592		If you think something is wrong
	Light bulbs596		(vehicles with a spare tire)
8	When trouble arises	フ	If you have a flat tire (vehicles without a spare tire)
8-1.	Essential information Emergency flashers614 If your vehicle has to be stopped in an emergency615	۸۵	If the engine will not start
	FarmaS()	start system)
			If your vehicle overheats

9 Venicle specifications	
9-1. Specifications Maintenance data (fuel, oil level, etc.)708 Fuel information738	
9-2. Customization Customizable features741	2
9-3. Items to initialize Items to initialize	3
Index What to do if	2
(Troubleshooting)	
تلفن شبانه روزی: ۱۲۰ ۱۸۸۶۲ ۲۸۸	6

FarmaSOS.com

For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual" for information regarding the equipment listed below.

- Navigation system
- Hands-free system (for cellular phone)
- Rear seat entertainment system
- · Audio/video system

Toyota Motor Europe NV/SA, Avenue du Bourget 60 - 1140 Brussels, Belgium www.toyota-eupore.com

For your information

Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Toyota policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of equipment.

Accessories, spare parts and modification of your Toyota

Both genuine Toyota and a wide variety of other spare parts and accessories for Toyota vehicles are currently available on the market. Should it be determined that any of the genuine Toyota parts or accessories supplied with the vehicle need to be replaced, Toyota recommends that genuine Toyota parts or accessories, be used to replace them. Other parts or accessories of matching quality can also be used. Toyota cannot accept any liability or guarantee spare parts and accessories which are not genuine Toyota products, nor for replacement or installation involving such parts. In addition, damage or performance problems resulting from the use of non-genuine Toyota spare parts or accessories may not be covered under warranty.

Installation of an RF-transmitter system

The installation of an RF-transmitter system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Dynamic radar cruise control system
- Cruise control system
- Anti-lock brake system
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for precautionary measures or special instructions regarding installation of an RF-transmitter system.

Further information regarding frequency bands, power levels, antenna positions and installation provisions for the installation of RF-transmitters, is available on request at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Scrapping of your Toyota

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer before you scrap your vehicle.



Your vehicle contains batteries and/or accumulators. Do not discard them into the environment but cooperate with separate collection (Directive 2006/66/EC).

CAUTION

General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Reading this manual

A CAUTION:


Explains something that, if not obeyed, could cause death or serious injury to people.

♠ NOTICE:

Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.

123 ··· Indicates operating or working procedures. Follow the steps in numerical order.

- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- Indicates the outcome of an operation (e.g. a lid opens).




- Indicates the component or position being explained.
- Means "Do not", "Do not do this", or "Do not let this happen".



How to search

- Searching by name
 - Alphabetical index P. 758



- Searching by installation position




- Searching by symptom or sound
 - What to do if... (Troubleshooting) P. 754




FarmaS

- Searching by title
 - Table of contents P. 2



Pictorial index

Exterior



1	Side doorsP. 13Locking/unlockingP. 13Opening/closing the door glassesP. 20Locking/unlocking by using the mechanical key*1P. 69Warning lights/warning messages*1P. 628, 63	8 1 7
2	Back doorP. 14Opening from outsideP. 14Opening/closing the glass hatch*1P. 15Warning lights/warning messages*1P. 628, 63	3
3	Outside rear view mirrorsP. 20Adjusting the mirror angleP. 20Folding the mirrorsP. 20Defogging the mirrors*1P. 467, 47	5


(4)	Windshield wipers	
	Precautions against winter season	P. 400
	To prevent freezing (windshield wiper de-icer) P.	468, 476
	Precautions against car wash	
(5)	Fuel filler door	
	Refueling method	
(6)	Tires	P. 565
	Tire size/inflation pressure	
	Winter tires/tire chain	P. 400
(7)	Coping with flat tires	
	Hood Opening	
	Engine oil	
	Coping with overheat	
8	Camera*1, 2 P.	334, 345
	bulbs of the exterior lights for driving	
(Repla	acing method: P. 596, Watts: P. 737)	
(Repla	acing method: P. 596, Watts: P. 737) Headlights/daytime running lights*1دلک شیانه دروی	
(Repla	acing method: P. 596, Watts: P. 737)	
(Replated 9) (10) (11)	Headlights/daytime running lights*1	P. 274 P. 287
(Replated 9) (10) (11)	Headlights/daytime running lights*1	P. 274 P. 287
(Replated 9) (10) (11)	Headlights/daytime running lights*1	P. 274 P. 287
(Replated 9) (10) (11)	Headlights/daytime running lights*1	P. 274 P. 287
(Replated 9) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	Headlights/daytime running lights*1	P. 274 P. 287 P. 269 P. 274
(Replated 9) (1) (1) (2) (3) (4)	Headlights/daytime running lights*1	P. 274 P. 287 P. 269 P. 274
(Replated 9) (1) (1) (2) (3) (4)	Headlights/daytime running lights*1	P. 274 P. 287 P. 269 P. 274
(Replated 9) (1) (1) (2) (3) (4)	Headlights/daytime running lights*1	P. 274 P. 287 P. 269 P. 274
(Replated 9) (1) (1) (2) (3) (4)	Headlights/daytime running lights*1	P. 274 P. 287 P. 269 P. 274

 \star_2 : The location of the camera differs depending on the location of the spare tire.

 $^{(\}rightarrow \text{P. }337,\,363)$ *3: Refer to the "Off-road Driving Owner's Manual".

 $^{^{\}star_4}$: The location of the license plate lights differs depending on the location of the spare tire. (\rightarrow P. 598)

■Instrument panel (Left-hand drive vehicles)




1	Engine switch)
	Starting the engine/changing the modes	,
	Emergency stop of the engine P. 615	5
	When the engine will not start P. 689)
	Warning messages*1 P. 636	3
2	Shift lever (Automatic transmission) P. 257 Changing the shift position	
	Changing the shift position P. 257	7
	Precautions against towing P. 617	7
	When the shift lever does not move P. 262	2
	Shift lever (Manual transmission) P. 264	Ļ
	Changing the shift position P. 264	1
	Precautions against towing P. 617	7
(3)	Meters P. 105	5
	Reading the meters P. 105	5
	Adjusting the instrument cluster light P. 108	
	Warning lights/indicators P. 98	3
	When the warning lights come on P. 625	5

4	Multi-information display P. 110, 11		
	Display	Э, Р.	636
(5)	Parking brake lever		
	Applying/releasing		
	Warning buzzer/message*1 P. 63	1,	638
6	Turn signal lever		
	Headlight switch Headlights/front position lights/tail lights/	Ρ.	2/4
	daytime running lights*1	Ρ.	274
(7)	Front fog lights*1/rear fog lights		
(7)	Windshield wiper and washer switch	P.	289
	Adding washer fluid	P.	556
8	Emergency flasher switch	P.	614
9	Fuel filler door opener	P.	301
10	Hood lock release lever	P.	539
11)	Tilt and telescopic steering control switch*1	P.	200
	Adjustment		
12	Tilt and telescopic steering lock release lever*1		
13)	Front manual air conditioning system	P.	466
	Usage	Ρ.	466
	Front automatic air conditioning system		
	Rear window defogger.		
14)	Audio system*1, 2	P.	406
	Audio system ^{*1, 2} Hands-free system ^{*1, 2}	Ρ.	406
	Hands-tree system ', f	۲.	438


*1: If equipped

 $^{^{\}star}2$: For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual".

Switches (Left-hand drive vehicles)




1 Power window switches
② Door lock switch
③ Window lock switch P. 208
 4 Driving position memory buttons*
5 Odometer/trip meter and trip meter reset button P. 108, 111
6 Instrument cluster light control dial P. 108
7 Headlight cleaner switch* P. 296
8 Manual headlight leveling dial*
Outside rear view mirror switches
① Lounge illumination control switches* P. 494
(1) Heater idle up switch* P. 468, 477
12 Heated steering wheel switch* P. 489
(13) Toyota parking assist-sensor switch* P. 324




FarmaSOS.com

*: If equipped



8 Multi-terrain Monitor switch*1,3



- 1) Front seat heater switches*1
- 2 Center differential lock/unlock switch*1,3
- 3 Four-wheel drive control switch*3
- 4 "DAC" switch*1, 3

- 7 Height control button*1,3
- 8 Multi-terrain Select ON/OFF switch*1, 3


- (1) Multi-terrain 6-1 11) Multi-terrain Select mode selector dial*1, 3 Crawl Control speed selector dial*1,3
- 12 AVS switch*1, 3


*1: If equipped

^{*2:} For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual".

^{*3:} Refer to the "Off-road driving Owner's manual".

Interior (Left-hand drive vehicles)





1	Conversation mirror	
_	Personal/interior lights*4	
_	Moon roof switches*1P	
4	Intrusion sensor cancel switch*1	P. 93
(5)	Microphone P	P. 440
6	"SOS" button*1	P. 520
	Vanity mirrors F	
8	Sun visors*3 🔨 🔨 🚉 تاريخ د دري دري دري دري دري دري دري دري دري د	P. 511
	Inside rear view mirror	

FarmaSOS.com

*1: If equipped


*2: For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual".

^{*3:} NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. (→P. 80)



 $^{^{}ullet 4}$: The illustration shows the front, but they are also equipped in the rear.

■Instrument panel (Right-hand drive vehicles)




1 Engine switch	. P. 615 . P. 689 . P. 636
2 Shift lever (Automatic transmission)	P. 257
Changing the shift position	
When the shift lever does not move	
Shift lever (Manual transmission)	P. 264
Changing the shift position	
Precautions against towing	
③ Meters	
Adjusting the instrument cluster light	
Warning lights/indicators	P. 98
When the warning lights come on	P. 625

4	Multi-information display P. 110, 11		
	Display	Э, Р.	636
(5)	Parking brake lever		
	Applying/releasing		
	Warning buzzer/message*1 P. 63	1,	638
6	Turn signal lever		
	Headlight switch Headlights/front position lights/tail lights/	Ρ.	2/4
	daytime running lights*1	Ρ.	274
(7)	Front fog lights*1/rear fog lights		
(7)	Windshield wiper and washer switch	P.	289
	Adding washer fluid	P.	556
8	Emergency flasher switch	P.	614
9	Fuel filler door opener	P.	301
10	Hood lock release lever	P.	539
11)	Tilt and telescopic steering control switch*1	P.	200
	Adjustment		
12	Tilt and telescopic steering lock release lever*1		
13)	Front manual air conditioning system	P.	466
	Usage	Ρ.	466
	Front automatic air conditioning system		
	Rear window defogger.		
14)	Audio system*1, 2	P.	406
	Audio system ^{*1, 2} Hands-free system ^{*1, 2}	Ρ.	406
	Hands-tree system ', f	۲.	438


^{*1:} If equipped

 $^{^{\}star}2$: For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual".

Switches (Right-hand drive vehicles)





① Outside rear view mirror switches
② Lounge illumination control switches*
③ Heated steering wheel switch* P. 489
4 Headlight cleaner switch*
قلفن شبانه روزی *Manual headlight leveling dial P. 275
6 Heater idle up switch* P. 468, 477
Toyota parking assist-sensor switch*
8 Instrument cluster light control dial P. 108
Odometer/trip meter and trip meter reset button P. 108, 111
① Driving position memory buttons* P. 193
11) Window lock switch P. 208
① Door lock switch P. 140
13 Power window switches P. 208



FarmaSOS.com

*: If equipped






- 3 Multi-terrain Select ON/OFF switch*1, 3
- (4) Crawl Control ON/OFF switch*1, 3
- 5 Center differential lock/unlock switch*1, 3
- (6) Rear differential lock/unlock switch*1,35 وتلفن شبانه روز
- 7 Four-wheel drive control switch*3
- 8 Multi-terrain Select mode selector dial*1, 3
- (1) Front seat heater switches*1 P. 490
- 11) "DAC" switch*1, 3
- (2) Front seat ventilator switches*1 P. 491


^{*1:} If equipped

^{*2:} For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual".

^{*3:} Refer to the "Off-road driving Owner's manual".

Interior (Right-hand drive vehicles)





FarmaSOS.com

*1: If equipped

*2: For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual".

*3: NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. (→P. 80)



^{*4:} The illustration shows the front, but they are also equipped in the rear.



تلفن شبانه روزی: ۱۹۲۰ میلا - ۲۱ - ۲۲ میلانه

FarmaSOS.com

For safety and security

1


1-1.	For safe use
	Before driving32
	For safety drive34
	Seat belts36
	SRS airbags41
ودرو فار	Airbag manual on-off system54 Safety information
	for children56
	Child restraint systems57
	Installing child restraints70
· ۲1-11187 + 12	Exhaust gas precautions82
1-2.	Theft deterrent system
	Engine immobilizer
	system83
-	Double locking system89
-armaSO	Alarm90

Before driving


Floor mat

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

Insert the retaining hooks (clips) into the floor mat eyelets.



- 2 Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.
 - *: Always align the \triangle marks.



The shape of the retaining hooks (clips) may differ from that shown in the illustration.

A CAUTION

Observe the following precautions.

Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle. This could lead to an accident, resulting in death or serious injury.

■When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) pro-
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.

Before driving

- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- •With the engine stopped and the shift lever in P (automatic transmission) or N (manual transmission), fully depress each pedal to the floor to make sure it does not interfere with the floor mat.




FarmaSOS.com

For safety drive

For safe driving, adjust the seat and mirror to an appropriate position before driving.

Correct driving posture

- Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P. 175)
- ② Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P. 175)



- ③ Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (→P. 197)
- ④ Wear the seat belt correctly. (→P. 36)

تلفن شبانه روزی:

Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle. $(\rightarrow P. 36)$

Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt. $(\rightarrow P. 57)$

Adjusting the mirrors

Make sure that you can see backward clearly by adjusting the inside and outside rear view mirrors properly. (→P. 203, 205)



CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not adjust the position of the driver's seat while driving. Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback. A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- Do not place anything under the front seats. Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.
- Always observe the legal speed limit when driving on public roads.
- When driving over long distances, take regular breaks before you start to feel tired.

Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

FarmaSOS.com

Seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.


Correct use of the seat belts

- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.



Fastening and releasing the seat belt

- 1 To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- ② To release the seat belt, press the release button.



Adjusting the seat belt shoulder anchor height (front and outer second [5-door models] seats)

- 1 Push the seat belt shoulder anchor down while pressing the release button.
- ② Push the seat belt shoulder anchor up.


Move the height adjuster up and down as needed until you hear a click.



Seat belt pretensioners (front seats)

The pretensioner helps the seat belt to quickly restrain the occupant by retracting the seat belt when the vehicle is subjected to certain types of severe frontal collision or side collision (vehicles with SRS side airbags and curtain shield airbags).

The pretensioner may not activate in the event of a minor frontal or side impact, or a rear impact.



تلفن شبانه روزي: 🕽

Pre-crash seat belts (front seats of vehicles with pre-crash safety system)

If the system determines that a collision is unavoidable, the front seat belts will retract before the collision. (\rightarrow P. 390)

■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

■ Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P. 57)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions on P. 36 regarding seat belt usage.

Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

■ Seat belt regulations

If seat belt regulations exist in the country where you reside, please contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for seat belt replacement or installation.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ الفن شبانه روزی

CAUTION

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident. Failure to do so may cause death or serious injury.

■Wearing a seat belt


- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Toyota recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips

Pregnant women

Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P. 36)$

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking, sudden swerving or a collision.



CAUTION

■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P. 36)$

When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

■ Seat belt pretensioners

If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Adjustable shoulder anchor


Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident. (\rightarrow P. 37)

■Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belt cannot protect an occupant from death or serious injury.
- Ensure that the belt and plate are locked and the belt is not twisted. If the seat belt does not function correctly, immediately contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. Inappropriate handling may lead to incorrect operation.

SRS airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.



FarmaSOS.com

SRS front airbags

- SRS driver airbag/front passenger airbag
 Can help protect the head and chest of the driver and front passenger from impact with interior components
- ② SRS driver knee airbag (if equipped)
 Can help provide driver protection


SRS side and curtain shield airbags

- ③ SRS side airbags (if equipped)
 Can help protect the torso of the front seat occupants
- 4 SRS curtain shield airbags (if equipped)
 Can help protect primarily the head of occupants in the outer seats

امداد حودرو فارما

تلفن شبانه روزى: ۱-۱۸۸۶۲ ۲۸۸ - ۲۱

Airbag system components



- 1 Front impact sensors
- ② Side impact sensors (front) (if equipped)
- ③ Airbag manual on-off switch (if equipped)
- 4 Curtain shield airbags (if equipped)
- (5) Front passenger airbag
- 6 Side airbags (if equipped)
- 7 SRS warning light
- Side impact sensors (rear) (if equipped)

- 9 Driver airbag
- ① Safing sensor (rear) (if equipped)
- ① Driver's seat belt buckle switch
- (if equipped)
- (if equipped)
- (14) Airbag sensor assembly
- (15) Seat belt pretensioners and force limiters

The main SRS airbag system components are shown above. The SRS airbag system is controlled by the airbag sensor assembly. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

CAUTION

SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly.
 - The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. Since the risk zone for the driver's airbag is the first 50 - 75 mm (2 - 3 in.) of inflation, placing yourself 250 mm (10 in.) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 250 mm (10 in.) away now, you can change your driving position in sev-
 - · Move your seat to the rear as far as you can while still reaching the pedals comfortably.
 - · Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 250 mm (10 in.) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.
 - · If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.



A CAUTION

■SRS airbag precautions

- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. $(\rightarrow P. 57)$
- Do not sit on the edge of the seat or lean against the dashboard.



- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not allow the front seat occupants to hold items on their knees.



A CAUTION

SRS airbag precautions

Vehicles with SRS curtain shield air-

Do not lean against the door, the roof side rail or the front, center and rear pillars.




Vehicles with SRS side airbags: Do not allow anyone to kneel on the passenger seats toward the door or put their head or hands outside the vehicle.



Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel.

These items can become projectiles when the SRS driver, front passenger and knee airbags (if equipped) deploy.




A CAUTION


■SRS airbag precautions

Vehicles with SRS curtain shield air-

Do not attach anything to areas such as the door, windshield glass, side door glass, front, center or rear pillars, roof side rail and assist grip. (Except for the speed limit sticker →P. 684)



Do not attach any heavy, sharp or hard objects such as keys or accessories to the key. The objects may restrict the SRS knee airbag (if equipped) inflation or be thrust into the driver's seat area by the force of the deploying airbag, thus causing a danger.





- Vehicles with SRS curtain shield airbags: Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbag deploy.
- Vehicles with SRS knee airbag: If the vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.

CAUTION

■ SRS airbag precautions

Vehicles with SRS side airbags:

Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the airbags. Such accessories may prevent the side airbags from activating correctly, disable the system or cause the side airbags to inflate accidentally, resulting in death or serious injury.

- Do not strike or apply significant levels of force to the area of the SRS airbag components.
 - Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front, center and rear pillar garnishes, are damaged or cracked, have them replaced by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

تلفن شبانه روزى: ۱۵۸۰۲۹۸۸۸–۲۱۰

CAUTION

■ Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, center and rear pillars or roof side rail
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment
- Installation of a grille guard (bull bars, kangaroo bar, etc.), snow plows or winches
- Modifications to the vehicle's suspension system
- Installation of electronic devices such as mobile two-way radios (RF-transmitter) and CD players
- Modifications to your vehicle for a person with a physical disability

■ If the SRS airbags deploy (inflate)

- Slight abrasions, burns, bruising etc., may be sustained from SRS airbags. due to the extremely high speed deployment (inflation) by hot gases.
- A loud noise and white powder will be emitted.
- Vehicles with SRS curtain shield airbags:

Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, parts of the front, center and rear pillars and roof side rail, may be hot for several minutes. The airbag itself may also be hot.

Vehicles without SRS curtain shield airbags:

Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats may be hot for several minutes. The airbag itself may also be hot.

- The windshield may crack.
- Vehicles with ERA-GLONASS: If the SRS airbags deploy, the system is designed to send an emergency call* to the Public Safety Answering Point (PSAP), notifying them of the vehicle's location (without needing to push the "SOS" button) and an agent will attempt to speak with the occupants to ascertain the level of emergency and assistance required. If the occupants are unable to communicate, the agent automatically treats the call as an emergency and helps to dispatch the necessary emergency services. (→P. 520)

^{*:} In some cases, the call cannot be made. $(\rightarrow P. 522)$

■ SRS airbag deployment conditions (SRS front airbags)

• The SRS front airbag will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 20 -30 km/h [12 - 18 mph] frontal collision with a fixed wall that does not move or deform).

However, this threshold velocity will be considerably higher in the following situations:

- If the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact
- If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck
- Depending on the type of collision, it is possible that only the seat belt pretensioners will activate.


SRS airbag deployment conditions (SRS side airbags and curtain shield airbags)

The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 1500 kg [3300 lb.] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 20 - 30 km/h [12 -18 mph]).

■ Conditions under which the SRS airbags may deploy (inflate), other than a collision

The SRS front airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.


- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or falling



■Types of collisions that may not deploy the SRS airbags (SRS front airbags)

The SRS front airbags are generally not designed to inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.


- Collision from the side
- Collision from the rear
- Vehicle rollover



■ Types of collisions that may not deploy the SRS airbags (SRS side airbags and curtain shield airbags)


The SRS side airbag and curtain shield airbag system may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.

- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle



The SRS side airbags and curtain shield airbags are not generally designed to inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.


- Collision from the front
- Collision from the rear
- Vehicle rollover



■When to contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer


In the following cases, the vehicle will require inspection and/or repair. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible.


- Any of the SRS airbags have been inflated.
- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS airbags to inflate.




- Vehicles with SRS side and curtain shield airbags:
 - A portion of a door is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side airbags and curtain shield airbags to inflate.
- Vehicles without an SRS knee airbag: The pad section of the steering wheel or dashboard near the front passenger airbag is scratched, cracked, or otherwise damaged.

Vehicles with an SRS knee airbag: The pad section of the steering wheel, dashboard near the front passenger airbag cover or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.






Vehicles with SRS side airbags: The surface of the seats with the side airbag is scratched, cracked or otherwise damaged.



Vehicles with SRS curtain shield air-

The portion of the front pillars, center pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked or otherwise damaged.



تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۱** ۲۸ تلفن شبانه روزی


Airbag manual on-off system*


This system deactivates the front passenger airbag. Only deactivate the airbag when using a child restraint system on the front passenger seat.

1 Airbag manual off indicator

This indicator light turns on when the engine switch is in IGNITION ON mode.

2 Airbag manual on-off switch






Deactivating the front seat passenger airbag

Insert the mechanical key into the cylinder and rotate to the "OFF" position.

The indicator light turns on (only when the engine switch is in IGNITION ON mode).



*: If equipped

■ Airbag manual off indicator

If any of the following problems occur, it is possible that there is a malfunction in the system. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

- The indicator light does not come on when the airbag manual on-off switch is switched to "OFF".
- The indicator light does not go off when the airbag manual on-off switch is switched to "ON".



A CAUTION

■When installing a child restraint system

For safety reasons, always install the child restraint system in a rear seat. In the event that the rear seat cannot be used, the front seat can be used as long as the airbag manual on-off system is set to "OFF".

If the airbag manual on-off system is left on, the strong impact of the airbag deployment (inflation) may cause serious injury or even death.

■When a child restraint system is not installed on the front passenger

Ensure that the airbag manual on-off system is set to "ON".

If it is left off, the airbag may not deploy in the event of an accident, which may result in serious injury or even death.



Safety information for children

Observe the following precautions when children are in the vehicle.

Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the shift lever, wiper switch etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally.
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, back door, seats etc.



Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof (if equipped) or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Child restraint systems

Toyota strongly urges the use of child restraint systems.

Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one to the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.
 - General installation instructions are provided in this manual. $(\rightarrow P. 70)$
- If child restraint system regulations exist in the country where you reside, please contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for the child restraint system installation.
- Toyota recommends that you use a child restraint system which conforms to the regulation ECE No.44.

Types of child restraints

Child restraint systems are classified into the following 5 groups according to the regulation ECE No.44.

Group 0: Up to 10 kg (22 lb.) (0 - 9 months) Group 0+: Up to 13 kg (28 lb.) (0 - 2 years)

Group I: 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)
Group II: 15 to 25 kg (34 to 55 lb.) (4 years - 7 years)
Group III: 22 to 36 kg (49 to 79 lb.) (6 years - 12 years)

In this owner's manual, the following 3 types of popular child restraint systems that can be secured with the seat belts are explained:

▶ Baby seat

▶ Child seat

Equal to Group 0 and 0+ of ECE No.44

Equal to Group 0+ and I of ECE No.44





▶ Junior seat

Equal to Group II and III of ECE No.44



Child restraint system suitability for various seating positions

Information provided in the table shows your child restraint system suitability for various seating positions.

▶ 3-door models

Seating position	Front passenger seat				
position	Standard	Airbag manual on-off switch		Rear seat	
Mass groups		ON	OFF	Outboard	Center
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	X Never put	● U*1	J	U
0+ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	X Never put	U*1	٥	U
I 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	-/ \/ \/ \/	Rear- facing — X Never put	ه روز ٰ ل: (تلف <mark>ن*</mark> لشبان	U* ²
	Forward- facing — UF*1	Forward- facing — UF ^{*1}			
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	rm _{uF*1} a	SO UF*1	S _{U*1} C	O _{U*2}	U* ²

Key of letters inserted in the above table:

- U: Suitable for "universal" category child restraint system approved for the use in this mass group.
- UF: Suitable for forward-facing "universal" category child restraint system approved for the use in this mass group.
- X: Not suitable seat position for children in this mass group.

NOTE:

*1: Adjust the seatback to the most upright position.

If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

If the passenger seat is equipped with a vertical height adjuster, it must be placed in the upper most position.

Follow these procedures:

- For installing a baby seat with support base
 If the baby seat interferes with the seatback when latching the baby seat
 into the support base, adjust the seatback rearward until there is no
 interference.
- For installing a forward-facing child seat
 If there is gap between the child seat and the seatback, tilt the seatback
 rearward until good contact is achieved.
 If the seat belt shoulder anchor is ahead of the child seat belt guide,
 move the seat cushion forward.
- For installing a junior seat

 If the child in your child restraint system is in a very upright position, adjust the seatback to the most comfortable position.

 If the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.
- *2: If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

The child restraint systems mentioned in the table may not be available outside of the EU area.

Other child restraint systems which are different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer concerned and the seller of those seats.

▶ 5-door models

Seating position	Front passenger seat			Cocond cost		
	Stan-	Airbag manual on-off switch		Second seat		Third seat (if equipped)
Mass groups	dard	ON	OFF	Out- board	Center	, , ,
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	X Never put	U*1	U	L1	L1
0+ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	X Never put	U*1	U	L1	L1
I 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	Rear- facing — X Never put For- ward- facing — UF*1	Rear- facing — X Never put For- ward- facing — UF*1	リ ブ V*1 ・人公 :。	U* ² بانه روژ <i>ک</i>	L2* ³ تلفن ش	L2*4
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)) UF*1	UF*1	O *S	U*2	L3*3	L3* ⁵

Key of letters inserted in the above table:

- U: Suitable for "universal" category child restraint system approved for the use in this mass group.
- UF: Suitable for forward-facing "universal" category child restraint system approved for the use in this mass group.
- L1: Suitable for "TOYOTA G0+, BABYSAFE PLUS" (0 to 13 kg [0 to 28 lb.]) and "TOYOTA MINI" (0 to 13 kg [0 to 28 lb.]) approved for the use in this mass group.
- L2: Suitable for "TOYOTA DUO+" (without ISOFIX, 9 to 18 kg [20 to 39 lb.]) approved for the use in this mass group.
- L3: Suitable for "TOYOTA KID" (15 to 36 kg [34 to 79 lb.]) approved for the use in this mass group.

امداد ودرو فارما

X: Not suitable seat position for children in this mass group.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

NOTE:

*1: Adjust the seatback to the most upright position.

If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

If the passenger seat is equipped with a vertical height adjuster, it must be placed in the upper most position.

Follow these procedures:

- For installing a baby seat with support base
 If the baby seat interferes with the seatback when latching the baby seat
 into the support base, adjust the seatback rearward until there is no
 interference.
- For installing a forward-facing child seat
 If there is gap between the child seat and the seatback, tilt the seatback
 rearward until good contact is achieved.
 If the seat belt shoulder anchor is ahead of the child seat belt guide,
 move the seat cushion forward.
- For installing a junior seat
 If the child in your child restraint system is in a very upright position, adjust the seatback to the most comfortable position.

 If the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.
- *2: If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.
- *3: When you use a child restraint system in this position, move the head restraint to the lowest position.
- *4: When you use a child restraint system in this position, move the head restraint to the upmost position. (vehicles with third manual seats)
- *5: When you use a child restraint system in this position, remove the head restraint. (vehicles with third manual seats)

The child restraint systems mentioned in the table may not be available outside of the EU area.

Other child restraint systems which are different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer concerned and the seller of those seats.

Child restraint system suitability for various seating positions (with ISOFIX rigid anchors)

Information provided in the table shows your child restraint system suitability for various seating positions.

▶ 3-door models

		Fixture	Vehicle ISOFIX positions		
Mass groups	Size class		Outboard rear seat		
			Right-hand	Left-hand	
	F	ISO/L1	Х	Х	
Carrycot	G	ISO/L2	X	Х	
		(1)	X	X	
0	E	ISO/R1	IL1	Х	
Up to 10 kg (22 lb.) (0 - 9 months)	7 フノ	(1)	X	Х	
	Е	ISO/R1	IL1	Х	
0+ Up to 13 kg (28 lb.) (0 - 2 years)	D	ISO/R2	IL1	Х	
	1 CCY	ISO/R3	IL1	Х	
		زی: (۱۱)	لفن ش x انه رو	X	
I 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	D	ISO/R2	X	Х	
	С	ISO/R3	Х	Х	
	m _B	ISO/F2	IUF*, IL2*	IUF*	
	B1	ISO/F2X	IUF*, IL2*	IUF*	
	Α	ISO/F3	IUF*, IL2*	IUF*	
		(1)	Х	Х	
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)		(1)	Х	Х	


⁽¹⁾ For the child restraint system which do not carry the ISO/XX size class identification (A to G), for the applicable mass group, the car manufacturer shall indicate the vehicle specific ISOFIX child restraint system(s) recommended for each position.

Key of letters inserted in the above table:

- IUF: Suitable for ISOFIX forward-facing child restraint systems of universal category approved for use in this mass group.
- IL1: Suitable for "TOYOTA MINI with BASE" (0 to 13 kg [0 to 28 lb.]) and "TOYOTA MIDI" (0 to 13 kg [0 to 28 lb.]) approved for the use in this mass group.
- IL2: Suitable for "TOYOTA MIDI" (9 to 18 kg [20 to 39 lb.]) approved for the use in this mass group.

When using a "TOYOTA MINI" or "TOYOTA MIDI", adjust the support leg and ISOFIX connectors as follows:

- 1 Lock the support leg where 5th hole can be seen.
- 2 Lock the ISOFIX connectors where number 3 can be seen.



- X: ISOFIX position not suitable for ISOFIX child restraint systems in this mass group and/or this size class.
- *: If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

The child restraint systems mentioned in the table may not be available outside of the EU area.

Other child restraint systems different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer and retailer.

▶ 5-door models

Mass groups	Size class	Fixture	Vehicle ISOFIX positions	
			Outboard second seat	
Carrycot	F	ISO/L1	X	
	G	ISO/L2	X	
		(1)	X	
0	Е	ISO/R1	IL1	
Up to 10 kg (22 lb.) (0 - 9 months)		(1)	X	
0+ Up to 13 kg (28 lb.) (0 - 2 years)	E	ISO/R1	IL1	
	D	ISO/R2	IL1	
	С	ISO/R3	IL1	
	וער ו	(1)	X	
I 9 to 18 kg (20 to 39 lb.) — (9 months - 4 years)	D	ISO/R2	X	
	С	ISO/R3	X	
	В	ISO/F2	IUF*, IL2*	
	//B1	الله الله الله الكال شبانه (ISO/F2X) الكال		
	А	A ISO/F3 IUF*, IL2*		
		(1)	X	
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	naS	OS	om _x	


(1) For the child restraint system which do not carry the ISO/XX size class identification (A to G), for the applicable mass group, the car manufacturer shall indicate the vehicle specific ISOFIX child restraint system(s) recommended for each position.

Key of letters inserted in the above table:

- IUF: Suitable for ISOFIX forward-facing child restraint systems of universal category approved for use in this mass group.
- IL1: Suitable for "TOYOTA MINI with BASE" (0 to 13 kg [0 to 28 lb.]) and "TOYOTA MIDI" (0 to 13 kg [0 to 28 lb.]) approved for the use in this mass group.
- IL2: Suitable for "TOYOTA MIDI" (9 to 18 kg [20 to 39 lb.]) approved for the use in this mass group.

When using a "TOYOTA MINI" or "TOYOTA MIDI", adjust the support leg and ISOFIX connectors as follows:

- ▶ 7-passengers models
- 1 Lock the support leg where 4th hole can be seen.
- 2 Lock the ISOFIX connectors where number 4 can be seen.



- ▶ 5-passengers models
- 1 Lock the support leg where 4th hole can be seen.
- 2 Lock the ISOFIX connectors where number 2 can be seen.



- X: ISOFIX position not suitable for ISOFIX child restraint systems in this mass group and/or this size class.
- *: If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.


The child restraint systems mentioned in the table may not be available outside of the EU area.

Other child restraint systems different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer and retailer.

■When installing a child restraint system on the front passenger seat

When you have to use a child restraint system on the front passenger seat, adjust the following:

- The seatback to the most upright position
- The seat cushion to the fully rearward position



■ Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If the child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. (→P. 36)



Using a child restraint system

The use of a child restraint system not suitable for the vehicle may not properly secure the infant or child. It may result in death or serious injury (in the event of sudden braking, sudden swerving or an accident).

Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Toyota strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.

CAUTION

Child restraint precautions

Vehicles without airbag manual on-off switch: Never install a rear-facing child restraint system on the front passenger seat.

In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child.

Vehicles with airbag manual on-off switch: Never install a rear-facing child restraint system on the front passenger seat when the airbag manual onoff switch is on. (\rightarrow P. 54)

In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child.

- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. Always move the seat as far back as possible, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front, center and rear pillars or roof side rail from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or accident.

When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.


■When the child restraint system is not in use

- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the luggage compartment. This will prevent it from injuring passengers in the event of a sudden stop, sudden swerve or accident.

Installing child restraints


Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the seats using a seat belt or ISOFIX rigid anchors. Attach the top strap when installing a child restraint.

Seat belts (An ELR belt requires a locking clip)




ISOFIX rigid anchors (ISOFIX child restraint system)

Lower anchors are provided for the outboard second seats. (Tags displaying the location of the anchors are attached to the seats.)



Anchor brackets (for the top strap)

An anchor bracket is provided for each second seat.



Installing child restraints using a seat belt


■ Rear-facing — Baby seat/child seat


- 1 Adjust the seats as follows:
 - ▶ 3-door models

Fold the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position. (→P. 178)

- 1 1st lock position
- 2 5th lock position
- ▶ 5-door models


Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position). $(\rightarrow P. 178)$









2 Place the child restraint system on the second seat facing the rear of the vehicle.



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted. Keep the lap portion of the belt tight.



Install a locking clip near the tab of the lap and shoulder belt by inserting the lap and shoulder webbing through the recesses of the locking clip. Buckle the belt again. If the belt has any slack, release the buckle and reinstall the locking clip.




■ Forward-facing — Child seat


- 1 Adjust the seats as follows:
- ▶ 3-door models

Fold the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position. (→P. 178)

- 1 1st lock position
- 2 5th lock position
- ▶ 5-door models

Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position). $(\rightarrow P. 178)$





2 Place the child restraint system on the seat facing the


front of the vehicle.



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted. Keep the lap portion of the belt tight.



Install a locking clip near the tab of the lap and shoulder belt by inserting the lap and shoulder webbing through the recesses of the locking clip. Buckle the belt again. If the belt has any slack, release the buckle and reinstall the locking clip.





تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ م


■ Junior seat


- 1 Adjust the seats as follows:
 - ▶ 3-door models

Fold the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position. (→P. 178)

- 1 1st lock position
- 2 5th lock position
- ▶ 5-door models

Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position). $(\rightarrow P. 178)$





2 Place the child restraint system on the seat facing the

front of the vehicle.



3 Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.

Check that the shoulder belt is correctly positioned over the child's shoulder, and that the lap belt is as low as possible. $(\rightarrow P. 36)$



Removing a child restraint installed with a seat belt

Push the buckle release button and fully retract the seat belt.



Installation with ISOFIX rigid anchors (ISOFIX child restraint system)


- 1 Adjust the seats as follows:
- ▶ 3-door models


Fold the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position.

(→P. 178)

- 1 1st lock position
- 2 5th lock position
- ▶ 5-door models

Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position). (\rightarrow P. 178)








2 Flip the cover (3-door models and 5-door models with third power/manual seats), and latch the buckles onto the exclusive fixing bars.

If the child restraint has a top strap, the top strap should be latched onto the anchor bracket.



Child restraint systems with a top strap

1 Secure the child restraint system using a seat belt or ISOFIX rigid anchors, and move the head restraint in place at the upmost position.



2 Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top strap.

Make sure the top strap is securely latched.



■When installing a child restraint system (→P. 70)

You need a locking clip to install the child restraint system. Follow the instructions provided by the manufacturer of the system. If your child restraint system does not provide a locking clip, you can purchase the following item from any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer:

Locking clip for child restraint system (Part No. 73119-22010)

A CAUTION

■When installing a child restraint system


Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving or an accident.

If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand second seat (left-hand drive vehicles) or the left-hand second seat (right-hand drive vehicles).



- Adjust the front passenger seat so that it does not interfere with the child restraint system.
- Child restraint system installed on the third seat should not contact the second seatbacks.
- Vehicles without an airbag manual onoff switch: Only put a forward facing child restraint system on the front seat when unavoidable.





CAUTION

■When installing a child restraint system

Vehicles without an airbag manual onoff switch: Never install a rear-facing child restraint system on the front passenger seat.

The force of the rapid inflation of the front passenger airbag can cause death or serious injury to children in the event of an accident.


Vehicles with an airbag manual on-off switch: Never install a rear-facing child restraint system on the front passenger seat when the airbag manual on-off switch is on. $(\rightarrow P. 54)$


The force of the rapid inflation of the front passenger airbag can cause death or serious injury to children in the event of an accident.

On some models: There is a label(s) on the passenger side sun visor, indicating it is forbidden to attach a rear-facing child restraint system to the front passenger seat.

Details of the label(s) are shown in the illustration below.









CAUTION

■When installing a child restraint system

- If child restraint system regulations exist in the country where you reside, please contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for the child restraint system installation.
- When installing a child restraint system on the second center seat, adjust both seat cushions to the same position (vehicles with third manual/power seats) and align both seatbacks at the same angle. The seatbacks must be adjusted to the same angle. Otherwise, the child restraint system cannot be securely restrained and this may cause death or serious injuries in the event of sudden braking, sudden swerving or an accident.
- When a junior seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer. \ _ / / / * **/**\\\
- When using the left-hand second seat (left-hand drive vehicles) or right-hand second seat (right-hand drive vehicles) for the child restraint system, do not sit in the center second seat. Seat belt function may be impaired. such as being positioned overly high or

loose-fitting, which may result in death or serious injury in the event of sudden braking, sudden swerving or an acci-



■ To correctly attach a child restraint system to the anchors

When using the lower anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or accident.

Exhaust gas precautions

Harmful substance to the human body is included in exhaust gases if inhale.

A CAUTION

Exhaust gases include harmful carbon monoxide (CO), which is colorless and odorless. Observe the following precautions.

Failure to do so may cause exhaust gases enter the vehicle and may lead to an accident caused by light-headedness, or may lead to death or a serious health hazard.

Important points while driving

- Keep the back door closed.
- If you smell exhaust gases in the vehicle even when the back door is closed, open the windows and have the vehicle inspected at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible.

When parking

- If the vehicle is in a poorly ventilated area or a closed area, such as a garage, stop the engine.
- Do not leave the vehicle with the engine running for a long time. If such a situation cannot be avoided, park the vehicle in an open space and ensure that exhaust fumes do not enter the vehicle interior.
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle.

Exhaust pipe

The exhaust system needs to be checked periodically. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Engine immobilizer system

The vehicle's keys have built-in transponder chips that prevent the engine from starting if a key has not been previously registered in the vehicle's on-board computer.


Never leave the keys inside the vehicle when you leave the vehicle.

This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.

Vehicles without a smart entry& start system

The indicator light flashes after the key has been removed from the engine switch to indicate that the system is operating.

The indicator light stops flashing after the registered key has been inserted into the engine switch to indicate that the system has been canceled.



تلفن شبانه روزی:

▶ Vehicles with a smart entry & start system

The indicator light flashes after the engine switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the engine switch has been turned to ACCESSORY or IGNITION ON mode to indicate that the system has been canceled.

■System maintenance

The vehicle has a maintenance-free type engine immobilizer system.

■ Conditions that may cause the system to malfunction

- If the grip portion of the key is in contact with a metallic object
- If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle

■ Certifications for the engine immobilizer system (vehicles with a smart entry & start system)

TOYOTA

TOYOTA MOTOR CORPORATION

1. TOYOTA-CHO, TOYOTA, AICHI, 471-8571, JAPAN TEL:+81-565-28-2121

R&TTE Declaration of Conformity

We,

Manufacturer's Name: TOYOTA MOTOR CORPORATION

Manufacturer's Address: 1, Toyota -cho, Toyota, Aichi, 471-8572, Japan

hereby declare under our sole responsibility that the product:

Product Name: Immobilizer Product Model: TMIMB-2

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

-Health & safety requirements:

EN 60950-1

-EMC requirements

EN 301 489-01 & EN 301 489-03

-Effective uses of radio spectrum:

EN 300 330-2

Supplementary information:

* Member states intended for use

EU and EFTA

In two

Signature:

Tetsuya Matsuo

Hereby, TOYOTA MOTOR CORPORATION, declares that this TMIMB-2 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

TOYOTA MOTOR CORPORATION vakuuttaa täten että TMIMB-2 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart TOYOTA MOTOR CORPORATION dat het toestel TMIMB-2 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente TOYOTA MOTOR CORPORATION déclare que l'appareil TMIMB-2 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar TOYOTA MOTOR CORPORATION att denna TMIMB-2 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede TOYOTA MOTOR CORPORATION erklærer herved, at følgende udstyr TMIMB-2 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt TOYOTA MOTOR CORPORATION, dass sich das Gerät TMIMB-2 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ ΤΟΥΟΤΑ MOTOR CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ ΤΜΙΜΒ-2 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente TOYOTA MOTOR CORPORATION dichiara che questo TMIMB-2 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente TOYOTA MOTOR CORPORATION declara que el TMIMB-2 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

TOYOTA MOTOR CORPORATION declara que este TMIMB-2 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, TOYOTA MOTOR CORPORATION, jiddikjara li dan TMIMB-2 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab TOYOTA MOTOR CORPORATION seadme TMIMB-2 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, TOYOTA MOTOR CORPORATION nyilatkozom, hogy a TMIMB-2 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

TOYOTA MOTOR CORPORATION týmto vyhlasuje, že TMIMB-2 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

TOYOTA MOTOR CORPORATION tímto prohlašuje, že tento TMIMB-2 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

TOYOTA MOTOR CORPORATION izjavlja, da je ta TMIMB-2 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo TOYOTA MOTOR CORPORATION deklaruoja, kad šis TMIMB-2 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo TOYOTA MOTOR CORPORATION deklarē, ka TMIMB-2 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym TOYOTA MOTOR CORPORATION oświadcza, że TMIMB-2 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir TOYOTA MOTOR CORPORATION yfir því að TMIMB-2 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

TOYOTA MOTOR CORPORATION erklærer herved at utstyret TMIMB-2 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, TOYOTA MOTOR CORPORATION, декларира, че TMIMB-2 е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, TOYOTA MOTOR CORPORATION, declară că aparatul TMIMB-2 este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, TOYOTA MOTOR CORPORATION, izjavljuje da ovaj TMIMB-2 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, TOYOTA MOTOR CORPORATION, deklaroj qe ky TMIMB-2 eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tiera perkatese te Direktives 1999/5/EC.

Ovim TOYOTA MOTOR CORPORATION, izjavljuje da je TMIMB-2 u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, TOYOTA MOTOR CORPORATION, deklariše da je TMIMB-2 u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

↑ NOTICE

■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.




تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Double locking system^{*}

Unauthorized access to the vehicle is prevented by disabling the door unlocking function from both the interior and exterior of the vehicle.

Vehicles employing this system have labels on the window glass of both front doors.



Setting the double locking system

Turn the engine switch off, have all the passengers exit the vehicle and ensure that all the doors are closed.

Using the entry function (vehicles with a smart entry & start system): Touch the sensor area on the front outside door handles twice within 5 seconds.

Using the wireless remote control:

Press 🔒 twice within 5 seconds.

Canceling the double locking system

Using the entry function (vehicles with a smart entry & start system): Hold the outside door handle on the driver's side.

Using the wireless remote control: Press



A CAUTION

■ Double locking system precaution

Never activate the double locking system when there are people in the vehicle because all the doors cannot be opened from inside the vehicle.

*: If equipped

Alarm^{*}

The alarm

The alarm uses light and sound to give an alert when an intrusion is detected.


The alarm is triggered in the following situations when the alarm is set:

- A locked door or glass hatch (if equipped) is unlocked or opened in any way other than using the entry function or the wireless remote control. (The doors will lock again automatically.)
- The hood is opened.
- The intrusion sensor detects something moving inside the vehicle.
 (An intruder gets in the vehicle.) (if equipped)
- The tilt sensor detects a change of vehicle inclination. (vehicles for U.K.)
- The quarter windows (5-door models) or back door window are broken. (if equipped)

Setting the alarm system

Close the doors, glass hatch and hood, and lock all the doors using the entry function or wireless remote control. The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.



*: If equipped

Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarm.

- Unlock the doors using the entry function or the wireless remote control.
- Start the engine. (The alarm will be deactivated or stopped after a few seconds.)

■System maintenance

The vehicle has a maintenance-free type alarm system.

■ Items to check before locking the vehicle


To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following.

- Nobody is in the vehicle.
- The windows and moon roof (if equipped) are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

■ Triggering of the alarm

The alarm may be triggered in the following situations: (Stopping the alarm deactivates the alarm system.)


The doors are unlocked using the mechanical key.



 A person inside the vehicle opens a door or hood.



• The battery is recharged or replaced when the vehicle is locked. (→P. 699)



■ Alarm-operated door lock

In the following cases, depending on the situation, the door may automatically lock to prevent improper entry into the vehicle:

- When a person remaining in the vehicle unlocks the door and the alarm is activated.
- While the alarm is activated, a person remaining in the vehicle unlocks the door.
- When recharging or replacing the battery.

■ Customization

The alarm can be set to deactivate when the mechanical key is used to unlock.

(Customizable features: →P. 741)



■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

Intrusion sensor and tilt sensor (if equipped)

- The intrusion sensor detects intruders or movement in the vehicle.
- The tilt sensor detects changes in vehicle inclination, such as when the vehicle is towed away. (vehicles for U.K.)

This system is designed to deter and prevent vehicle theft but does not guarantee absolute security against all intrusions.

■ Setting the intrusion sensor and tilt sensor

The intrusion sensor and tilt sensor will be set automatically when the alarm is set. $(\rightarrow P. 90)$

■ Canceling the intrusion sensor and tilt sensor

If you are leaving pets or other moving things inside the vehicle, make sure to stop the intrusion sensor and tilt sensor before setting the alarm, as they will respond to movement inside the vehicle.

- 1 Turn the engine switch off.
- 2 Press the intrusion sensor and tilt sensor cancel switch.

When the system is canceled, the indicator flashes rapidly.




Canceling and automatic re-enabling of the intrusion sensor and tilt sensor (if equipped)

- The alarm will still be set even when the intrusion sensor and tilt sensor are canceled.
- After the intrusion sensor and tilt sensor are canceled, pressing the engine switch or unlocking the doors using the entry function or wireless remote control will re-enable the intrusion sensor and tilt sensor.
- The intrusion sensor and tilt sensor will automatically be re-enabled when the alarm system is deactivated.

■Intrusion sensor detection considerations (if equipped)

The sensor may trigger the alarm in the following situations:

- A window or the moon roof (if equipped) is open.
 - In this case, the sensor may detect the following:
 - Wind or the movement of objects such as leaves and insects inside the vehicle
 - Ultrasonic waves emitted from devices such as the intrusion sensors of other vehicles
 - · The movement of people outside the vehicle
- Unstable items, such as dangling accessories or clothes hanging on the coathooks, are in the vehicle.





FarmaSO

- Places with extreme vibrations or noises, or situations in which the vehicle is subject to repeated impacts or vibrations:
 - · When parked in a parking garage
 - When the vehicle is transported by a ferry, trailer, train, etc.
 - · When ice adhering to the vehicle is removed
 - · When the vehicle is in an automatic or high-pressure car wash
 - · When in a hail or lightning storm

■ Tilt sensor detection considerations (if equipped)

The sensor may trigger the alarm in the following situations:

- The vehicle is transported by a ferry, trailer, train, etc.
- The vehicle is parked in a parking garage.
- The vehicle is inside a car wash that moves the vehicle.
- Any of the tires loses air pressure.
- The vehicle is jacked up.
- An earthquake occurs or the road caves in.
- Cargo is loaded onto or unloaded from the roof luggage carrier.



■ To ensure the intrusion sensor functions correctly (if equipped)

 To ensure that the sensors operate properly, do not touch or cover them.



 Do not spray air fresheners or other products directly into the sensor holes.



FarmaSO



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

Instrument cluster

2

		Warning lights and indicators	98
		Gauges and meters	105
		Multi-information display	
		(Type A)	110
. /(9	9.79	Multi-information display	
		(Type B)	115
		Multi-information display	
		(Type C)	120
		Fuel consumption	


Instrument cluster

Warning lights and indicators


The warning lights and indicators on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

For the purpose of explanation, the following illustrations display all warning lights and indicators illuminated.


▶ Vehicles with the multi-information display type A



▶ Vehicles with the multi-information display type B



▶ Vehicles with the multi-information display type C





The units used on the speedometer and some indicators may differ depending on the target region.

تلفن شبانه روزی: ۱۹۲۰ میلا - ۲۱ - ۲۱

Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.







- *1: These lights turn on when the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system), to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or turn off. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- *2: The light flashes to indicate a malfunction.
- *3: This light illuminates on the center panel.

Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.





تلفن شبانه روزی: ۱۹۲۰۸۸۶۲۰۲۵ تلفن شبانه روزی

- *1: These lights turn on when the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or the engine switch is turned to IGNITION ON mode (vehicles with a smart entry & start system) to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not turn on, or if the lights do not turn off. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- *2: Refer to the "Off-road Driving Owner's Manual"
- *3: The light turns on when pre-crash braking is disabled. The light flashes quickly to indicate that the system is operating.
- *4: In order to confirm operation, the BSM outside rear view mirror indicators illuminate in the following situations:
 - When the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system) while the system is set to ON.
 - When the system is set to ON while the engine switch is in the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system). If the system is functioning correctly, the BSM outside rear view mirror indicators will turn off after a few seconds. If the BSM outside rear view mirror indicators do not illuminate or do not turn off, there may be a malfunction with the system. If this occurs, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- *5: This light illuminates on the outside rear view mirrors.
- *6: This light illuminates on the center panel.


A CAUTION .

■If a safety system warning light does not turn on


Should a safety system light such as ABS/Multi Terrain ABS and the SRS warning light not turn on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately if this occurs.

Gauges and meters


▶ Vehicles with the multi-information display type A



▶ Vehicles with the multi-information display type B



▶ Vehicles with the multi-information display type C



The units used on the speedometer may differ depending on the target region.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸ – ۲۱

- 1 Tachometer
 - Displays the engine speed in revolutions per minute
- ② Multi-information display

Presents the driver with a variety of driving-related data $(\rightarrow P. 110, 120)$

③ Speedometer

Displays the vehicle speed

4 Fuel gauge

Displays the quantity of fuel remaining in the tank

(5) Odometer and trip meter display

Odometer:

Displays the total distance the vehicle has been driven.

Trip meter:

Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.

6 Shift position and shift range


- Tengine coolant temperature gauge
 - Displays the engine coolant temperature
- 8 Odometer/trip meter display change button

→P. 108, 111

Changing the display

- ▶ Vehicles with the multi-information display type A and B
- →P. 110, 115
- ▶ Vehicles with the multi-information display type C

Switches between odometer and trip meter displays. When the trip meter is displayed, pressing and holding the button will reset the trip meter.



Instrument cluster light control

The brightness of the instrument cluster lights can be adjusted by turning the dial.

- 1 Darker
- 2 Brighter



■ The meters and display illuminate when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

The engine switch is in IGNITION ON mode.

■The brightness of the instrument cluster lights

▶ Vehicles with the multi-information display type A and B

When the headlight switch is turned to on, the brightness will be reduced slightly.

▶ Vehicles with the multi-information display type C

When the headlight switch is turned to on, the brightness will be reduced slightly unless the control dial is turned fully clockwise.

■ When disconnecting and reconnecting battery terminals

- ▶ Vehicles with the multi-information display type A and B
- →P. 114, 119
- ▶ Vehicles with the multi-information display type C

The trip meter data will be reset.

If the trip meter was displayed last, the ODO screen will be displayed after resetting.



NOTICE


■ To prevent damage to the engine and its components

- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P. 701)

Multi-information display (Type A)*

Display contents

The multi-information display presents the driver with a variety of driving-related data including the current outside air temperature.



Outside temperature display


(→P. 112)

● Trip information contents

- (→P. 111)
- Shift position and shift range (if equipped)
- (→P. 257)
- Eco Driving Indicator Zone Display (if equipped)
- (→P. 113)

Switching the display

Items displayed can be switched by pressing the "ODO/TRIP" button.



Trip information contents

Odometer

Displays the total distance the vehicle has been driven.

■ Trip meters A and B

Display the distance the vehicle has been driven since the meters were last reset. Trip meters A and B can be used to record and display different distances independently.

Press the hold the button to reset.

Driving range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.

■ Current fuel consumption

Displays the current rate of fuel consumption

■ Eco Driving Indicator Zone Display*

→P. 113

■ Average fuel consumption

Displays the average fuel consumption since the function was reset

- The function can be reset by pressing the "ODO/TRIP" button for longer than 1 second when the average fuel consumption is displayed.
- Use the displayed average fuel consumption as a reference.

■ Average vehicle speed

Displays the average vehicle speed since the engine was started or the function was reset

The function can be reset by pressing the "ODO/TRIP" button for longer than 1 second when the average vehicle speed is displayed.

■ Outside temperature display

Displays the outside temperature The temperature range that can be displayed is from -40 $^{\circ}$ C (-40 $^{\circ}$ F) to 50 $^{\circ}$ C (122 $^{\circ}$ F).

■ Eco Driving Indicator Light setting screen*

Eco Driving Indicator Light can be set to on or off.


The function can be activated or deactivated by pressing the "ODO/TRIP" button for longer than 1 second when Eco Driving Indicator Light setting screen is displayed.

*: Displayed on vehicles with an automatic transmission only

تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

■ Eco Driving Indicator (vehicles with an automatic transmission)

- Eco Driving Indicator Light
 During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on.
- ② Eco Driving Indicator Zone Display Suggests Zone of Eco driving with current Eco driving ratio based on acceleration.
- 3 Zone of Eco driving
- ④ Eco driving ratio based on acceleration If the vehicle exceeds Zone of Eco driving, the right side of Eco Driving Indicator Zone Display will blink and Eco Driving Indicator Light will turn off.



Eco Driving Indicator Light will not operate in the following conditions:

- The shift lever is in anything other than D.
- The vehicle is set to second start mode. (→P. 258)
- The vehicle speed is approximately 130 km/h (80 mph) or higher.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ الا

■When disconnecting and reconnecting battery terminals

The following information data will be reset:

- Trip meter
- Average fuel consumption
- Average vehicle speed

If the trip meter was displayed last, the ODO screen will be displayed after resetting.

■ Customization

Settings (e.g. available language) can be changed. (Customizable features →P. 742)



A CAUTION

■The multi-information display at low temperatures (vehicles with an automatic transmission)

Allow the interior of the vehicle to warm up before using the multi-information display. At extremely low temperatures, the multi-information display monitor may respond slowly, and display changes may be delayed. For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or serious injury.




■The multi-information display at low temperatures (vehicles with a manual transmission)

Allow the interior of the vehicle to warm up before using the multi-information display. At extremely low temperatures, the multi-information display monitor may respond slowly, and display changes may be delayed.

Multi-information display (Type B)

Display contents

The multi-information display presents the driver with a variety of driving-related data including the current outside air temperature.



Outside temperature display

(→P. 117)

● Trip information contents

(→P. 116)

● Shift position and shift range (if equipped)


(→P. 257)

Eco Driving Indicator Zone Display (if equipped)

(→P. 118)

Switching the display

Items displayed can be switched by pressing the "ODO/TRIP" button.



Trip information contents

Odometer

Displays the total distance the vehicle has been driven.

■ Trip meters A and B

Display the distance the vehicle has been driven since the meters were last reset. Trip meters A and B can be used to record and display different distances independently.

Press the hold the button to reset.

Driving range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.

■ Current fuel consumption

Displays the current rate of fuel consumption

■ Eco Driving Indicator Zone Display (vehicles with an automatic transmission)

→P. 118

■ Average fuel consumption

Displays the average fuel consumption since the function was reset

- The function can be reset by pressing the "ODO/TRIP" button for longer than 1 second when the average fuel consumption is displayed.
- Use the displayed average fuel consumption as a reference.


■ Average vehicle speed

Displays the average vehicle speed since the engine was started or the function was reset

The function can be reset by pressing the "ODO/TRIP" button for longer than 1 second when the average vehicle speed is displayed.

■ Outside temperature display

Displays the outside temperature



When the outside temperature drops below 3 °C (37 °F), and the outside temperature are displayed.


■ Settings display

Settings (e.g. available language) can be changed. (Customizable features →P. 742)



■ Eco Driving Indicator (vehicles with an automatic transmission)

- Eco Driving Indicator Light
 During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on.
- ② Eco Driving Indicator Zone Display Suggests Zone of Eco driving with current Eco driving ratio based on acceleration.
- 3 Zone of Eco driving
- ④ Eco driving ratio based on acceleration If the vehicle exceeds Zone of Eco driving, the right side of Eco Driving Indicator Zone Display will blink and Eco Driving Indicator Light will turn off.



Eco Driving Indicator Light will not operate in the following conditions:

- The shift lever is in anything other than D.
- The vehicle is set to second start mode. (→P. 258)
- The vehicle speed is approximately 130 km/h (80 mph) or higher.

تلفن شبانه روزى: ۱۵۸۰۲۰۸۸۸-۲۱۰

■When disconnecting and reconnecting battery terminals

The following information data will be reset:

- Trip meter
- Average fuel consumption
- Average vehicle speed

If the trip meter was displayed last, the ODO screen will be displayed after resetting.



■The multi-information display at low temperatures (vehicles with an automatic transmission)

Allow the interior of the vehicle to warm up before using the multi-information display. At extremely low temperatures, the multi-information display monitor may respond slowly, and display changes may be delayed. For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or serious injury.



NOTICE


■The multi-information display at low temperatures (vehicles with a manual transmission)

Allow the interior of the vehicle to warm up before using the multi-information display. At extremely low temperatures, the multi-information display monitor may respond slowly, and display changes may be delayed.

Multi-information display (Type C)*

Display contents

The multi-information display presents the driver with a variety of driving-related data including the current outside air temperature.



Trip information contents

(→P. 121)

Displays driving range, fuel consumption and other cruising related information

Electronic features control contents

(→P. 122)

Other contents

(→P. 123)


Switching the display

Menu switch

Changes modes to electronic features control mode, customization mode or back to normal display mode

(2) "ENTER" switch

Changes trip information items. This switch is also used to turn on/ off electronic features controls and to change customization settings.



Trip information contents

Trip information items displayed can be switched by pressing the "ENTER" switch upwards or downwards.

■ Front tire angle

The direction of the front tires is displayed

The tire direction is displayed in 3 stages for both left and right, in accordance with the angle of the tire.

Speedometer

تلفن شبانه روزي: الله Displays the vehicle speed.

Driving range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

Average fuel consumption after refueling

Displays the average fuel consumption since the vehicle was last refueled

Use the displayed average fuel consumption as a reference.

■ Current fuel consumption

Displays the current rate of fuel consumption

■ Average fuel consumption

Displays the average fuel consumption since the function was reset

- The function can be reset by pressing the "ENTER" switch for longer than 1 second when the average fuel consumption is displayed.
- Use the displayed average fuel consumption as a reference.

■ Eco Driving Indicator Zone Display

→P. 125

Average vehicle speed

Displays the average vehicle speed since the engine was started or the function was reset

The function can be reset by pressing the "ENTER" switch for longer than 1 second when the average vehicle speed is displayed.

■ Elapsed time

Displays the elapsed time since the function was last reset

The function can be reset by pressing the "ENTER" switch for longer than 1 second when the elapsed time is displayed.

■ Clinometer (L4L/L4 only)

→Refer to the "Off-road Driving Owner's Manual"

■ Differential lock/unlock display (L4L/L4 only)

→Refer to the "Off-road Driving Owner's Manual"

■ Active TRC (Traction Control) display (if equipped)

→Refer to the "Off-road Driving Owner's Manual"

■ Display off

A blank screen is displayed

Electronic features control contents

- Toyota parking assist-sensor (if equipped) (→P. 324)
- BSM (Blind Spot Monitor) (if equipped) (→P. 378)
- Second start mode (if equipped) (\rightarrow P. 258)

Other contents

- Shift position and shift range (if equipped) (→P. 257)
- Rear height control air suspension display (if equipped)
 - →Refer to the "Off-road Driving Owner's Manual"
- Multi-terrain Select display (if equipped)
 - →Refer to the "Off-road Driving Owner's Manual"
- Crawl Control display* (if equipped)
 - →Refer to the "Off-road Driving Owner's Manual"
- Dynamic radar cruise control display* (if equipped) (→P. 306)
- Warning messages (→P. 636)

Automatically displayed when a malfunction occurs in one of the vehicles systems

■ Compass (vehicles with a navigation system)

The compass indicates the direction in which the vehicle is heading.

Displays and directions: →P. 126

■ Outside temperature display

Displays the outside temperature

The temperature range that can be displayed is from -40 °C (-40 °F) to 50 °C (122 °F).

When the outside temperature drops below 3 °C (37 °F), and the outside temperature are displayed.

■ Turn-by-turn navigation screen (vehicles with a navigation system) (→P. 124)

If the turn-by-turn navigation setting screen is not displayed, set the destination. When the destination is set, the turn-by-turn navigation screen is displayed.

■ Customization

Settings (e.g. available language) can be changed. (Customizable features →P. 742)

^{*:} Automatically displayed when the system is used

■ Electronic features control can be turned on/off when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

The engine switch is in IGNITION ON mode.

■ System check display

▶ Vehicles without a smart entry & start system

After turning the engine switch to "ON" position, opening image is displayed while system operation is checked. When the system check is complete, the normal screen will return.

▶ Vehicles with a smart entry & start system

After switching the engine switch to IGNITION ON mode, opening image is displayed while system operation is checked. When the system check is complete, the normal screen will return.

■ Conditions for ending electronic features control

In the following situations, the electronic features control will end automatically:


- The menu switch is pressed
- Toyota parking assist-sensor starts operating (if equipped)
- The Crawl Control is operated (if equipped)
- The dynamic radar cruise control is operated (if equipped)
- A warning message appears after the electronic features control screen is displayed

■Turn-by-turn navigation (vehicles with a navigation system)

The turn-by-turn navigation appears only while route guidance of the navigation system is being performed. When a turn approaches, the distance to the turn and the turn direction are displayed.


- 1 Distance to the next turn
- ② Turn direction

The image shown may differ from the actual intersection.



■ Eco Driving Indicator (vehicles with an automatic transmission)

- Eco Driving Indicator Light
 During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on.
- ② Eco Driving Indicator Zone Display Suggests Zone of Eco driving with current Eco driving ratio based on acceleration.
- 3 Zone of Eco driving
- ④ Eco driving ratio based on acceleration If the vehicle exceeds Zone of Eco driving, the right side of Eco Driving Indicator Zone Display will blink and Eco Driving Indicator Light will turn off.



Eco Driving Indicator Light will not operate in the following conditions:

- The shift lever is in anything other than D.
- The vehicle is set to second start mode. (→P. 258)
- The vehicle speed is approximately 130 km/h (80 mph) or higher.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ الا

■ Displays and directions of the compass (vehicles with a navigation system)

Display	Direction	
N	North	
NE	Northeast	
E	East	
SE	Southeast	
S	South	
SW	Southwest	
W	West	
NW	Northwest	

Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change:

- When the vehicle is stopped, or moving at low speeds (less than 20 km/h [12 mph])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)

تلفن شبانه روزي:

■When "--" or "E" is displayed

The system may be malfunctioning. Take your vehicle to any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■When disconnecting and reconnecting battery terminals

- The following information data will be reset:Average fuel consumption after refueling
 - · Average fuel consumption
 - · Average vehicle speed
 - · Elapsed time
- The following information data will be initialized:
 - Turn-by-turn navigation (vehicles with a navigation system)

A CAUTION

■ The multi-information display at low temperatures (vehicles with an automatic transmission)

Allow the interior of the vehicle to warm up before using the multi-information display. At extremely low temperatures, the multi-information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or serious injury.

↑ NOTICE

■The multi-information display at low temperatures (vehicles with a manual transmission)

Allow the interior of the vehicle to warm up before using the multi-information display. At extremely low temperatures, the multi-information display monitor may respond slowly, and display changes may be delayed.

تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

Fuel consumption information^{*}

The fuel consumption information can be displayed on the navigation system or multimedia system screen.

Display the screen

Press the "CAR" button, and then select "Trip information" on the screen.

Fuel consumption

- 1 Cruising range
- ② Previous fuel consumption per minute
- (3) Reset the trip information data



Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the engine switch was last turned to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system). Use the displayed average fuel consumption as a reference.

These images are examples only, and may vary slightly from actual conditions.

■ Resetting the data

Selecting "Clear" on the consumption screen will reset the consumption data.

■ Cruising range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.

*: If equipped

Operation of each component

3


3-1.	Key information	
	Keys13	0
3-2.	Opening, closing and locking the doors	g
1 1	Side doors13	
1 1/2 2 2 2	Back door14	6
6/19 9/19	Glass hatch15	3
	Smart entry & start system15	۵
2.2	•	J
3-3.	Adjusting the seats	_
	Front seats17	
+ 1 1 - 1 1 1 2 1 1 1 1	Rear seats17	
1 1 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	Driving position memory 19	
	Head restraints19	7
3-4.	Adjusting the steering whee and mirrors	ı
FarmaSO:	Steering wheel20	Λ
	Inside rear view mirror20	
		J
	Outside rear view mirrors20	_
		J
3-5.	Opening and closing the windows and moon roof	
	Power windows20	8
	Moon roof21	2

Keys

The keys

The following keys are provided with the vehicle.

▶ Vehicles without a smart entry & start system (type A)




- 1 Master keys
- 2 Valet key
- ③ Wireless remote controls
 Operating the wireless remote control function
- 4 Key number plate


FarmaSOS.com

تلفن شبانه روزی: ۱۸۵ ۲۶۸۸ تلفن

- 1 Master keys
 - Operating the wireless remote control function
- 2 Valet key
- 3 Key number plate



- ▶ Vehicles with a smart entry & start system
- 1) Electronic keys
 - Operating the smart entry & start system (→P. 159)
 - Operating the wireless remote control function
- 2 Mechanical keys
- 3 Key number plate




تلفن شبانه روزی: ۱-۲۱-۸۸۸۶۲ ۲۲ **۰**


Operation of each component

Wireless remote control

- ▶ Vehicles without a smart entry & start system (type A)
- 1 Locks the doors (\rightarrow P. 136)
- ② Closes the windows and moon roof* (→P. 136)
- ③ Unlocks the doors (→P. 136)
- ④ Opens the windows and moon roof* (→P. 136)
- ⑤ Opens the glass hatch (→P. 153)




- *: These settings must be customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- ▶ Vehicles without a smart entry & start system (type B: 2 switches)
- 1 Locks the doors (\rightarrow P. 136)
- ② Closes the windows and moon roof* (→P. 136)
- ③ Unlocks the doors (\rightarrow P. 136)
- 4 Opens the windows and moon $roof^* (\rightarrow P. 136)$



*: These settings must be customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

- ▶ Vehicles without a smart entry & start system (type B: 3 switches)
- 1 Locks the doors (\rightarrow P. 136)
- ② Closes the windows and moon roof* (→P. 136)
- ③ Unlocks the doors (\rightarrow P. 136)
- ④ Opens the windows and moon roof* (→P. 136)
- ⑤ Opens the glass hatch(→P. 153)



- *: These settings must be customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- ▶ Vehicles with a smart entry & start system
- 1 Locks the doors (\rightarrow P. 136)
- ② Closes the windows and moon roof* (→P. 136)
- ③ Unlocks the doors (\rightarrow P. 136)
- ④ Opens the windows and moon roof* (→P. 136)
- ⑤ Opens the glass hatch (vehicles with a glass hatch)(→P. 153)




*: These settings must be customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Using the mechanical key (vehicles with a smart entry & start system)

To take out the mechanical key, push the release button and take the key out.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key. $(\rightarrow P. 691)$



■When required to leave the vehicle's key with a parking attendant

Lock the glove box as circumstances demand. (→P. 497)

▶ Vehicles without a smart entry & start system

Carry the master key for your own use and provide the attendant with the valet key.

▶ Vehicles with a smart entry & start system

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

■ If you lose your keys/wireless remote control

Keys

 $^{+}$ تلفن شبانه روزی: $\omega \wedge ^{+}$

New genuine keys can be made by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer using a master key (vehicles without a smart entry & start system) or the other key (vehicles with a smart entry & start system) and the key number stamped on your key number plate. Keep the plate in a safe place such as your wallet, not in the vehicle.

▶ Wireless remote control (if equipped)

New genuine wireless remote control can be purchased and programmed by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. If a wireless remote control has been lost, bring the other wireless remote control when going to pick up the new one.

■When riding in an aircraft

When bringing a key with wireless remote control function onto an aircraft, make sure you do not press any buttons on the key while inside the aircraft cabin. If you are carrying the key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the key to emit radio waves that could interfere with the operation of the aircraft.

■ Key battery depletion

▶ Vehicles without a smart entry & start system

If the wireless remote control function does not operate, the battery may be depleted. Replace the battery when necessary. $(\rightarrow P. 588)$

▶ Vehicles with a smart entry & start system

→P. 165

■ Replacing the electronic key battery

→P. 588



NOTICE

■ To prevent key damage

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for long periods of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the electronic key.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers, or medical electrical equipment, such as low-frequency therapy equipment.

Carrying the electronic key on your person (vehicles with a smart entry & start system)

Carry the electronic key 10 cm (3.9 in.) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 10 cm (3.9 in.) of the electronic key may interfere with the key, causing the key to not function properly.

In case of a smart entry & start system malfunction or other key-related problems (vehicles with a smart entry & start system)

Take your vehicle with all the electronic keys provided with your vehicle to any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

When an electronic key is lost (vehicles with a smart entry & start system)

If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately with all remaining electronic keys that were provided with your vehicle.

Side doors

The vehicle can be locked and unlocked using the entry function, wireless remote control, key or door lock switch.

Locking and unlocking the doors from the outside

Smart entry & start system (if equipped)


Carry the electronic key to enable this function.

① Grip the front door handle to unlock the doors.

Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked.


② Touch the lock sensor (the indentation on the upper or lower part of the front door handle) to lock the doors.




Theck that the door is securely locked. وزى شبانه روزى


Wireless remote control

- ► Vehicles without a smart entry & start system (type A)
- Vehicles without a smart entry & start system (type B: 2 switches)





- Vehicles without a smart entry & start system (type B: 3 switches)
- ➤ Vehicles with a smart entry & start system





1 Locks all the doors


Press and hold to close the windows and moon roof.* Check that the door is securely locked.

- 2 Unlocks all the doors
 - Press and hold to open the windows and moon roof.*
- *: These settings must be customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Key

- ▶ Vehicles without a smart entry & start system
- ① Locks all the doors

 Turn and hold to close the windows and moon roof.*
- ② Unlocks all the doors
 Turn and hold to open the windows and moon roof.*
- *: These settings must be customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



▶ Vehicles with a smart entry & start system

The doors can also be locked and unlocked with the mechanical key. $(\rightarrow P. 691)$

■ Operation signals

Doors: A buzzer (if equipped) sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)


Windows and moon roof: A buzzer sounds to indicate that the windows and moon roof are operating.

■ Security feature

If a door or the glass hatch is not opened within approximately 30 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

■When the door cannot be locked by the lock sensor on the upper part of the door handle (vehicles with a smart entry & start system)

If the door will not lock even when the topside sensor area is touched, try touching both the topside and underside sensor areas at the same time.



■ Door lock buzzer

If an attempt to lock the doors is made when a door and/or the glass hatch is not fully closed, a buzzer sounds continuously for 5 seconds. Fully close the door and/or the glass hatch to stop the buzzer, and lock the vehicle once more.

- Setting the alarm (if equipped)
 - Locking the doors will set the alarm system. (\rightarrow P. 90)
- If the smart entry & start system or the wireless remote control does not operate properly (vehicles with a smart entry & start system)
 - Use the mechanical key to lock and unlock the doors. (\rightarrow P. 691)
 - lacktriangle Replace the battery with a new one if it is depleted. (\rightarrow P. 588)


A CAUTION

- When closing the windows or moon roof using wireless remote control Observe the following precautions. Failing to do so may result in death or serious injury.
 - Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window or moon roof is being operated.
- To prevent inadvertent power windows and moon roof operation, never let a small child have and use the wireless remote control.
- Jam protection function
 - Never try jamming any part of your body to activate the jam protection function intentionally.
 - The jam protection function may not work if something gets caught just before the window or moon roof fully closes.

Locking and unlocking the doors from the inside

Door lock switch


- 1 Locks all the doors
- 2 Unlocks all the doors



Inside lock button

- 1 Locks the door
- 2 Unlocks the door

The driver's door and front passenger's door (for some models only) can be opened by pulling the inside handle even if the lock button is in the lock position



Locking the front doors from the outside without a key

- 1 Move the inside lock button to the lock position.
- 2 Close the door while pulling the door handle.
- ▶ Vehicles without a smart entry & start system

The door cannot be locked if the key is in the engine switch.

▶ Vehicles with a smart entry & start system

The door cannot be locked if the engine switch is in ACCESSORY or IGNITION ON mode, or the electronic key is left inside the vehicle. However, the key may not be detected correctly and the door may be locked.

Rear door child-protector lock (5-door models)

The door cannot be opened from inside the vehicle when the lock is set.

- 1 Unlock
- 2 Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.



Automatic door locking and unlocking systems (if equipped)

The following functions can be set or canceled:

Function	Operation
Shift position linked door unlocking function*	Shifting the shift lever to P unlocks all the doors.
Driver's door linked door unlocking function	All the doors are unlocked when the driver's door is opened within 43 seconds after turning the engine switch off.


^{*:} Vehicles with an automatic transmission

■ Setting and canceling the functions

To switch between setting and canceling, follow the procedure below.

- 1 Close all the doors and turn the engine switch to IGNITION ON mode. (Perform step 2 within 20 seconds.)
- 2 Shift the shift lever to P or N, and press and hold the driver's door lock switch (or or) for approximately 5 seconds and then release.

The shift lever and switch positions corresponding to the desired function to be set are shown in the following table.



Use the same procedure to cancel the function.

Function	Shift lever position	Driver's door lock switch position
Shift position linked door unlocking function*	Р	a
Driver's door linked door unlocking function	N	a

^{*:} Vehicles with an automatic transmission

When the setting or canceling operation is complete, all the doors are locked and then unlocked.

■ Changing the door unlock function setting (vehicles with a smart entry & start system)

It is possible to set which doors the entry function unlocks using the wireless remote control.

- 1 Turn the engine switch off.
- 2 Cancel the intrusion sensor and tilt sensor of the alarm system to prevent unintended triggering of the alarm during the setting change. (→P. 93)

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step 3.)

Multi-information display	Unlocking function	Веер
(Left-hand drive vehicles)	Holding the driver's door handle unlocks only the driver's door.	Exterior: Beeps 3 times
(Right-hand drive vehicles)	Holding the front passenger's door handle unlocks all the doors.	Interior: Pings once
	Holding either door handle unlocks all the doors.	Exterior: Beeps twice Interior: Pings once

For vehicles with an alarm: To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door or the glass hatch is not opened within 30 seconds after is pressed, the doors will be locked again and the alarm will automatically be set.)

In case that the alarm is triggered, immediately stop the alarm. (→P. 90)

■ Conditions affecting the operation of the smart entry and start system or wireless remote control

▶ Vehicles without a smart entry & start system

The wireless remote control function may not operate normally in the following situations.

- Near a TV tower, radio station, electric power plant, airport or other facility that generates strong radio waves
- When carrying a portable radio, cellular phone or other wireless communication device
- When multiple wireless keys are in the vicinity
- When the wireless key has come into contact with, or is covered by a metallic object
- When a wireless key (that emits radio waves) is being used nearby
- When the wireless key has been left near an electrical appliance such as a personal computer
- ▶ Vehicles with a smart entry & start system

→P. 162

■ Customization

Settings (e.g. unlocking function using a key) can be changed (Customizable features →P. 741)

CAUTION

■ To prevent an accident

Observe the following precautions while driving the vehicle. Failing to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.

- Ensure that all the doors are properly closed.
- Do not pull the inside handle of the doors while driving Be especially careful for the front doors, as the doors may be opened
 - even if the inside lock button is in locked position.
- Set the rear door child-protector locks when children are seated in the second seat.

■When using the wireless remote control and operating the power windows or moon roof

Operate the power window or moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or moon roof. Also, do not allow children to operate the wireless remote control. It is possible for children and other passengers to get caught in the power window or moon roof.

Back door


The back door can be locked/unlocked and opened by the following procedures.

Locking and unlocking the back door from the outside

Smart entry & start system (if equipped)

Carry the electronic key to enable this function.


- ▶ Vehicles with back door mounted spare tire
- Locks all the doors
 Check that the door is securely locked.
- ② Unlocks all the doors The doors cannot be unlocked for 3 seconds after the doors are



- ▶ Vehicles with under floor mounted spare tire
- Locks all the doors
 Check that the door is securely locked.
- 2 Unlocks all the doors

locked.

The doors cannot be unlocked for 3 seconds after the doors are locked.




Wireless remote control

→P. 137

Locking and unlocking the back door from the inside

- Door lock switch
 - 1 Locks all the doors
 - ② Unlocks all the doors




- Inside lock button (vehicles with longitudinal type third seats)
 - 1 Locks the door



Opening the back door from the outside


- ▶ Vehicles with back door mounted spare tire
- 1) Pull the handle
- ② Open the back door

The back door can be kept open at a desired position.



- ▶ Vehicles with under floor mounted spare tire
- 1) Pull the handle
- 2 Open the back door

The back door can be kept open at a desired position.




Keeping the back door open

- 1 Unlocks the back door stopper
- 2 Locks the back door stopper

The back door stopper can only be operated when the back door is fully open.

When closing the back door, check that the back door stopper is unlocked.




Back door child-protector lock (vehicles with longitudinal type third seats)

The door cannot be opened from inside the vehicle when the lock is set.


- 1 Unlock
- ② Lock

This lock can be set to prevent children from opening the back door. Push down on back door switch to lock back door.



When closing the back door


Close the back door using the back door handle, and make sure to push the back door from the outside to close it.





Rear step bumper

The rear step bumper is for rear end protection and easier step-up loading.



CAUTION

■While driving

- Keep the back door closed while driving. If the back door is left open, it may hit near-by objects while driving or luggage may be unexpectedly thrown out, causing an accident. In addition, exhaust gases may enter the vehicle, causing death or a serious health hazard. Make sure to close the back door before driving.
- Before driving the vehicle, make sure that the back door is fully closed. If the back door is not fully closed, it may open unexpectedly while driving, causing an accident.
- Never let anyone sit in the luggage compartment. In the event of sudden braking, sudden swerving or a collision, they are susceptible to death or serious injury.

■When children are in the vehicle

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not allow children to play in the luggage compartment. If a child is accidentally locked in the luggage compartment, they could have heat exhaustion or other injuries.
- Do not allow a child to open or close the back door. Doing so may cause the back door to move unexpectedly, or cause the child's hands, head, or neck to be caught by the closing back door.

* **/**\\

Operating the back door

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in death or serious injury.

- •When opening or closing the back door, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the back door is about to open or close.
- Use caution when opening or closing the back door in windy weather as it may move abruptly in strong wind.

A CAUTION

Operating the back door

• The back door may suddenly shut if the back door stopper is not locked. It is more difficult to open or close the back door on an incline than on a level surface, so beware of the back door unexpectedly opening or closing by itself. Make sure that the back door stopper is locked and secure before using the luggage compartment.



- Even with the back door stopper locked, the back door stopper may unlock and the back door may close when excessive force such as a strong wind is applied to the back door. Take extra care to prevent any part of your body from being caught.
- When closing the back door, take extra care to prevent your fingers etc. from being caught.
- When closing the back door, make sure to press it lightly on its outer surface. If the back door handle is used to fully close the back door, it may result in hands or arms being caught.



- Do not pull on the back door damper stay to close the back door, and do not hang on the back door damper stay.
 Doing so may cause hands to be caught or the back door damper stay to break, causing an accident.
- If a bicycle carrier or similar heavy object is attached to the back door, it may suddenly shut again after being opened, causing someone's hands, head or neck to be caught and injured. When installing an accessory part to the back door, using a genuine Toyota part is recommended.

↑ NOTICE


■ Back door damper stay

The back door is equipped with damper stay that hold the back door in place.

Observe the following precautions.

Failure to do so may cause damage to the back door damper stay, resulting in malfunction.

- Do not attach any accessories other than genuine Toyota parts to the back door.
- Do not lean against, climb on or place luggage on the damper stay, or apply lateral forces to it.



تلفن شبانه روزی: ۱۹۲۰ میلا - ۲۱ - ۲۱

Glass hatch*


The glass hatch can be opened using the glass hatch opener or wireless remote control.

Opening the glass hatch

Glass hatch opener

- 1 Press the button to pop up the glass hatch.
- 2 Raise


The glass hatch cannot be opened when the back door is locked. Unlock the back door to open the glass hatch. (→P. 146)



Smart entry & start system (if equipped)

- ① While carrying the electronic key, press the button to pop up the glass hatch.
- ② Raise

The glass hatch can be opened even when the back door is locked.



*: If equipped

◆ Wireless remote control

Press and hold the button to open the glass hatch. The glass hatch will pop up.

- ▶ Vehicles without a smart entry ▶ Vehicles without a smart entry & start system (type A)
 - & start system (type B)



■When opening the glass hatch

- Open the glass hatch slowly and carefully.
- Use the glass hatch opener or wireless remote control when the back door is closed.

■ Operation signals (when opening with the wireless remote control)

A buzzer (if equipped) sounds once to indicate that the glass hatch have been opened.

■ Opening the glass hatch while the rear window wiper is in operation

Rear window wiper operation will stop moving. Operation will recommence after the glass hatch has been closed.

■ Door lock buzzer

If an attempt to lock the doors and/or the glass hatch is made when a door is not fully closed, a buzzer sounds continuously for 5 seconds. Fully close the door and/or the glass hatch to stop the buzzer, and lock the vehicle once more

- Function to prevent the glass hatch being locked with the electronic key inside (vehicles with a smart entry & start system)
 - When all doors are being locked, closing the glass hatch with the electronic key left inside the luggage compartment will sound an alarm.
 In this case, the glass hatch can be opened using the entry function.
 - Even when the spare electronic key is put in the luggage compartment with all the doors locked, the key confinement prevention function can be activated so the glass hatch can be opened. In order to prevent theft, take all electronic keys with you when leaving the vehicle.
 - Even when the electronic key is put in the luggage compartment with all the doors are locked, the key may not be detected depending on the places and the surrounding radio wave conditions. In this case, the key confinement prevention function cannot be activated, causing the doors to lock when the glass hatch is closed. Make sure to check where the key is before closing the glass hatch.

■ After closing the glass hatch

Check that the glass hatch is firmly closed. If it is not firmly closed, the rear window wiper and washer will not operate correctly.

■ Customization

The glass hatch opening operation can be changed. (Customizable features: →P. 741)

CAUTION

■While driving

- Keep the glass hatch closed while driving.
 - If the glass hatch is left open, it may hit near-by objects while driving or luggage may be unexpectedly thrown out, causing an accident. In addition, exhaust gases may enter the vehicle, causing death or a serious health hazard. Make sure to close the glass hatch before driving.
- Before driving the vehicle, make sure that the glass hatch is fully closed. If the glass hatch is not fully closed, it may open unexpectedly while driving, causing an accident.

■When children are in the vehicle

Do not allow a child to open or close the glass hatch.

Doing so may cause the glass hatch to move unexpectedly, or cause the child's hands, head, or neck to be caught by the closing glass hatch.

Operating the glass hatch

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in death or serious injury.

- Remove any heavy loads, such as snow and ice, from the glass hatch before opening it. Failure to do so may cause the glass hatch suddenly shut again after it is opened.
- When opening or closing the glass hatch, thoroughly check to make sure the surrounding area is safe. * **/**\\
- If anyone is in the vicinity, make sure they are safe and let them know that the glass hatch is about to open or close.
- Use caution when opening or closing the glass hatch in windy weather as it may move abruptly in strong wind.

A CAUTION

Operating the glass hatch

- The glass hatch may close if it is not opened fully. It is more difficult to open or close the glass hatch on an incline than on a level surface, so beware of the glass hatch unexpectedly opening or closing by itself. Make sure that the glass hatch is fully open and secure before using the luggage compartment.
- When closing the glass hatch, take extra care to prevent your fingers etc. from being caught.
- When closing the glass hatch, make sure to press it lightly on its outer surface.





- Do not pull on the glass hatch damper stay to close the glass hatch, and do not hang on the glass hatch damper stay.
 Doing so may cause hands to be caught or the glass hatch damper stay to break, causing an accident.
- Do not attach any accessories other than genuine Toyota parts to the glass hatch. Such additional weight on the glass hatch may cause the glass hatch to suddenly shut again after it is opened.

№ NOTICE


■ Glass hatch damper stays

The glass hatch is equipped with damper stays that hold the glass hatch in place.

Observe the following precautions.

Failure to do so may cause damage to the glass hatch damper stay, resulting in malfunction.

- Do not attach any foreign objects, such as strikers, plastic sheets, or adhesives to the damper stay rod.
- Do not touch the damper stay rod with gloves or other fabric items.
- Do not attach any accessories other than genuine Toyota parts to the glass hatch.
- Do not place your hand or foot on the damper stay or apply lateral forces to it.



تلفن شبانه روزی: ۱۹۲۰ میلا - ۲۱ - ۲۱


Smart entry & start system*

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. The driver should always carry the electronic key.

- Locks and unlocks the side doors (\rightarrow P. 136)
- Locks and unlocks the back door (→P. 146)
- Opens the glass hatch (→P. 153)
- Starts the engine (\rightarrow P. 249)

■ Antenna location

- ① Antennas outside the cabin
- ② Antennas inside the cabin
- 3 Antenna outside the luggage compartment





FarmaSOS

■ Effective range (areas within which the electronic key is detected)

When locking or unlocking the doors

The system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of either of the outside front door handle. (Only the doors detecting the key can be operated.)





The system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of the back door handle.

(2.3 ft.) of the back door handle.

When starting the engine or changing engine switch modes

The system can be operated when the electronic key is inside the vehicle. Vehicles for U.K.: The system may not operate when the back door or the glass hatch are open, even if the electronic key is in the rear of the vehicle.

■ Alarms and warning indicators

Vehicles with the multi-information display type A: A combination of exterior and interior alarms as well as warning lights are used to prevent theft of the vehicle and unforeseeable accidents resulting from erroneous operation. Take appropriate measures for the warning light that comes on. (→P. 632)

Vehicles with the multi-information display type C: A combination of exterior and interior alarms as well as warning messages shown on the multi-information display are used to prevent theft of the vehicle and accidents resulting from erroneous operation. Take appropriate measures in response to any warning message on the multi-information display. (→P. 637)

The following table describes circumstances and correction procedures when only alarms are sounded.

Alarm	Situation	Correction procedure	
Interior alarm pings once and exterior alarm sounds once for 5 seconds*1	An attempt was made to lock the doors using the smart entry & start system while the electronic key was still inside the vehicle.	Retrieve the electronic key from the vehicle and lock the doors again.	
Exterior alarm sounds once for 5	An attempt was made to lock the vehicle while a door and/ or the glass hatch was open.	Close all of the doors and/or the glass hatch, and lock the doors again.	
seconds	An attempt was made to close the glass hatch while the electronic key was still inside the vehicle.	Open the glass hatch again and retrieve the electronic key from the vehicle.	
Interior alarm continuously	The engine switch was turned to ACCESSORY mode while the driver's door was open (or the driver's door was opened while the engine switch was in ACCESSORY mode).	Turn the engine switch off and close the driver's door.	
Interior alarm continuously*1, 2	The driver's door was opened while any shift position other than P was selected without turning off the engine switch.	Shift the shift lever to P.	
Interior alarm pings once*1	The electronic key has a low battery.	Replace the electronic key battery.	

^{*1:} Vehicles with the multi-information display type A

^{*2:} Vehicles with an automatic transmission

■ Battery-saving function

The battery-saving function will be activated in order to prevent the electronic key battery and the vehicle battery from being discharged while the vehicle is not in operation for a long time.

- In the following situations, the smart entry & start system may take some time to unlock the doors.
 - The electronic key has been left in an area of approximately 2 m (6 ft.) of the outside of the vehicle for 10 minutes or longer.
 - The smart entry & start system has not been used for 5 days or longer.
- If the smart entry & start system has not been used for 14 days or longer, the doors cannot be unlocked at any doors except the driver's door. In this case, take hold of the driver's door handle, or use the wireless remote control or the mechanical key, to unlock the doors.

■ Conditions affecting operation

The smart entry & start system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart entry & start system, wireless remote control and engine immobilizer system from operating properly.

(Ways of coping: \rightarrow P. 691)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication device
- When the electronic key is in contact with, or is covered by the following metallic objects
 - · Cards to which aluminum foil is attached
 - Cigarette boxes that have aluminum foil inside
 - Metallic wallets or bags
 - Coins
 - · Hand warmers made of metal
 - · Media such as CDs and DVDs
- When multiple electronic keys are in the vicinity
- When other wireless keys (that emit radio waves) are being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
 - · Another vehicle's electronic key or a wireless key that emits radio waves
 - Personal computers or personal digital assistants (PDAs)
 - · Digital audio players
 - Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window

■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
 - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
 - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the glass hatch is opened.
 - The electronic key is on the instrument panel, luggage cover or floor, or in the door pockets or glove box when the engine is started or engine switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the doors will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- Even if the electronic key is not inside the vehicle, it may be possible to start the engine if the electronic key is near the window.
- The doors may lock or unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash, when the electronic key is within the effective range. (The doors will automatically be locked after approximately 30 seconds if the doors or the glass hatch are not opened and closed.)
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- Touching the door lock sensor while wearing gloves may prevent lock operation
- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. Place the electronic key in a location 2 m (6 ft.) or more away from the vehicle. (Take care to ensure that the key is not stolen.)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.

- The lock sensor may not work properly if it comes into contact with ice, snow, mud, etc. Clean the lock sensor and attempt to operate it again, or use the lock sensor on the lower part of the door handle.
- Fingernails may scrape against the door during operation of the door handle. Be careful not to injure fingernails or damage the surface of the door.
- A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.
- Unlocking the vehicle may take more time if another electronic key is within the effective range.

■When the vehicle is not driven for extended periods

- To prevent theft of the vehicle, do not leave the electronic key within 2 m (6 ft.) of the vehicle.
- The smart entry & start system can be deactivated in advance. (→P. 741)

■ To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention function may not operate.)

■ If the smart entry & start system does not operate properly

- Locking and unlocking the doors: Use the mechanical key. $(\rightarrow P. 691)$
- Starting the engine: →P. 692

■ Electronic key battery depletion

- The standard battery life is 1 to 2 years.
- If the battery becomes low, an alarm will sound in the cabin when the engine stops. (→P. 160, 651)
- As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the electronic key battery may be depleted. Replace the battery when necessary. (→P. 588)
 - The smart entry & start system or the wireless remote control does not operate.
 - · The detection area becomes smaller.
 - The LED indicator on the key surface does not turn on.
- To avoid serious deterioration, do not leave the electronic key within 1 m (3 ft.) of the following electrical appliances that produce a magnetic field:
 - T\/s
 - · Personal computers
 - · Cellular phones, cordless phones and battery chargers
 - Recharging cellular phones or cordless phones
 - Table lamps
 - Induction cookers

■ Customization

Settings (e.g. smart entry & start system) can be changed. (Customizable features →P. 741)

If the smart entry & start system has been deactivated in a customized setting

- Locking and unlocking the doors:
 Use the wireless remote control or mechanical key. (→P. 137, 691)
- Starting the engine and changing engine switch modes: →P. 692
- Stopping the engine: →P. 251

■ Certification for the smart entry & start system

TOYOTA

TOYOTA MOTOR CORPORATION

1, TOYOTA-CHO, TOYOTA, AICHI, 471-8571, JAPAN TEL:+81-565-28-2121

R&	ITE Declara	tion of Conformity	
We,			
Manufacturer's Name: Manufacturer's Address:	TOYOTA MOTOR	CORPORATION Toyota, Aichi, 471-8572, Japan	
hereby declare under our sole responsibility that the product: Product Name: LF Oscillator Product Model: TMLF8-15 to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents: -Health & safety requirements: EN 60950-1 -EMC requirements EN 301 489-01 & EN 301 489-03			
-Effective uses of radi		EN 300 330-2	
* CE mark	nas	CE.com	
* Member states intended for use		EU and EFTA	
Date:	February 25	, 2013	
Signature:		Tetreyn Traturo Tetsuya Matsuo	
	uu		

Hereby, TOYOTA MOTOR CORPORATION, declares that this TMLF8-15 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

TOYOTA MOTOR CORPORATION vakuuttaa täten että TMLF8-15 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart TOYOTA MOTOR CORPORATION dat het toestel TMLF8-15 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente TOYOTA MOTOR CORPORATION déclare que l'appareil TMLF8-15 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar TOYOTA MOTOR CORPORATION att denna TMLF8-15 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede TOYOTA MOTOR CORPORATION erklærer herved, at følgende udstyr TMLF8-15 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt TOYOTA MOTOR CORPORATION, dass sich das Gerät TMLF8-15 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ ΤΟΥΟΤΑ MOTOR CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ ΤΜLF8-15 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente TOYOTA MOTOR CORPORATION dichiara che questo TMLF8-15 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente TOYOTA MOTOR CORPORATION declara que el TMLF8-15 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

TOYOTA MOTOR CORPORATION declara que este TMLF8-15 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, TOYOTA MOTOR CORPORATION, jiddikjara li dan TMLF8-15 jikkonforma mal-ħtigijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab TOYOTA MOTOR CORPORATION seadme TMLF8-15 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, TOYOTA MOTOR CORPORATION nyilatkozom, hogy a TMLF8-15 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

TOYOTA MOTOR CORPORATION týmto vyhlasuje, že TMLF8-15 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

TOYOTA MOTOR CORPORATION tímto prohlašuje, že tento TMLF8-15 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

TOYOTA MOTOR CORPORATION izjavlja, da je ta TMLF8-15 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo TOYOTA MOTOR CORPORATION deklaruoja, kad šis TMLF8-15 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo TOYOTA MOTOR CORPORATION deklarē, ka TMLF8-15 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym TOYOTA MOTOR CORPORATION oświadcza, że TMLF8-15 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir TOYOTA MOTOR CORPORATION yfir því að TMLF8-15 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

TOYOTA MOTOR CORPORATION erklærer herved at utstyret TMLF8-15 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, TOYOTA MOTOR CORPORATION, декларира, че TMLF8-15 е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/ЕС.

Prin prezenta, TOYOTA MOTOR CORPORATION, declară că aparatul TMLF8-15 este in conformitate cu cerințele esențiale şi cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, TOYOTA MOTOR CORPORATION, izjavljuje da ovaj TMLF8-15 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, TOYOTA MOTOR CORPORATION, deklaroj qe ky TMLF8-15 eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tiera perkatese te Direktives 1999/5/EC.

Ovim TOYOTA MOTOR CORPORATION, izjavljuje da je TMLF8-15 u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, TOYOTA MOTOR CORPORATION, deklariše da je TMLF8-15 u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

Hereby, Tokai Rika Co., Ltd., declares that this B74EA is in compliance with the essential requirements and other relevant provisions of Directives 1999/5/EC.

Tokai Rika Co., Ltd. vakuuttaa täten että B74EA tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart Tokai Rika Co., Ltd. dat het toestel B74EA in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente Tokai Rika Co., Ltd. déclare que l'appareil B74EA est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar Tokai Rika Co., Ltd. att denna B74EA står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede Tokai Rika Co., Ltd. erklærer herved, at følgende udstyr B74EA overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Tokai Rika Co., Ltd., dass sich das Gerät B74EA in Übereinstimmung mit den grundlegenden Änforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Tokai Rika Co., Ltd. ΔΗΛΩΝΕΙ ΟΤΙ Β74ΕΑ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΉΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΈΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente Tokai Rika Co., Ltd. dichiara che questo B74EA è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente Tokai Rika Co., Ltd. declara que el B74EA cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Tokai Rika Co., Ltd. declara que este B74EA está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, Tokai Rika Co., Ltd., jiddikjara li dan B74EA jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab Tokai Rika Co., Ltd. seadme B74EA vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, Tokai Rika Ço., Ltd. nyilatkozom, hogy a B74EA megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Tokai Rika Co., Ltd. týmto vyhlasuje, že B74EA spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Tokai Rika Co., Ltd. tímto prohlašuje, že tento B74EA je ve shodě se základními požadavky a dalšĺmi příslušnými ustanoveními směrnice 1999/5/ES.

Tokai Rika Co., Ltd. izjavlja, da je ta B74EA v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo Tokai Rika Co., Ltd. deklaruoja, kad šis B74EA atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo Tokai Rika Ço., Ltd. deklarē, ka B74EA atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym Tokai Rika Co., Ltd. oświadcza, że B74EA jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir Tokai Rika Co., Ltd. yfir því að B74EA er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Tokai Rika Co., Ltd. erklærer herved at utstyret B74EA er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, Tokai Rika Co., Ltd., декларира, че В74EA е в съответствие със съществените изисквания й другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, Tokai Rika Co., Ltd., declară că aparatul B74EA este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B74EA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, Tokai Rika Co., Ltd., deklaroj qe ky B74EA eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tjera perkatese te Direktives 1999/5/EC.

Ovim Tokai Rika Co., Ltd., izjavljuje da je B74EA u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, Tokai Rika Co., Ltd., deklariše da je B74EA u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

İşbu belge ile Tokai Rika Co., Ltd., bu B74EA ürününün 1999/5/EC Yönetmeliği'nin temel gerekliliklerine ve diğer ilgili hükümlerine uygun olduğunu beyan eder.

The DECLARATION of CONFORMITY (DoC) is available at the following تلفن شبانه روزی: 🗚 ٠ '

address: http://www.tokai-rika.co.jp/pc



Hereby, Tokai Rika Co., Ltd., declares that this B72UA is in compliance with the essential requirements and other relevant provisions of Directives 1999/5/EC.

Tokai Rika Co., Ltd. vakuuttaa täten että B72UA tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart Tokai Rika Co., Ltd. dat het toestel B72UA in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente Tokai Rika Co., Ltd. déclare que l'appareil B72UA est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar Tokai Rika Co., Ltd. att denna B72UA står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede Tokai Rika Co., Ltd. erklærer herved, at følgende udstyr B72UA overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Tokai Rika Co., Ltd., dass sich das Gerät B72UA in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Tokai Rika Co., Ltd. ΔΗΛΩΝΕΙ ΟΤΙ Β72UA ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente Tokai Rika Co., Ltd. dichiara che questo B72UA è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente Tokai Rika Co., Ltd. declara que el B72UA cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Tokai Rika Co., Ltd. declara que este B72UA está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, Tokai Rika Co., Ltd., jiddikjara li dan B72UA jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab Tokai Rika Co., Ltd. seadme B72UA vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, Tokai Rika Co., Ltd. nyilatkozom, hogy a B72UA megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Tokai Rika Co., Ltd. týmto vyhlasuje, že B72UA spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Tokai Rika Co., Ltd. tímto prohlašuje, že tento B72UA je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Tokai Rika Co., Ltd. izjavlja, da je ta B72UA v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo Tokai Rika Co., Ltd. deklaruoja, kad šis B72UA atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo Tokai Rika Co., Ltd. deklarē, ka B72UA atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym Tokai Rika Co., Ltd. oświadcza, że B72UA jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir Tokai Rika Co., Ltd. yfir því að B72UA er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Tokai Rika Co., Ltd. erklærer herved at utstyret B72UA er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, Tokai Rika Co., Ltd., декларира, че B72UA е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, Tokai Rika Co., Ltd., declară că aparatul B72UA este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B72UA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, Tokai Rika Co., Ltd., deklaroj qe ky B72UA eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tjera perkatese te Direktives 1999/5/EC.

Ovim Tokai Rika Co., Ltd., izjavljuje da je B72UA u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, Tokai Rika Co., Ltd., deklariše da je B72UA u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

İşbu belge ile Tokai Rika Co., Ltd., bu B72UA ürününün 1999/5/EC Yönetmeliği'nin temel gerekliliklerine ve diğer ilgili hükümlerine uygun olduğunu beyan eder.

The DECLARATION of CONFORMITY (DoC) is available at the following address:

http://www.tokai-rika.co.jp/pc



CAUTION

■ Caution regarding interference with electronic devices

- People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the smart entry & start system antennas. (→P. 159)
 - The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for details, such as the frequency of radio waves and timing of the emitted radio waves. Then, consult your doctor to see if you should disable the entry function.
- Users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio

Radio waves could have unexpected effects on the operation of such medical devices.


Ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for details on disabling the entry function.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱۰

Front seats


Adjustment procedure

Manual seat



- 1 Seat position adjustment lever 3 Vertical
- ② Seatback angle adjustment lever
- 3 Vertical height adjustment lever (driver's side only)
- 4 Lumbar support adjustment switch (driver's side only)


▶ Power seat



- ① Seat position adjustment switch ④ Vertical
- ② Seatback angle adjustment switch
- ③ Seat cushion (front) angle adjustment switch (driver's side only)
- Vertical height adjustment switch (driver's side only)
- (5) Lumbar support adjustment switch (driver's side only)

Active head restraints (if equipped)

When the occupant's lower back presses against the seatback during a rear-end collision, the head restraint moves slightly forward and upward to help reduce the risk of whiplash on the seat occupant.



Moving a front passenger's seat for second seat access (3-door models)

■ Getting in the vehicle

Pull the seatback angle adjustment lever and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position




■ Getting out of the vehicle

Depress the release pedal and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position

Make sure that no passenger is seated on the front passenger seat before depressing the release pedal.




■ After passengers have entered/exited the vehicle

Lift up the seatback and slide the seat backward until it locks.

■ Active head restraints

Even small forces applied to the seatback may cause the head restraint to move. Pushing up a locked head restraint forcibly may appear the head restraint inner structure. These do not indicate problems.



A CAUTION

■When adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.
 - Fingers or hands may become jammed in the seat mechanism.

■ Seat adjustment


- To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.
 - If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.
 - Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.
- After adjusting the seat, make sure that the seat is locked in position.
 (manual seat only)

Rear seats*

Adjustment procedure

► Second seats (3-door models) (if equipped)

Seatback angle adjustment lever



► Second seats (5-door models without third seats and vehicles with longitudinal type seats) (if equipped)

Seatback angle adjustment lever




- ► Second seats (5-door models with third seats) (if equipped)
- Seatback angle adjustment lever
- ② Seat position adjustment lever



*: If equipped

► Third seats (power seat) (if equipped)

Seatback angle adjustment switch




Moving a second seat for third seat access (5-door models with third seats)

■ Getting in the vehicle (right side only [left-hand drive vehicles] or left side only [right-hand drive vehicles])

Pull the seatback angle adjustment lever and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position




■ Getting out of the vehicle (right side only [left-hand drive vehicles] or left side only [right-hand drive vehicles])

Pull the release lever and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position

Make sure that no passenger is seated on the second seat before pulling the release lever.




■ After passengers have entered/exited the vehicle

Lift up the seatback and slide the seat backward until it locks.

Tumbling the second seats (3-door models)


■ Before tumbling the second seats

Lower the head restraints to the lowest position.



Use the seat belt hangers to prevent the belts from being tangled.


Make sure that the seat belts are removed from the hangers before using them.




تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

■ Tumbling the second seats

1 Pull the seatback angle lever and fold them down.




2 Pull the seat lock release lever on the back and swing the whole seat up and forward.



■ Returning the second seats

Push the knob to unlock the seat, swing the whole seat down and swing the seatback up.




FarmaS

Folding down the second seatbacks (5-door models without third seats and vehicles with longitudinal type seats)


■ Before folding down the second seatbacks

Stow the center seat belt buckle with the hook-and-loop fastener and lower the head restraints to the lowest position.




■ Folding down second seatbacks

1 Swing the bottom cushion up by pulling the lock release strap.



2 Push the seatback lock release button and fold them down.


To return the second seatbacks to their original positions, lift them up until they lock.



Folding down the second seatbacks (5-door models with third seats)

■ Before folding down the second seatbacks

Lower the head restraints to the lowest position.



■ Folding down second seatbacks

Pull the seatback lock release lever and fold them down.

To return the second seatbacks to their original positions, lift them up until they lock.






■ Folding down second center seatback only (5-door models)

Pull the center seatback lock release lever behind the seatback and fold it down.


To return the center seatback to its original position, lift it up until it locks.



■ If you cannot raise the seatback

Release the seat belt lock by:

- ① Pushing on the lower front edge of the seatback to slacken the seat belt.
- 2 Let the seat belt retract a little.




تلفن شبانه روزی: ۱۹۲۰ میلا - ۲۱ - ۲۲ میلانه


Folding the third seats (longitudinal type seat)

■ Folding the third seats

1 Swing the seat cushion fully up.



2 Take the holding strap of its pocket on the back of the seatback and secure the seat hooking the strap onto the hook in the back of the seat cushion.




■ Returning the third seats
Reverse the steps above.



Folding down the third seats (manual seat)


■ Before folding down the third seats

Lower the head restraints to the lowest position.



Use the seat belt hangers to prevent the belts from being tangled.

Make sure that the seat belts are removed from the hangers before using them.




■ Folding down the third seats

► From back door side


Pull the seat cushion/seatback lock release lever and fold the seatback down.

The seat cushion is stowed automatically.




- ▶ From rear door side
- 1 Pull the seat cushion lock release lever.

The seat cushion is stowed automatically.




2 Pull the seatback lock release lever and fold them down.





■ Returning the third seats

1 From rear door side, unlock the seatbacks by pulling the lock release lever, and lift them up until they lock.




raillao

2 Pull the grip and carry the seat cushions out.



Folding down the third seats (power seat)

▶ Left-hand drive vehicles



▶ Right-hand drive vehicles




- 1 Right seat return switch
- 2 Right seat fold switch
- 3 Left seat return switch
- 4 Left seat fold switch

The switches can be operated from both the rear door side and the back door side.

■ Before folding down the third seats

Use the seat belt hangers to prevent the belts from being tangled.

Make sure that the seat belts are removed from the hangers before using them.



■ Folding down the third seats


1 Press and hold



Two

beeps sound and the seatback will rise.

When operating is completed, two beeps sound again.




2 Press and hold



again.

Two beeps sound, the head restraints will fold forward, and the seat will be stowed.

When operating is completed, two beeps sound again.




■ Returning the third seats

1 Press and hold



Two beeps sound and seatback and seat cushion begin to move. When operating is completed, two beeps sound again.

2 Lift the head restraints up until they lock.





■ The third power seats can be operated when

- The engine switch is off.
- The shift lever is in P position (vehicles with an automatic transmission) or the parking brake is applied (vehicles with a manual transmission) with the engine switch in IGNITION ON mode.

■ During third power seat stowing operation

Do not remove your hand from the switch until the operation stops automatically. If you remove your hand from the switch, the operation will stop and the buzzer will sound continuously. The buzzer will stop when the switch is pressed again.

■ Enlarging the luggage compartment (vehicles with third power seats)

The third seat can be used for sitting when it is in the position shown in step 2 of the folding down the third seats. (\rightarrow P. 188)

This can be convenient for enlarging the luggage compartment, for instance when the luggage is against the back of the seatback.

If the warning buzzer sounds continuously (vehicles with third power seats)

If there is an abnormality in the system, the warning buzzer will sound continuously while the engine switch is in IGNITION ON mode. In this case, perform the following operations:

1 Press and hold to return the seat.

2 Press and hold to stow the seat.

For each step, wait until the seat movement stops automatically and the two beeps sound twice before removing your hand from the switch.

If the warning buzzer does not stop even after performing the above procedure correctly, perform the following operations:

- 3 Press and hold 4 on the rear door side.
- 4 While holding 4, press forward on 5 times within 10 seconds and keep holding 4 until 3 beeps sound. The beep will then sound continuously again.
- 5 Repeat step 1 and 2.

CAUTION

■When folding the seatbacks down

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not fold the seatbacks down while driving.
- Stop the vehicle on level ground, set the parking brake and shift the shift lever to P (automatic transmission) or N (manual transmission).
- Do not allow anyone to sit on a folded seatback or in the luggage compartment while driving.
- Do not allow children to enter the luggage compartment.

■ Seat adjustment

Observe the following precautions. Failure to do so may result in death or serious injury.

- To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.
 - If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.
 - Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.
- Be careful not to get hands or feet pinched between the rear console box and the second seat when folding down the seatback.

CAUTION

■When stowing the third seats

Observe the following precautions. Failure to do so may result in death or serious injury.

- Check that there is no luggage and that there are no other people around the seat before stowing operation.
- Conduct the procedure slowly and carefully (vehicles with manual third
- Do not insert hands or feet into the moving parts of the seat.
- Do not allow children to operate the seat.
- Do not use the seat if only the seat cushion has been stowed (vehicles with manual third seats).

■ After returning the seatbacks to the upright position

Observe the following precautions. Failure to do so may result in death or serious injury.

- Make sure the seatback is securely locked by pushing it forward and rearward on the top. (except for third power seats)
- Check that the seat belts are not twisted or caught in the seatback.



■ When returning the third seat (vehicles with a luggage cover)

If the luggage cover is installed in the luggage compartment, make sure you remove it before returning the third seat (→P. 508). The luggage cover may be damaged by the seat.

Driving position memory*

This feature automatically adjusts the driver's seats and steering wheel to suit your preferences.

Driving position memory


Your preferred driving position (the position of the driver's seat and steering wheel) can be memorized and recalled with the touch of a button.

Two different driving positions can be entered into memory.

■ Recording procedure

- 1 Vehicles with an automatic transmission: Check that the shift lever is in P. Vehicles with a manual transmission: Check that the parking brake is set.
- 2 Vehicles without a smart entry & start system: Turn the engine switch to the "ON" position. Vehicles with a smart entry & start system: Turn the engine switch to IGNITION ON mode.
- 3 Adjust the driver's seat and steering wheel to the desired positions.
- While pressing the "SET" button, or within 3 seconds after the "SET" button is pressed, press button "1" or "2" until the buzzer sounds.

If the selected button has already been preset, the previously recorded position will be overwritten.



*: If equipped

■ Recall procedure

1 Vehicles with an automatic transmission:


Check that the shift lever is in P.

Vehicles with a manual transmission:

Check that the parking brake is set.

Vehicles without a smart entry & start system: Turn the engine switch to the "ON" position. Vehicles with a smart entry & start system: Turn the engine switch to IGNITION ON mode.

3 Press button "1" or "2" for the driving position you want to recall until the buzzer sounds.



■ To stop the position recall operation part-way through

Perform any of the following:

- The Press the "SET" button. المناه روزي: ۵۰ + ۱۸ المناه روزي:
- Press button "1" or "2".
- Operate any of the seat adjustment switches (only cancels seat position recall).
- Operate the tilt and telescopic steering control switch (only cancels steering wheel position recall).

\blacksquare Seat positions that can be memorized (\rightarrow P. 175)

The adjusted positions other than the position adjusted by lumbar support switch can be recorded.

Operating the driving position memory after turning the engine switch off

Recorded seat positions can be activated up to 180 seconds after the driver's door is opened and another 60 seconds after it is closed again.

■ In order to correctly use the driving position memory function

If a seat position is already in the furthest possible position and the seat is operated in the same direction, the recorded position may be slightly different when it is recalled.

Memory recall function (vehicles with a smart entry & start system)

Each electronic key can be registered to recall your preferred driving position.


■ Registering procedure

Record your driving position to button "1" or "2" before performing the following:

Carry only the key to which you want to register, and then close the driver's door. If 2 or more keys are in the vehicle, the driving position cannot be recorded properly.

- 1 Vehicles with an automatic transmission: Check that the shift lever is in P. Vehicles with a manual transmission: Check that the parking brake is set.
- 2 Turn the engine switch to IGNITION ON mode.
- 3 Recall the driving position that you want to record.
- While pressing the recalled button, press and hold the driver's door lock switch (either lock or unlock) until the signal beeps.

If the button could not be registered, the buzzer sounds continuously for approximately 3 seconds.



■ Recall procedure

Carry the electronic key that has been registered to the driving position, and then unlock and open the driver's door using the smart entry & start system or wireless remote control.

The driving position will move to the recorded position.

If the driving position is in a position that has already been recorded, the seat and outside rear view mirrors will not move.

■ Cancelation procedure

Carry only the key you want to cancel and then close the driver's

If 2 or more keys are in the vehicle, the driving position cannot be canceled properly.

- 1 Turn the engine switch to IGNITION ON mode.
- 2 While pressing "SET" button, press and hold the driver's door lock switch (either lock or unlock) until the buzzer sounds twice.

■ Recalling the driving position using the memory recall function

- Different driving positions can be registered for each electronic key. Therefore, the driving position that is recalled may be different depending on the key being carried.
- If a door other than the driver's door is unlocked with the smart entry & start system, the driving position cannot be recalled. In this case, press the driving position button which has been set.

■ Customization

The unlock door settings of the memory recall function can be customized. (Customizable features: →P. 744)



A CAUTION

■ Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel.

Head restraints

Head restraints are provided for all seats.


Front, second and third manual seats (if equipped)

1 Up

Pull the head restraints up.

② Down


Push the head restraint down while pushing the lock release button.



Third power seats (if equipped)

To fold the head restraints, pull the lock release strap.


To return the head restraints, lift them up until they lock.



■ Removing the head restraints

▶ Front, second and third manual seats

Pull the head restraint up while pressing the lock release button.




▶ Third power seats

The head restraint cannot be removed.


■ Installing the head restraints (front, second and third manual seats)

Align the head restraint with the installation holes and push it down to the lock position.



■ Adjusting the height of the head restraints

Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.



■Using the second center, second outer (5-door models without third seats and vehicles with longitudinal type third seats) and third manual seat head restraints

Always raise the head restraint one level from the stowed position when using.



■ Using the third power seats (if equipped)

Always lift the head restraints up until they lock when using.

A CAUTION

■ Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.




تلفن شبانه روزی: ۱۰۲۱–۸۸۸۶۲ ۲۸

Steering wheel


Adjustment procedure

- ▶ Manual adjustment type
- 1 Hold the steering wheel and pull the lever down.




2 Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.






- ① Up
- 2 Down FarmaS
- 3 Away from the driver
- 4 Toward the driver



Auto tilt away (power adjustment type)


When the engine switch is turned off, the steering wheel returns to its stowed position by moving up and away to enable easier driver entry and exit.

Turning the engine switch to ACCESSORY or IGNITION ON mode will return the steering wheel to the original position.



Horn

To sound the horn, press on or close to the mark.



- The power adjustment type steering wheel can be adjusted when The engine switch is in ACCESSORY or IGNITION ON mode.*
 - *: If the driver's seat belt is fastened, the steering wheel can be adjusted regardless of engine switch mode.
- Automatic adjustment of the steering position

 A desired steering position can be entered to memory and recalled automatically by the driving position memory system. (→P. 193)
- After adjusting the steering wheel (manual adjustment type)

 Make sure that the steering wheel is securely locked.

 The horn may not sound if the steering wheel is not securely locked.

A CAUTION

■ Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

■ After adjusting the steering wheel (manual adjustment type)

Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident, and resulting in death or serious injury.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱۰

Inside rear view mirror


The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

Adjusting the height of rear view mirror

The height of the rear view mirror can be adjusted to suit your driving posture.


Adjust the height of the rear view mirror by moving it up and down.





Anti-glare function

- ▶ Manual anti-glare inside rear view mirror
 Reflected light from the headlights of vehicles behind can be reduced by operating the lever.
- 1 Normal position
- 2 Anti-glare position



▶ Auto anti-glare inside rear view mirror

Responding to the level of brightness of the headlights of vehicles behind, the reflected light is automatically reduced.


Changing automatic anti-glare function mode

On/off

When the automatic anti-glare function is in ON mode, the indicator illuminates.

The function will set to ON mode each time the engine switch is turned to IGNITION ON mode.


Pressing the button turns the function to OFF mode. (The indicator also turns off.)



■ To prevent sensor error (vehicles with auto anti-glare inside rear view mirror)

To ensure that the sensors operate properly, do not touch or cover them.





CAUTION


Do not adjust the position of the mirror while driving.

Doing so may lead to mishandling of the vehicle and an accident, resulting in death or serious injury.


Outside rear view mirrors

Adjustment procedure

- 1 To select a mirror to adjust, press the switch.
 - 1 Left
 - ② Right




- 2 To adjust the mirror, press the switch.
 - ① Up
 - 2 Right
 - ③ Down
 - 4 Left



Folding the mirrors

▶ Manual type

Push the mirror back in the direction of the vehicle's rear.



▶ Power type

Press the switch to fold the mirrors.

Press it again to extend them to the original position.



■ Mirror angle can be adjusted when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ACC" or "ON" position.

▶ Vehicles with a smart entry & start system

The engine switch is in ACCESSORY or IGNITION ON mode.

■When the mirrors are fogged up (vehicles with outside rear view mirror defoggers)

Turn on the mirror defoggers to defog the mirrors. (→P. 467, 475)

A CAUTION

■Important points while driving

Observe the following precautions while driving.

Failing to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

■When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

■When the mirror defoggers are operating (vehicles with outside rear view mirror defoggers)

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.




■ If ice should jam the mirror

Power windows

Opening and closing procedures

The power windows can be opened and closed using the switches. Operating the switch moves the windows as follows:

- 1 Closing
- ② One-touch closing*
- 3 Opening
- 4 One-touch opening*
- *: To stop the window partway, operate the switch in the opposite direction.



Window lock switch

Press the switch down to lock the passenger window switches.

Use this switch to prevent children from accidentally opening or closing a passenger window.



■The power windows can be operated when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

The engine switch is in IGNITION ON mode.

Operating the power windows after turning the engine off

▶ Vehicles without a smart entry & start system

The power windows can be operated for approximately 45 seconds even after the engine switch is turned to the "ACC" or "LOCK" position. They cannot, however, be operated once either front door is opened.

▶ Vehicles with a smart entry & start system

The power windows can be operated for approximately 45 seconds even after the engine switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object becomes jammed between the window and the window frame while the window is closing, window movement is stopped and the window is opened slightly.

■ Catch protection function

If an object becomes caught between the door and window while the window is opening, window movement is stopped.



■ When the power window cannot be opened or closed

When the jam protection function or catch protection function operates unusually or the power window can not be fully opened and closed, perform the following operations with the power window switch of that door.

- Stop the vehicle. With the engine switch in the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system), within 4 seconds of the jam protection function or catch protection function activating, continuously operate the power window switch in the one-touch closing direction or one-touch opening direction so that the door window can be opened and closed.
- If the window cannot be opened and closed even when performing the above operations, perform the following procedure for function initialization.
- 1 Turn the engine switch to the "ON" position (vehicles without a smart entry & start system) or the engine switch to IGNITION ON mode (vehicles with a smart entry & start system).
- 2 Pull and hold the power window switch in the one-touch closing direction and completely close the window.
- 3 Release the power window switch for a moment, resume pulling the switch in the one-touch closing direction, and hold it there for approximately 6 seconds or more.
- 4 Press and hold the power window switch in the one-touch opening direction. After the door window is completely opened, continue holding the switch for an additional 1 second or more.
- Release the power window switch for a moment, resume pushing the switch in the one-touch opening direction, and hold it there for approximately 4 seconds or more.
- Pull and hold the power window switch in the one-touch closing direction again. After the window is completely closed, continue holding the switch for a further 1 second or more.

If you release the switch while the window is moving, start again from the beginning.

If the window reverses and cannot be fully closed or opened, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ Door lock linked window operation

The power windows can be opened and closed using the wireless remote control or key if customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. (\rightarrow P. 137, 138)

■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features →P. 741)

CAUTION

Observe the following precautions.

Failing to do so may result in death or serious injury.

Closing the windows

- The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch. (\rightarrow P. 208)
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- When using the wireless remote control or mechanical key and operating the power windows, operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window. Also, do not let a child operate window by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the power window.
- When exiting the vehicle, turn the engine switch to the "LOCK" position (vehicles without a smart entry & start system) or off (vehicles with a smart entry & start system), carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident. تلفن شبانه روزي:

Jam protection function

- Never use any part of your body to intentionally activate the up jam protection function.
- The jam protection function may not work if something gets jammed just before the window is fully closed. Be careful not to get any part of your body jammed in the window.

Catch protection function

- Never use any part of your body or clothing to intentionally activate the catch protection function.
- The catch protection function may not work if something gets caught just before the window is fully opened. Be careful not to get any part of your body or clothing caught in the window.

Moon roof

Use the overhead switches to open and close the moon roof and tilt it up and down.


Opening and closing

① Opens the moon roof*

The moon roof stops slightly before the fully open position to reduce wind noise.


Press the switch again to fully open the moon roof.

- 2 Closes the moon roof*
 - *: Lightly press either end of the moon roof switch to stop the moon roof partway.



Tilting up and down

- 1) Tilts the moon roof up*
- 2 Tilts the moon roof down*
- *: Lightly press either end of the moon roof switch to stop the moon roof partway.



FarmaS

■ The moon roof can be operated when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

The engine switch is in IGNITION ON mode.

■ Operating the moon roof after turning the engine off

▶ Vehicles without a smart entry & start system

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to the "ACC" or "LOCK" position. It cannot, however, be operated once either front door is opened.

▶ Vehicles with a smart entry & start system

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

■Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

■ Door lock linked moon roof operation

The moon roof can be opened and closed using the wireless remote control or key if customized at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. (→P. 137, 138)

■ Moon roof open reminder function

An alarm will sound when the driver's door is opened with the moon roof not fully closed and the engine switch off.

■When the moon roof does not close normally

Perform the following procedure:


- If the moon roof closes but then re-opens slightly
- 1 Stop the vehicle.

The moon roof will close, re-open and pause for approximately 10 seconds.*2 Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.

- 3 Check to make sure that the moon roof is completely closed and then release the switch.
- If the moon roof tilts down but then tilts back up
- 1 Stop the vehicle.
- 2 Press and hold "\" on the () *1 until the moon roof moves into the tilt up position and stops.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

3 Release "∧" on the





again.*1

The moon roof will pause for approximately 10 seconds in the tilt up position.*2 Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.

- 4 Check to make sure that the moon roof is completely closed and then release the switch.
- *1: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
- *2: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold "\" on

the \bigcirc or "\" on the \bigcirc and the moon roof will tilt up and pause for

approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features \rightarrow P. 741)

CAUTION

Observe the following precautions.

Failing to do so may cause death or serious injury.

Opening the moon roof

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

Closing the moon roof

- The driver is responsible for moon roof opening and closing operations. In order to prevent accidental operation, especially by a child, do not let a child operate the moon roof. It is possible for children and other passengers to have body parts caught in the moon roof.
- Check to make sure that all passengers do not have any part of their bodies in a position where it could be caught when the moon roof is being
- When using the wireless remote control or mechanical key and operating the moon roof, operate the moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the moon roof. Also, do not let a child operate moon roof by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the moon roof.
- When exiting the vehicle, turn the engine switch to the "LOCK" position (vehicles without a smart entry & start system) or off (vehicles with a smart entry & start system), carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.

Driving

4

4-1.	Before driving	4-4.	Refueling
	Driving the vehicle218		Opening the fuel
	Cargo and luggage230		tank cap298
	Trailer towing (with towing hitch)233	4-5.	Using the driving support systems
4-2.	Driving procedures		Cruise control302
	Engine (ignition) switch (vehicles without a smart	17	Dynamic radar cruise control306
	entry & start system)246		Toyota parking
	Engine (ignition) switch		assist-sensor324
	(vehicles with a smart		Rear view monitor
	entry & start system)249	1.8	system334
	Automatic transmission257	・ハロ	Toyota parking assist
	Manual transmission264		monitor345
	Turn signal lever269		Driving assist systems372
	Parking brake270		BSM
	Diesel Particulate Filter system	0	(Blind Spot Monitor)378 • The Blind Spot Monitor
	(diesel engine only)271		function385
4-3.	Operating the lights and wipers		The Rear Crossing Traffic Alert function387 POO (Pro County)
	Headlight switch274		PCS (Pre-Crash Safety system)390
	Fog light switch287	4.0	
	Windshield wipers and washer289	4-6.	Driving tips Winter driving tips400
	Rear window wiper and washer295		
	Headlight cleaner switch 206		

Driving the vehicle

The following procedures should be observed to ensure safe driving:

Starting the engine

→P. 246, 249

Driving

- Automatic transmission
- 1 With the brake pedal depressed, shift the shift lever to D. $(\rightarrow P. 257)$
- 2 Release the parking brake. (→P. 270)
- 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.
 - ▶ Manual transmission
- While depressing the clutch pedal, shift the shift lever to 1. (→P. 264)
- 2 Release the parking brake. (→P. 270)
- 3 Gradually release the clutch pedal. At the same time, gently depress the accelerator pedal to accelerate the vehicle.

Stopping

- ► Automatic transmission
- 1 With the shift lever in D, depress the brake pedal.
- 2 If necessary, set the parking brake.
 - If the vehicle is to be stopped for an extended period of time, shift the shift lever to P or N. $(\rightarrow P. 257)$
- ▶ Manual transmission
- 1 While depressing the clutch pedal, depress the brake pedal.
- 2 If necessary, set the parking brake.
 - If the vehicle is to be stopped for an extended period of time, shift the shift lever to N. $(\rightarrow P. 264)$

Parking the vehicle

- ▶ Automatic transmission
- 1 With the shift lever in D, depress the brake pedal.
- 2 Set the parking brake (\rightarrow P. 270), and shift the shift lever to P (\rightarrow P. 257).
- 3 Vehicles without a smart entry & start system:

 Turn the engine switch to the "LOCK" position to stop the engine.

 Vehicles with a smart entry & start system:

 Press the engine switch to stop the engine.
- 4 Lock the door, making sure that you have the key on your person. If parking on a hill, block the wheels as needed.
- ▶ Manual transmission
- 1 While depressing the clutch pedal, depress the brake pedal.
- 2 Shift the shift lever to N. (→P. 264)
- 3 Set the parking brake. (→P. 270)

 If parking on a hill, shift the shift lever to 1 or R as needed.
- Vehicles without a smart entry & start system:

 Turn the engine switch to the "LOCK" position to stop the engine.

 Vehicles with a smart entry & start system:

 Press the engine switch to stop the engine.
- Lock the door, making sure that you have the key on your person. If parking on a hill, block the wheels as needed.

Starting off on a steep uphill

- Automatic transmission
- 1 Make sure that the parking brake is set and shift the shift lever to D.
- 2 Gently depress the accelerator pedal.
- 3 Release the parking brake.
 - ▶ Manual transmission
- 1 With the parking brake firmly set and the clutch pedal fully depressed, shift the shift lever to 1.
- 2 Lightly depress the accelerator pedal at the same time as gradually releasing the clutch pedal.
- Release the parking brake.

When starting off on a uphill (vehicles with hill-start assist control system)

The hill-start assist control is available. (→Refer to the "Off-road Driving Owner's Manual")

■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

■ Engine speed while driving (automatic transmission)

In the following conditions, the engine speed may become high while driving. This is due to automatic up-shifting control or down-shifting implementation to meet driving conditions. It does not indicate sudden acceleration.

- The vehicle is judged to be driving uphill or downhill
- When the accelerator pedal is released

■ Breaking in your new Toyota

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 300 km (200 miles): Avoid sudden stops.
- For the first 800 km (500 miles): Do not tow a trailer.
- For the first 1000 km (600 miles):
 - · Do not drive at extremely high speeds.
 - · Avoid sudden acceleration.
 - · Do not drive continuously in the low gears.
 - Do not drive at a constant speed for extended periods.
 - Do not drive slowly with the manual transmission in a high gear.

■ Drum-in-disc type parking brake system

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer perform the bedding-down operation.

■ Idling time before stopping the engine (diesel engine)

To prevent damage to the turbocharger, allow the engine to idle immediately after high-speed driving or driving up a hill.

+ Y \ Dr	Idling time	
Normal city driving	2 (6(5)-	Not necessary
High-speed	Constant speed of approx. 80 km/h (50 mph)	Approximately 20 seconds
driving Far	Constant speed of approx. 100 km/h (62 mph)	Approximately 1 minute
Steep hill driving or (62 mph) or more (ra	Approximately 2 minutes	

■ Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. $(\rightarrow P. 714)$

CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

■When starting the vehicle

On vehicles with an automatic transmission, always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
 - · Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident.
 - · When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
 - Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
 - · Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.

Observe the following precautions.

Failure to do so may result in death or serious injury.

■When driving the vehicle

- During normal driving, do not turn off the engine. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.
 - However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: →P. 615
- •Use engine braking (downshift) to maintain a safe speed when driving down a steep hill.
 - Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (→P. 258)
- Do not adjust the positions of the steering wheel, the seat, or the inside or outside rear view mirrors while driving. Doing so may result in a loss of vehicle control.
- Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle.

تلفن شبانه روزى: ۱۵۸۰۲۹۸۸۸–۲۱۰

CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

■When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle.
- Sudden acceleration, engine braking due to shifting, or changes in engine speed could cause the vehicle to skid.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected.

■When shifting the shift lever

- On vehicles with an automatic transmission, do not let the vehicle roll backwards while the shift lever is in a driving position, or roll forward while the shift lever is in R.
 - Doing so may cause the engine to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.
- On vehicles with an automatic transmission, do not shift the shift lever to P while the vehicle is moving.
 - Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to R while the vehicle is moving forward. Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to a driving position while the vehicle is moving backward.
 - Doing so can damage the transmission and may result in a loss of vehicle
- Moving the shift lever to N while the vehicle is moving will disengage the engine from the transmission.
 - Engine braking is not available when N is selected.
- On vehicles with an automatic transmission, be careful not to shift the shift lever with the accelerator pedal depressed. Shifting the shift lever to a gear other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ If you hear a squealing or scraping noise (brake pad wear indicators)

Have the brake pads checked and replaced by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible.

Rotor damage may result if the pads are not replaced when needed.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

■When the vehicle is stopped

- Do not race the engine.
 - If the vehicle is in any gear other than P (vehicles with an automatic transmission only) or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.
- On vehicles with automatic transmission, in order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.
- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.
- Avoid revving or racing the engine. Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ When the vehicle is parked

• Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.

Doing so may result in the following:

- · Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- · The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
- · Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such as the glove box or on the floor, it may be lit accidentally when luggage is loaded or the seat is adjusted, causing a fire.
- Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehi-
- Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
- Always apply the parking brake, shift the shift lever to P (vehicles with an automatic transmission only), stop the engine and lock the vehicle. Do not leave the vehicle unattended while the engine is running. If the vehicle is parked with the shift lever in P but the parking brake is not set, the vehicle may start to move, possibly leading to an accident.
- Do not touch the exhaust pipes while the engine is running or immediately after turning the engine off. Doing so may cause burns.

Observe the following precautions.

Failure to do so may result in death or serious injury.

■When taking a nap in the vehicle

Always turn the engine off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

When braking

- When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle.
- If the power brake assist function does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking. In this case, braking is still possible, but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately.
- Do not pump the brake pedal if the engine stalls.
 Each push on the brake pedal uses up the reserve for the power-assisted brakes.
- The brake system consists of 2 individual hydraulic systems; If one of the systems fails, the other will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase.

Have your brakes fixed immediately.

■ If the vehicle becomes stuck

Do not spin the wheels excessively when any of the tires is up in the air, or the vehicle is stuck in sand, mud, etc. This may damage the driveline components or propel the vehicle forward or backward, causing an accident.

⚠ NOTICE

■When driving the vehicle

- ► Automatic transmission
- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain the engine output.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.
- ▶ Manual transmission
- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain the engine output.
- Do not shift gears unless the clutch pedal is fully depressed. After shifting, do not release the clutch abruptly. Doing so may damage the clutch, transmission and gears.
- Observe the following to prevent the clutch from being damaged.
 - Do not rest your foot on the clutch pedal while driving.
 Doing so may cause clutch trouble.
 - Do not use any gear other than the 1st gear when starting off and moving forward.
 - Doing so may damage the clutch.
 - Do not use the clutch to hold the vehicle when stopping on an uphill grade.
 - Doing so may damage the clutch.
- Do not shift the shift lever to R when the vehicle is still moving. Doing so may damage the clutch, transmission and gears.

When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

Do not turn the steering wheel fully in either direction and hold it there for

■ When parking the vehicle (vehicles with an automatic transmission) Always set the parking brake, and shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if

Diesel engine only: Make sure to idle the engine immediately after highspeed driving or hill climbing. Stop the engine only after the turbocharger has cooled down.

Failure to do so may cause damage to the turbocharger.

If you get a flat tire while driving

Avoiding damage to vehicle parts

an extended period of time.

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehi-

It may be difficult to control your vehicle.

the accelerator pedal is accidentally depressed.

Doing so may damage the power steering pump.

- The vehicle will make abnormal sounds or vibrations.
- The vehicle will lean abnormally.

Information on what to do in case of a flat tire. $(\rightarrow P. 653)$

When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

Engine stalling

♠ NOTICE

- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer check the following:


- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, transmission, transfer, differentials, etc.
- Lubricant condition for the propeller shaft, bearings and suspension joints (where possible), and the function of all joints, bearings, etc.

Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load:

Roof luggage carrier (if equipped)

- Roof luggage carrier components
 - 1 Roof rail
- ② Cross rail





A CAUTION

■Things that must not be carried in the luggage compartment

The following things may cause a fire if loaded in the luggage compartment:

- Receptacles containing gasoline
- Aerosol cans



Storage precautions

Observe the following precautions.

Failure to do so may prevent the pedals from being depressed properly, may block the driver's vision, or may result in items hitting the driver or passengers, possibly causing an accident.

- Stow cargo and luggage in the luggage compartment whenever possible.
- Do not stack anything in the luggage compartment higher than the seatbacks.
- Do not place cargo or luggage in or on the following locations.
 - · At the feet of the driver
 - On the front passenger or rear seats (when stacking items)
 - On the luggage cover (if equipped)
 - On the instrument panel
 - · On the dashboard
- Secure all items in the occupant compartment.
- •When you fold down the rear seats, long items should not be placed directly behind the front seats.
- Never allow anyone to ride in the luggage compartment. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened. Otherwise, they are much more likely to suffer death or serious bodily injury, in the event of sudden braking, sudden swerving or an تلفن شبانه روزی**: ♦٨ ٠** ′ accident.

Load and distribution

- Do not overload your vehicle.
- Do not apply loads unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

CAUTION

■ Roof luggage carrier precautions (if equipped)

To use the roof rails as a roof luggage carrier, you must fit the roof rails with two or more genuine Toyota cross rails or their equivalent. Follow the manufacturer's instructions and precautions when installing the cross rails or their equivalent.

When you load cargo on the roof luggage carrier, observe the following:

- Place the cargo so that its weight is distributed evenly between the front and rear axles.
- If loading long or wide cargo, never exceed the vehicle overall length or width. (→P. 708)
- Before driving, make sure the cargo is securely fastened on the roof luggage carrier.
- Loading cargo on the roof luggage carrier will make the center of gravity of the vehicle higher. Avoid high speeds, sudden starts, sharp turns, sudden braking or abrupt maneuvers, otherwise it may result in loss of control or vehicle rollover due to failure to operate this vehicle correctly and result in death or serious injury.
- If driving for a long distance, on rough roads, or at high speeds, stop the vehicle now and then during the trip to make sure the cargo remains in its
- Do not exceed 80 kg (176 lb.) cargo weight on the roof luggage carrier.



♠ NOTICE

■ When loading cargo on the roof luggage carrier (if equipped) Be careful not to scratch the surface of the moon roof (if equipped).

Trailer towing (with towing hitch)*

Your vehicle is designed primarily as a passenger-and-load-carrying vehicle. Towing a trailer will have an adverse effect on handling, performance, braking, durability, and fuel consumption. Your safety and satisfaction depend on the proper use of correct equipment and cautious driving habits. For your safety and the safety of others, do not overload the vehicle or trailer.

To tow a trailer safely, use extreme care and drive the vehicle in accordance with the trailer's characteristics and operating conditions.

Toyota warranties do not apply to damage or malfunction caused by towing a trailer for commercial purposes.

Ask your local authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for further details before towing, as there are additional legal requirements in some countries.

Weight limits

Check the allowable towing capacity, GVM (Gross Vehicle Mass), MPAC (Maximum Permissible Axle Capacity), and permissible drawbar load before towing. (→P. 708)

♦ Towing hitch/bracket

Toyota recommends the use of the Toyota hitch/bracket for your vehicle. Other products of a suitable nature and comparable quality may also be used.

◆ To prevent an accident

The handling of the vehicle will feel different when towing a trailer. Beware of the 3 most common causes of towing-related accidents: driver error, excessive speed, and overloading.

*: If equipped

Selecting a trailer ball

Use the correct trailer ball for your application.

1 Trailer ball load rating


Matches or exceeds the gross trailer weight rating of the trailer.

2 Ball diameter


Matches the size of the trailer coupler. Most couplers are stamped with the required trailer ball size.

3 Shank length

Protrudes beyond the bottom of the lock washer and nut at least 2 threads.



Matches the ball mount hole diameter size.



Connecting trailer lights

Use the wire harness stored in the rear end.

تلفن شبانه روزی: ۱-۲۱-۸۸۸۶۲ ۲۲ **۰**


■ Total trailer weight and permissible drawbar load

1 Total trailer weight

Weight of the trailer itself plus the trailer load should be within the maximum towing capacity. Exceeding this weight is dangerous. (→P. 708)

When towing a trailer, use a friction coupler or friction stabilizer (sway control device).

When the total trailer weight is over 2000 kg (4409 lb.), a friction stabilizer (sway control device) is required.



2 Permissible drawbar load

Allocate the trailer load so that the drawbar load is greater than 25 kg (55.1 lb.) or 4 % of the towing capacity. Do not let the drawbar load exceed the indicated weight. (\rightarrow P. 708)

4

Driving

تلفن شبانه روزى: ۱-۸۸۸۶۲ ۲۸۵ الا

■ Information tag (manufacturer's label)

1) Gross vehicle mass


The combined weight of the driver, passengers, luggage, towing hitch, total curb mass and drawbar load should not exceed the gross vehicle mass by more than 100 kg (220.5 lb.). Exceeding this weight is dangerous.

2 Maximum permissible rear axle capacity

The weight borne by the rear axle should not exceed the maximum permissible axle capacity by 15 % or more. Exceeding this weight is dangerous.

The values for towing capacity were derived from testing conducted at sea level. Take note that engine output and towing capacity will be reduced at high altitudes.

*: To distinguish the vehicle category, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



LC150 OM OM60P18E (EE)

■When the gross vehicle mass or maximum permissible axle capacity is exceeded

Failing to observe this precaution may lead to an accident causing death or serious injury.


- Add additional 20.0 kPa (0.2 kgf/cm² or bar, 3 psi) to the recommended tire inflation pressure value. (\rightarrow P. 735)
- Do not exceed the established speed limit for towing a trailer in built-up areas or 100 km/h (62 mph), whichever is lower.




تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱۰


Installation positions for the towing hitch/bracket and hitch ball

- ▶ 5-door models
- 1 78 mm (3.0 in.)
- 2 78 mm (3.0 in.)
- ③ 53 mm (2.1 in.)
- ④ 53 mm (2.1 in.)
- ⑤ 53 mm (2.1 in.)
- ⑥ 53 mm (2.1 in.)
- 7 1219 mm (48.0 in.)
- 8 137 mm (5.4 in.)*1
 141 mm (5.6 in.)*2
- 9 79 mm (3.1 in.)*1 83 mm (3.3 in.)*2
- ① 54 mm (2.1 in.)*1 58 mm (2.3 in.)*2
- (1) 428 mm (16.9 in.)*1 336 mm (13.2 in.)*2
- ② 200 mm (7.9 in.)*1 199 mm (7.8 in.)*2
- 13 171 mm (6.7 in.)*1 169 mm (6.7 in.)*2
- 171 mm (6.7 in.)*1 168 mm (6.6 in.)*2
- *1: Vehicles with rear height control air suspension
- *2: Vehicles without rear height control air suspension






- ① 78 mm (3.0 in.)
- ② 78 mm (3.0 in.)
- ③ 53 mm (2.1 in.)
- ④ 53 mm (2.1 in.)
- ⑤ 53 mm (2.1 in.)
- ⑥ 53 mm (2.1 in.)
- 7 1110 mm (43.7 in.)
- 8 142 mm (5.6 in.)
- 9 84 mm (3.3 in.)
- ① 59 mm (2.3 in.)
- ① 327 mm (12.9 in.)
- ① 199 mm (7.8 in.)
- (3) 169 mm (6.7 in.)
- ① 167 mm (6.6 in.)







When connecting and disconnecting a trailer (vehicles with rear height control air suspension)

- Connecting
- 1 Set the rear height control air suspension to LO mode.
- 2 Turn off the engine switch or the rear height control air suspension.
- 3 Connect the trailer.
- 4 Turn on the switch that was turned off on step 2.
- 5 Set the rear height control air suspension to N mode.
- Disconnecting
- 1 Set the rear height control air suspension to LO mode.
- 2 Turn off the rear height control air suspension.
- 3 Turn off the engine switch.
- 4 Set the supporting leg of a trailer on the ground and raise the hitch by 100 mm (4 in.).
- 5 Turn on the engine switch.
- 6 Turn on the rear height control air suspension.
- 7 Wait until vehicle height is stabilized.

Make sure the hitch is disconnected. If the hitch does not disconnect, raise the hitch higher and repeat steps 2 through 7.

■ Tire information

- Increase the tire inflation pressure to 20.0 kPa (0.2 kgf/cm² or bar, 3 psi) greater than the recommended value when towing. (→P. 735)
- Increase the air pressure of the trailer tires in accordance with the total trailer weight and according to the values recommended by the manufacturer of your trailer.

■ Trailer lights

Check that the turn signal lights and stoplights are operating correctly every time you hitch up the trailer. Directly wiring up to your vehicle may damage the electrical system and stop the lights from functioning correctly.

■ Break-in schedule

Toyota recommends that vehicles fitted with new power train components should not be used for towing trailers for the first 800 km (500 miles).

- Check that the maximum load limit for the towing hitch/bracket hitch ball is not exceeded. Bear in mind that the coupling weight of the trailer will add to the load exerted on the vehicle. Also make sure that the total load exerted on the vehicle is within the range of the weight limits. (→P. 235)
- Ensure that the trailer load is secure.
- Supplementary outside rear view mirrors should be added to the vehicle if the traffic behind cannot be clearly seen with standard mirrors. Adjust the extending arms of these mirrors on both sides of the vehicle so that they always provide maximum visibility of the road behind.

■ Maintenance

- Maintenance must be performed more frequently when using the vehicle for towing due to the greater weight burden placed on the vehicle compared to normal driving.
- Retighten all bolts securing the hitching ball and bracket after towing for approximately 1000 km (600 miles).

■ If trailer sway occurs

One or more factors (crosswinds, passing vehicles, rough roads, etc.) can adversely affect handling of your vehicle and trailer, causing instability.

- If trailer swaying occurs:
 - Firmly grip the steering wheel. Steer straight ahead.

 Do not try to control trailer swaying by turning the steering wheel.
 - Begin releasing the accelerator pedal immediately but very gradually to reduce speed.

Do not increase speed. Do not apply vehicle brakes.

If you make no extreme correction with the steering or brakes, your vehicle and trailer should stabilize (if enabled, Trailer Sway Control can also help to stabilize the vehicle and trailer.).

- After the trailer swaying has stopped:
 - · Stop in a safe place. Get all occupants out of the vehicle.
 - · Check the tires of the vehicle and the trailer.
 - · Check the load in the trailer.

Make sure the load has not shifted.

Make sure the tongue weight is appropriate, if possible.

· Check the load in the vehicle.

Make sure the vehicle is not overloaded after occupants get in.

If you cannot find any problems, the speed at which trailer swaying occurred is beyond the limit of your particular vehicle-trailer combination. Drive at a lower speed to prevent instability. Remember that swaying of the towing vehicle-trailer increases as speed increases.

4

Driving

■ To avoid accident or injury

- Vehicles with the rear height control air suspension:
 Set the vehicle height to the low mode and turn off the rear height control air suspension to prevent the vehicle height from automatically changing.
- Vehicles with the emergency tire puncture repair kit:
 Do not tow a trailer when the tire installed is repaired with the emergency tire puncture repair kit.

↑ NOTICE

■ When the rear bumper strengthening material is aluminum

Ensure the steel bracket part does not come directly in contact with that area.

When steel and aluminum come into contact, there is a reaction similar to corrosion, which will weaken the section concerned and may result in damage. Apply a rust inhibitor to parts that will come in contact when attaching a steel bracket.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

Guidance

Your vehicle will handle differently when towing a trailer. In order to avoid accident, death or serious injury, keep the following in mind when towing:

■ Checking connections between trailer and lights

Stop the vehicle and check the operation of the connection between the trailer and lights after driving for a brief period as well as before starting off.

■ Practicing driving with a coupled trailer

- Get the feel for turning, stopping and reversing with the trailer coupled by practicing in an area with no or light traffic.
- When reversing with a coupled trailer, hold the section of the steering wheel nearest to you and rotate clockwise to turn the trailer left or counterclockwise to turn it right. Always rotate a little at a time to prevent steering error. Have someone guide you when reversing to lessen the risk of accident.

■ Increasing vehicle-to-vehicle distance

At a speed of 10 km/h (6 mph), the distance to the vehicle running ahead of you should be equivalent to or greater than the combined length of your vehicle and trailer. Avoid sudden braking that may cause skidding. Otherwise, the vehicle may spin out of control. This is especially true when driving on wet or slippery road surfaces.

■ Sudden acceleration/steering input/cornering

Executing sharp turns when towing may result in the trailer colliding with your vehicle. Decelerate well in advance when approaching turns and take them slowly and carefully to avoid sudden braking.

Important points regarding turning

The wheels of the trailer will travel closer to the inside of the curve than the wheels of the vehicle. To make allowance for this, take the turns wider than you would normally do.

■ Important points regarding stability

Vehicle movement resulting from uneven road surfaces and strong crosswinds will affect handling. The vehicle may also be rocked by passing buses or large trucks. Frequently check behind when moving alongside such vehicles. As soon as such vehicle movement occurs, immediately start to decelerate smoothly by slowly applying the brakes. Always steer the vehicle straight ahead while braking.

■ Passing other vehicles

Consider the total combined length of your vehicle and trailer and ensure that the vehicle-to-vehicle distance is sufficient before executing lane changes.

■ Transmission information

Refrain from driving in the 6th gear (6-speed manual transmission) or 5th gear (5-speed manual transmission), 5 or 6 range in S mode to maintain the effectiveness of the engine brake and the charge performance of electrical components.

■ If the engine overheats

Towing a loaded trailer up a long, steep incline in temperatures exceeding 30°C (85°F) may result in the engine overheating. If the engine coolant temperature gauge indicates that the engine is overheating, turn the air conditioning off immediately, leave the road and stop the vehicle in a safe place. (\rightarrow P. 701)

■ When parking the vehicle

Always place wheel chocks under the wheels of both the vehicle and trailer. Firmly set the parking brake and shift the shift lever to P for automatic transmissions, and 1 or R for manual transmissions.



Follow all the precautions described in this section. Failure to do so could cause an accident resulting in death or serious injury.

■ Trailer towing precautions

- When towing, make sure that none of the weight limits are exceeded. (→P. 235)
- Do not use cruise control (if equipped) or dynamic radar cruise control (if equipped) when trailer towing.

■ Vehicle speed in towing

Observe the legal maximum speeds for trailer towing.

■ Before descending hills or long declines

Reduce speed and downshift. Never downshift abruptly.

Operation of the brake pedal

Do not hold the brake pedal depressed often or for long periods of time. Doing so may result in the brake overheating or reduce braking effects.



NOTICE

For vehicles with an emergency tire puncture repair kit (if equipped)

Do not tow anything if a tire that has been repaired using the emergency tire puncture repair kit is installed. The load on the tire may cause unexpected damage to the tire. \star العن شبانه روزی: ω

■ Do not directly splice trailer lights

Directly splicing trailer lights may damage your vehicle's electrical system

Engine (ignition) switch (vehicles without a smart entry & start system)

Starting the engine

- ▶ Automatic transmission
- 1 Check that the parking brake is set.
- ² Check that the shift lever is set in P.
- 3 Firmly depress the brake pedal.
- 4 Turn the engine switch to the "START" position to start the engine.
- ▶ Manual transmission
- 1 Check that the parking brake is set.
- 2 Check that the shift lever is set in N.
- 3 Firmly depress the clutch pedal.
- 4 Turn the engine switch to the "START" position to start the engine.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

① "LOCK"

The steering wheel is locked and the key can be removed. (Vehicles with an automatic transmission: The key can be removed only when the shift lever is in P.)

② "ACC"


Some electrical components such as the audio system can be used.

③ "ON"

All electrical components can be used.

(4) "START"

For starting the engine.



■Turning the key from "ACC" to "LOCK"

- Shift the shift lever to P (automatic transmission) or N (manual transmission). (\rightarrow P. 257, 264)
- 2 Push in the key and turn it to the "LOCK" position.

FarmaS



■ If the engine does not start


The engine immobilizer system may not have been deactivated. (→P. 83) Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

4

Drivina

■ When the steering lock cannot be released

When starting the engine, the engine switch may seem stuck in the "LOCK" position. To free it, turn the key while turning the steering wheel slightly left and right.



■ Key reminder function

A buzzer sounds if the driver's door is opened while the engine switch is in the "LOCK" or "ACC" position to remind you to remove the key.



CAUTION

■When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

Caution when driving

Do not turn the engine switch to the "LOCK" position while driving. If in an emergency, you must turn the engine off while the vehicle is moving, turn the engine switch only to the "ACC" position to stop the engine. An accident may result if the engine is stopped while driving. $(\rightarrow P. 615)$



NOTICE

■ To prevent battery discharge

Do not leave the engine switch in the "ACC" or "ON" position for long periods of time without the engine running.

When starting the engine

- Do not crank the engine for more than 30 seconds at a time. This may overheat the starter and wiring system.
- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

Performing the following operations when carrying the electronic key on your person starts the engine or changes engine switch modes.

Starting the engine

- ▶ Automatic transmission
- 1 Check that the parking brake is set.
- 2 Check that the shift lever is set in P.
- 3 Firmly depress the brake pedal.

The engine switch indicator will turn green.

If the indicator does not turn green, the engine cannot be started.

4 Press the engine switch shortly and firmly.


When operating the engine switch, one short, firm press is enough. It is not necessary to press and hold the switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less.

Continue depressing the brake pedal until the engine is completely started.

Diesel engine only: the 00 indicator turns on. The engine will start after the indicator light goes out.

The engine can be started from any engine switch mode.



4

Driving

- ▶ Manual transmission
- 1 Check that the parking brake is set.
- 2 Check that the shift lever is set in N.
- 3 Firmly depress the clutch pedal.

The engine switch indicator will turn green.

If the indicator does not turn green, the engine cannot be started.

4 Press the engine switch shortly and firmly.


When operating the engine switch, one short, firm press is enough. It is not necessary to press and hold the switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less.

Continue depressing the clutch pedal until the engine is completely started

The 00 indicator turns on. The engine will start after the indicator light goes out.

The engine can be started from any engine switch mode.



- ▶ Automatic transmission
- 1 Stop the vehicle.
- 2 Set the parking brake (\rightarrow P. 270), and shift the shift lever to P.
- 3 Press the engine switch.
- 4 Release the brake pedal and check that the indicator on the engine switch is off.
- ► Manual transmission
- 1 Stop the vehicle.
- 2 Shift the shift lever to N.
- 3 Set the parking brake. (\rightarrow P. 270)
- 4 Press the engine switch.
- 5 Release the brake pedal and check that the indicator on the engine switch is off.

4

Driving

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

Changing engine switch modes


Modes can be changed by pressing the engine switch with brake pedal (vehicles with an automatic transmission) or clutch pedal (vehicles with a manual transmission) released. (The mode changes each time the switch is pressed.)

(1) Off*

The emergency flashers can be used.

② ACCESSORY mode

Some electrical components such as the audio system can be used. The engine switch indicator turns amber.



(3) IGNITION ON mode

All electrical components can be used.

The engine switch indicator turns amber.

*: If the shift lever is in a position other than P when turning off the engine, the engine switch will be turned to ACCESSORY mode, not to off (vehicles with an automatic transmission only).



If the engine is stopped with the shift lever in a position other than P, the engine switch will not be turned off but instead be turned to ACCESSORY mode. Perform the following procedure to turn the switch off:

- 1 Check that the parking brake is set.
- 2 Shift the shift lever to P.
- 3 Check that the indicator on the engine switch is illuminated in amber and then press the engine switch once.
- 4 Check that the indicator on the engine switch is off.

■ Auto power off function

▶ Vehicles with an automatic transmission

When the shift lever is in P, if the vehicle is left in ACCESSORY or IGNITION ON mode with the engine not running for more than 20 minutes (ACCESSORY mode) or one hour (IGNITION ON mode), the engine switch will automatically turn off. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the engine switch in ACCESSORY or IGNITION ON mode for long periods of time when the engine is not running.

▶ Vehicles with a manual transmission

If the vehicle is left in ACCESSORY or IGNITION ON mode with the engine not running for more than 20 minutes (ACCESSORY mode) or one hour (IGNITION ON mode), the engine switch will automatically turn off. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the engine switch in ACCESSORY or IGNITION ON mode for long periods of time when the engine is not running.

■ Operation of the engine switch

If the switch is not pressed shortly and firmly, the engine switch mode may not change or the engine may not start.

4

Driving

■ Electronic key battery depletion

→P. 165

■ Conditions affecting operation

→P. 162

■ Note for the entry function

→P. 163

■ If the engine does not start


The engine immobilizer system may not have been deactivated. $(\rightarrow P.~83)$ Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ Steering lock

After turning the engine switch off and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the engine switch again automatically cancels the steering lock.

■ When the steering lock cannot be released

The green indicator light on the engine switch will flash and a message will be shown on the multi-information display. Press the engine switch again while turning the steering wheel left and right.



Steering lock motor overheating prevention

To prevent the steering lock motor from overheating, the motor may be suspended if the engine is turned on and off repeatedly in a short period of time. In this case, refrain from running the engine. After about 10 seconds, the steering lock motor will resume functioning.

■ When the engine switch indicator flashes in amber

The system may be malfunctioning. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

■ If the electronic key battery is depleted

→P. 588

■ If the smart entry & start system has been deactivated in a customized setting

→P. 691

A CAUTION

■When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

Caution while driving

If engine failure occurs while the vehicle is moving, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.

■ Stopping the engine in an emergency

If you want to stop the engine in an emergency while driving the vehicle, press and hold the engine switch for more than 2 seconds, or press it briefly 3 times or more in succession. (→P. 615)

However, do not touch the engine switch while driving except in an emergency. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

№ NOTICE

■ To prevent battery discharge

- Do not leave the engine switch in ACCESSORY or IGNITION ON mode for long periods of time without the engine running.
- If the indicator on the engine switch is illuminated, the engine switch is not off. When exiting the vehicle, always check that the engine switch is off.
- On vehicles with an automatic transmission, do not stop the engine when the shift lever is in a position other than P. If the engine is stopped in another shift lever position, the engine switch will not be turned off but instead be turned to ACCESSORY mode. If the vehicle is left in ACCES-SORY mode, battery discharge may occur.

■When starting the engine


- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

Symptoms indicating a malfunction with the engine switch

If the engine switch seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

تلفن شبانه روزی: ۸۵ • ۲۱ ۸۸۸ - ۲۱

Shifting the shift lever



While the engine switch is in IGNITION ON mode, move the shift lever with the brake pedal depressed.

When shifting the عالم المحتاد المحتا When shifting the shift lever between P and D, make sure that the

FarmaSOS.com

*: If equipped

Shift position purpose

Shift position	Purpose and condition
Р	Parking the vehicle/starting the engine
R	Reversing
N	Neutral (Condition in which the power is not transmitted)
D	Normal driving*1
S	S mode driving ^{*2} (→P. 260)

^{*1:} Shifting to the D position allows the system to select a gear suitable for the driving conditions. Setting the shift lever to the D position is recommended for normal driving.


Selecting the second start mode

Use second start mode for accelerating and driving on slippery road surfaces such as snow.

▶ Vehicles with the multi-information display type A and B

Turn the "2nd STRT" button on.


Press the button again to cancel second start mode.




^{*2:} Selecting shift ranges using S mode restricts the upper limit of the possible gear ranges, controls engine braking forces, and prevents unnecessary upshifting.

- ▶ Vehicles with the multi-information display type C
- 1 Press the menu switch.

The multi-information display will change modes to electronic features control mode.



2 Press the "ENTER" switch upwards or downwards until "2ND START" appears.




3 Press the "ENTER" switch to change to "ON".

The "2nd STRT" indicator will be displayed.

Each pressing of the switch turns second start mode on and off.

Press the menu switch to change to the normal display.



4

Driving

Changing shift ranges in S mode

When the shift lever is in the S position, the shift lever can be operated as follows:

- 1 Upshifting
- 2 Downshifting


5-speed models:

The selected shift range, from 1 to 5, will be displayed in the meter.

The initial shift range in S mode is set automatically to 4 according to vehicle speed. However, the initial shift range may be set to 3 if Al-SHIFT has operated while the shift lever was in the D position. $(\rightarrow P. 261)$

6-speed models:

The selected shift range, from 1 to 6, will be displayed in the meter. The initial shift range in S mode is set automatically to 4 or 5 according to vehicle speed. However, the initial shift range may be set to 3 if AI-SHIFT has operated while the shift lever was in the D position. $(\rightarrow P. 261)$



تلفن شبانه روزی: ۱

■ Shift ranges and their functions

- You can choose from 5 (5-speed models) or 6 (6-speed models) levels of engine braking force.
- A lower shift range will provide greater engine braking force than a higher shift range, and the engine speed will also increase.

On declines, there may be case where the vehicle shifts down automatically to obtain engine braking. As a result of the downshifting, the engine speed may increase.

■ Second start mode automatic deactivation

Second start mode is automatically deactivated if the engine is turned off after driving in second start mode.

■S mode

When the shift range is 4 or lower, holding the shift lever toward "+" sets the shift range to 5 (5-speed models) or 6 (6-speed models).

■ AI-SHIFT

Al-SHIFT automatically selects a suitable gear according to driver performance and driving conditions.

AI-SHIFT automatically operates when the shift lever is in the D position. (Shifting the shift lever to the S position cancels the function.)

When driving with the cruise control or dynamic radar cruise control (if equipped)

Engine braking will not occur in S mode, even when downshifting to 4 or 5. $(\rightarrow P. 302, 306)$

■ Shift lock system

The shift lock system is a system to prevent accidental operation of the shift lever in starting.

The shift lever can be shifted from P only when the engine switch is in the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system) and the brake pedal is being depressed.

FarmaSOS.com

4

Driving

■ If the shift lever cannot be shifted from P

First, check whether the brake pedal is being depressed.

If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted.


Releasing the shift lock:

- 1 Set the parking brake.
- 2 Vehicles without a smart entry & start system: Turn the engine switch to the "LOCK" position.

Vehicles with a smart entry & start system:

Turn the engine switch off.

- 3 Depress the brake pedal.
- Press the shift lock override button.
 The shift lever can be shifted while the button is pressed.



■ If the "S" indicator does not come on even after shifting the shift lever to S

This may indicate a malfunction in the automatic transmission system. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

■ Downshift restriction warning buzzer (S mode)

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever is operated. (A buzzer will sound twice.)

■ Transmission protection function (6-speed models)

If the tires spin continually when the vehicle becomes stuck in mud, dirt or snow, or if the accelerator pedal is depressed and released repeatedly while driving, the automatic transmission temperature may become too high and the automatic transmission may be damaged.

To avoid damaging the automatic transmission, the system may temporarily lock the gear.

If the automatic transmission temperature falls, the gear locking is canceled and the automatic transmission is returned to the normal operation.

A CAUTION

■When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.

■ To prevent an accident when releasing the shift lock

Before pressing the shift lock override button, make sure to set the parking brake and depress the brake pedal.

If the accelerator pedal is accidentally depressed instead of the brake pedal when the shift lock override button is pressed and the shift lever is shifted out of P, the vehicle may suddenly start, possibly leading to an accident resulting in death or serious injury.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱۰

Manual transmission*

Shifting the shift lever

▶ 5-speed transmission

Fully depress the clutch pedal before operating the shift lever, and then release it slowly.

If it is difficult to shift in reverse, shift the shift lever to N, release the clutch pedal momentarily, and then try again.



FarmaSOS.com

*: If equipped

Fully depress the clutch pedal before operating the shift lever, and then release it slowly.




درو فارما

Gear Shift Indicator (if equipped)

The Gear Shift Indicator display is a guide to help the driver achieve improved fuel economy and reduced exhaust emissions within limits of engine performance.

- ① Upshifting
- ② Downshifting



Driv

■ Gear Shift Indicator display

- The Gear Shift Indicator will not be displayed when the four-wheel drive control switch is in L4.
- The Gear Shift Indicator may not be displayed when your foot is placed on the clutch pedal.

■ Maximum downshifting speeds

Observe the downshifting speeds in the following table to prevent over-revving the engine.

▶ 5-speed transmission

	Maximum speed (km/h [mph])			
Shift position	Transfer position H4	Transfer position L4		
1,	45 (28)	17 (11)		
2	78 (48)	30 (19)		
3,	119 (74)	46 (29)		
4	165 (103)	67 (42)		

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ الا

	Maximum speed (km/h [mph])			
Shift position	Transfer position H4	Transfer position L4		
1	38 (24)	15 (9)		
2	77 (48)	30 (19)		
3	105 (65)	41 (25)		
4	131 (81)	51 (32)		
5	157 (98)	61 (38)		

■ Reverse warning buzzer (vehicles with a 6-speed transmission)


A buzzer will sound to alert the driver if the shift lever is shifted to the R position.



A CAUTION

■ Gear Shift Indicator display (if equipped)

For safety, the driver should not look only at the display. Refer to the display when it is safe to do so while considering actual traffic and road conditions. Failure to do so may lead to an accident.



تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **- ۲۱**

Turn signal lever


Operating instructions

The turn signal lever can be used to show the following intentions of the driver:

- 1 Right turn
- 2 Lane change to the right (push and hold the lever partway)

The right hand signals will flash until you release the lever.

- 3 Lane change to the left (push and hold the lever partway)
 - The left hand signals will flash until you release the lever.
- (4) Left turn





■Turn signals can be operated when

▶ Vehicles without a smart entry & start system The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system


The engine switch is in IGNITION ON mode.

■ If the indicator flashes faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.

Parking brake

- 1 To set the parking brake, fully pull the parking brake lever while depressing the brake pedal.
- ② To release the parking brake, slightly raise the lever and lower it completely while pressing the button.



■ Parking the vehicle

→P. 219

■Usage in winter time

→P. 400



■ Before driving

Fully release the parking brake.

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear

When the deposit collected by the filter reaches a predetermined amount, it is automatically regenerated.

Regeneration

Regeneration is performed as necessary in accordance with driving conditions.

System characteristics

The DPF system has the following characteristics:

- Idle speed increases during regeneration
- The smell of the exhaust gas differs from that of a conventional diesel vehicle

DPF system failure warning

- If the DPF system warning message "DPF FULL SEE OWNER'S MANUAL" appears on the display, drive continuously. (→P. 647)
- If the DPF system warning message "DPF FULL VISIT YOUR DEALER" appears on the display, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer, immediately. (→P. 645)

ately. (→P. 645)

₽

■ Replacing the engine oil

Make sure to use an oil of the recommended grade or of matching quality. $(\rightarrow P. 715)$

■ DPF system warning

Under the following driving conditions, the DPF system warning message may come on earlier than normal.*

- When only driving at low speeds (for example 20 km/h [12 mph] or below).
- If the engine is turned on and off frequently (if the engine is not left running for more than 10 minutes at a time).
- *: Differs in accordance with weather, driving conditions, etc.

A CAUTION

During regeneration

Observe the following precautions.

Failure to do so may result in serious injury such as burns caused by the hot exhaust pipe and exhaust gases, or may cause a fire.

 Do not stop the vehicle where flammable materials, such as dry grass, are near the exhaust pipe.



 Make sure that there are no people near the exhaust pipe.

FarmaSO



- Vehicles with DPF system switch: Do not carry out regeneration when the vehicle is in an enclosed area, such as a garage.
- Do not touch the exhaust pipe and exhaust gases during regeneration.

■ If the malfunction indicator light comes on

The malfunction indicator light comes on if you continue driving while the DPF system warning message "DPF FULL VISIT YOUR DEALER" appears on the display. In this event, damage may be caused to the vehicle or an accident may occur. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer, immediately.

⚠ NOTICE

■ To prevent the DPF system from failing

- Do not drive for long periods of time while the DPF system warning message "DPF FULL VISIT YOUR DEALER" appears on the display.
- Do not use fuel other than the specified type
- Do not use engine oil other than the recommended type
- Do not modify the exhaust pipe



D

تلفن شبانه روزى: ۱۵۸۰۲۰۸۸۸-۲۱


Headlight switch

The headlights can be operated manually or automatically.

Operating instructions

Turning the end of the lever turns on the lights as follows:


- O Vehicles without daytime running light system: Off.
 Vehicles with daytime running light system: The daytime running lights turn on (→P. 284).
- 2 =00= The front position, tail, license plate and instrument panel lights turn on.
- The headlights and all lights listed above turn on.



(4) **AUTO** Vehicles without a smart entry & start system: The head(if equipped) lights, front position lights, daytime running lights (→P. 284)
and so on turn on and off automatically (when the engine switch is in the "ON" position.)

Vehicles with a smart entry & start system: The headlights, front position lights, daytime running lights (\rightarrow P. 284) and so on turn on and off automatically (when the engine switch is in IGNITION ON mode.)

- 1 With the headlights on, push the lever away from you to turn on the high beams.
 - Pull the lever toward you to the center position to turn the high beams off.
- ② Pull the lever toward you and release it to flash the high beams once.



You can flash the high beams with the headlights on or off.

Manual headlight leveling dial (if equipped)

The level of the headlights can be adjusted according to the number of passengers and the loading condition of the vehicle.

- 1 Raises the level of the head-lights
- 2 Lowers the level of the head-lights



FarmaSOS.com

4

Driving

■ Guide to dial settings

▶ 5-door and 9-seat models

	O	Occupancy and luggage load conditions			
	Driver only, or Driver and one pas- senger in the front seat	Driver, one passenger in the front seat, and all passengers in the rear seats farthest to the rear	All passengers	All passengers and full luggage loading in the luggage room	Driver and full lug- gage loading in the lug- gage room
GRJ150L-GKTEK	0	1	2.5	3	4
KDJ150L-GKAEY	0	1	2.5	3	4
TRJ150L-GKMEK TRJ150L-GKTEK	-	タイ・人(1	۶ روزی: ۵ 2.5	تلفن شبك 3	3

The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

	O	Occupancy and luggage load conditions			
	Driver only, or Driver and one pas- senger in the front seat	Driver, one passenger in the front seat, and all passengers in the rear seats farthest to the rear	All pas- sengers	All passengers and full luggage loading in the luggage room	Driver and full lug- gage loading in the lug- gage room
GDJ150L-GKFEYW (TX grade, TXL grade comply with EURO V and TXL grade with- out KDSS and comply with EURO VI)	0	1	2	3	3.5
GDJ150L-GKFEYW (TXL grade with KDSS comply with EURO VI)	0	1	2	2.5	3.5
GDJ150L-GKTEYW	-\\\\\\	タイ・人 1	۶ روزی: (2	تلفن شبا <i>ن</i> 3	3.5
GDJ150R-GKFEYW GDJ150R-GKTEYW (TXL grade with KDSS)	rma	aŞO	S ₂ C	o m	3.5
GDJ150R-GKFEYW (TX grade and TXL grade without KDSS)	0	1	2	3	4
GDJ150R-GKTEYW (TX grade and TXL grade without KDSS)	0	1	2	3	3.5

The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

▶ 5-door and 7-seat models (2/2)

	Od	ccupancy ar	ıd luggage lo	oad conditio	ns
	Driver only, or Driver and one pas- senger in the front seat	Driver, one passenger in the front seat, and all passengers in the rear seats farthest to the rear	All pas- sengers	All passengers and full luggage loading in the luggage room	Driver and full lug- gage loading in the lug- gage room
GRJ150L-GKTEK GRJ150L-GKTEKW	0	1	2	3	4
KDJ150L-GKAEY	9 0		2	3	4
KDJ150L-GKAEYW KDJ150L-GKFEYW (TX grade)		タイ+人(ء روز ي: ۵	تلف <u>ر</u> 5.3شبك	3.5
KDJ150L-GKAEYW KDJ150L-GKFEYW (TXL grade)	rma	aS0	S ² .c	om	3.5
TRJ150L-GKMEK TRJ150L-GKTEK (TXL grade with subtank)	0	1	2	2.5	2.5
TRJ150L-GKMEK TRJ150L-GKTEK (TX grade and TXL grade without subtank)	0	1	2	3	3

The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

4

Driving

^{*:} To distinguish the vehicle category, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

▶ 5-door and 5-seat models (vehicle category M1*) (2/2)

	O	Occupancy and luggage load conditions			
	Driver only, or Driver and one pas- senger in the front seat	Driver, one passenger in the front seat, and all passengers in the rear seats farthest to the rear	All pas- sengers	All passengers and full luggage loading in the luggage room	Driver and full lug- gage loading in the lug- gage room
KDJ150L-GKAEYW KDJ150L-GKFEYW KDJ150L-GKAEY	0	1	1	3.5	3.5
TRJ150L-GKMEK TRJ150L-GKTEK (TX grade)	9 0		1)	3.5	3.5
TRJ150L-GKMEK TRJ150L-GKTEK (TXL grade)		タイ4人(ه روزلی: ۵	تلفن ³ شبا <i>ل</i>	3

^{*:} To distinguish the vehicle category, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

The model code is indicated on the manufacturer's label. (→P. 711)

	Occupancy and luggage load conditions				
	Without load	Driver and full luggage loading in the luggage room			
GDJ150L-GKTEYW GDJ150L-GKFEYW GDJ150R-GKTEYW GDJ150R-GKFEYW	0	3			
GRJ150L-GKTEKW	0	3			

^{*:} To distinguish the vehicle category, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

The model code is indicated on the manufacturer's label. (→P. 711)

Driving

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸ الا

▶ 5-door and 2-seat models

	Occupancy and lugg	gage load conditions
	Without load	Driver and full luggage loading in the luggage room
GDJ150L-GKFEYW GDJ150L-GKTEYW GDJ150R-GKTEYW (TX grade)	0	3.5
GDJ150L-GKFEYW GDJ150L-GKTEYW GDJ150R-GKTEYW (TXL grade)	0	3
GDJ150R-GKFEYW	690,95	3
GRJ150L-GKTEKW	0	3
+ 5)	<u>- ハハハア 「 ・ ハ </u>	تلفن شبانه روز:

The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

	O	Occupancy and luggage load conditions			
	Driver only, or Driver and one pas- senger in the front seat	Driver, one passenger in the front seat, and all passengers in the rear seats farthest to the rear	All pas- sengers	All passengers and full luggage loading in the luggage room	Driver and full lug- gage loading in the lug- gage room
GDJ155L-GJFEYW GDJ155L-GJTEYW GDJ155R-GJFEYW GDJ155R-GJTEYW (VX grade)	0	1.5	1.5	2.5	3
GDJ155L-GJFEYW GDJ155L-GJTEYW GDJ155R-GJFEYW GDJ155R-GJTEYW (TX and TXL grades)	0	1.5	1.5	3	3.5

The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

▶ 3-door and 2-seat models

Eo	Occupancy and lugg	gage load conditions
га	Without load	Driver and full luggage loading in the luggage room
GDJ155L-GJFEYW GDJ155L-GJTEYW GDJ155R-GJFEYW GDJ155R-GJTEYW	0	4

The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

4

Driving

■ Daytime running light system (if equipped)

Vehicles with LED headlights: To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically whenever the engine is started with the headlight switch off or in the "AUTO" position. (Illuminate brighter than the front position lights.) Daytime running lights are not designed for use at night.

Vehicles with halogen headlights: To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically whenever the engine is started with the headlight switch off or in the "AUTO" position. (Illuminate dimmer than the headlights and tail lights.) Daytime running lights are not designed for use at night.

Headlight control sensor (if equipped)

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



■ Automatic light off system

- ▶ Type A
- Vehicles without a smart entry & start system All lights turn off automatically if the engine switch is turned to the "ACC" or "LOCK" position and the driver's door is opened.

To turn the lights on again, turn the engine switch to the "ON" position, or turn the light switch off once and then back to \bullet or \bullet 005.

Vehicles with a smart entry & start system

All lights turn off if the engine switch is turned to ACCESSORY mode or turned off and the driver's door is opened.

To turn the lights on again, turn the engine switch to IGNITION ON mode,

- When the light switch is in AUTO: All lights turn off automatically if the engine switch is turned to ACCESSORY mode or turned off and a door or the glass hatch (if equipped) is opened and closed.
- ■When the light switch is in =00= or ED: The headlights and front fog lights turn off automatically if the engine switch is turned to ACCESSORY mode or turned off. (A buzzer sounds if the driver's door is opened at this time.)

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the light switch off once and then back to =0000 or =000.

- ▶ Type C
- When only the tail lights are on: All lights turn off if the engine switch is turned to ACCESSORY mode or turned off and the driver's door is opened.
- When the headlights are on: All lights turn off 30 seconds after a door or the glass hatch (if equipped) is opened and closed.

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the light switch off once and then back to or -005.

- ▶ Type D
- When the light switch is in Auто: All lights turn off 30 seconds after a door or the glass hatch (if equipped) is opened and closed if the engine switch is turned to ACCESSORY mode or turned off. (The lights turn off immediately on the key is pressed after all the doors are locked.)
- When the light switch is in ₹005 or ₹○ : The headlights and front fog lights turn off automatically if the engine switch is turned to ACCESSORY mode or turned off. (A buzzer sounds if the driver's door is opened at this time.)

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the light switch off once and then back to =0.05 or =0.05.

■ Automatic headlight leveling system (if equipped)

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

■If the automatic headlight leveling system warning light flashes (if equipped)

It may indicate a malfunction in the system. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ Light reminder buzzer (if equipped)

A buzzer sounds when the engine switch is turned off or turned to ACCES-SORY mode and the driver's door is opened while the tail lights remain on.

■ Customization

Settings (e.g. light sensor sensitivity) can be changed. (Customizable features →P. 741)



■ To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running.


تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

The fog lights secure excellent visibility in difficult driving conditions, such as in rain and fog.

- ► Front and rear fog light switch
- O Turns the front and rear fog lights off
- 2 ‡ Turns the front fog lights on

Releasing the switch ring returns it to #().

Operating the switch ring again turns only the rear fog lights off.




FarmaSOS.com

IIB4PD028a

▶ Rear fog light switch

- ① o Turns the rear fog lights off



■Fog lights can be used when

▶ Vehicles with front and rear fog lights

Front fog lights: The headlights or front position lights are turned on.

Rear fog lights: The front fog lights are turned on. 9)


▶ Vehicles with rear fog lights only

The headlights or front position lights are turned on.

Operating the wiper lever


The wiper operation is selected by moving the lever as follows.

- ▶ Intermittent windshield wipers with interval adjuster
- 1 Intermittent operation
- 2 Low speed operation
- 3 High speed operation
- 4 Temporary operation



Wiper intervals can be adjusted when intermittent operation is selected.


- (5) Increases the intermittent windshield wiper frequency
- 6 Decreases the intermittent windshield wiper frequency



Washer/wiper dual operation

The wipers will automatically operate a couple of times after the washer squirts.


Vehicles with headlight cleaners: If the headlights are on, the headlight cleaners will operate once.



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

- ▶ Rain-sensing windshield wipers
- (1) Rain-sensing operation ("AUTO")
- 2 Low speed operation
- 3 High speed operation
- 4 Temporary operation


When "AUTO" is selected, the wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.



تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۱** ۲۸ تلفن شبانه روزی

The sensor sensitivity can be adjusted when "AUTO" is selected.

- (5) Increases the sensitivity
- 6 Decreases the sensitivity



Washer/wiper dual operation

The wipers operate automatically. (After operating several times, the wipers operate one more time after a short delay to prevent dripping.) Vehicles with headlight cleaners: If the headlights are on, the headlight cleaners will operate once.



تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۸**۸ ۲۲ ۲۸ تلفن

■The windshield wiper and washer can be operated when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

The engine switch is in IGNITION ON mode.

■ Raindrop sensor (vehicles with rain-sensing windshield wipers)

The raindrop sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs etc. are present on the windshield.



- If the wiper switch is turned to the "AUTO" position while the engine switch is in IGNITION ON mode, the wipers will operate once to show that "AUTO" mode is activated.
- When the sensor sensitivity ring is turned toward high while in "AUTO" mode, the wipers will operate once to indicate that the sensor sensitivity is enhanced.
- If the temperature of the raindrop sensor is 90°C (194°F) or higher, or -15°C (5°F) or lower, automatic operation may not occur. In this case, operate the wipers in any mode other than "AUTO".

■ Effects of vehicle speed on wiper operation (vehicles with rain-sensing windshield wipers)

With the settings other than "AUTO" also, the time until drip prevention wiper sweep occurs is changed depending on vehicle speed.

With the low speed operation selected, wiper operation will be switched from low speed to intermittent wiper operation only when the vehicle is stationary. (However, when the sensor sensitivity is adjusted to the highest level, the mode cannot be switched.)

■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the windshield washer fluid reservoir.



CAUTION

■ Caution regarding the use of windshield wipers in "AUTO" mode (vehicles with rain-sensing windshield wipers)

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in "AUTO" mode. Take care that your fingers or anything else does not become caught in the windshield wipers.

■ Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.



NOTICE

When the windshield is dry

Do not use the wipers, as they may damage the windshield.

When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.

■ When there is no washer fluid spray from the nozzle

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

When a nozzle becomes blocked

Do not try to clear it with a pin or other object. The nozzle will be damaged.

IIB4PD046

Rear window wiper and washer

Turning the end of the lever turns on the rear window wiper and washer.

- 1 --- Intermittent operation
- 2 Normal operation
- ③ 🛱 Washer/wiper dual operation
- 4 Washer/wiper dual operation



درو فارما

■The rear window wiper and washer can be operated when

● Vehicles without a smart entry & start system: The engine switch is in the "ON" position.

Vehicles with a smart entry & start system: The engine switch is in IGNITION ON mode.

The glass hatch (if equipped) is closed.

■ If no washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the washer fluid reservoir.



■When the rear window is dry

Do not use the wiper, as it may damage the rear window.

■When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.


Headlight cleaner switch*


Washer fluid can be sprayed on the headlights.

Press the switch to clean the headlights.

▶ Left-hand drive vehicles

▶ Right-hand drive vehicles





■ The headlight cleaners can be operated when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ON" position and the headlight switch is turned on.

If equipped, the headlight switch is in the "AUTO" position and the headlight is on.

▶ Vehicles with a smart entry & start system

The engine switch is in IGNITION ON mode and the headlight switch is turned on.

If equipped, the headlight switch is in the "AUTO" position and the headlight is on.

*: If equipped

■Windshield washer linked operation

▶ Vehicles without a smart entry & start system

When the windshield washer is operated with the engine switch is in the "ON" position and the headlight on, the headlight cleaners will operate once. $(\rightarrow P. 289)$

▶ Vehicles with a smart entry & start system

When the windshield washer is operated with the engine switch is in IGNITION ON mode and the headlight on, the headlight cleaners will operate once. $(\rightarrow P. 289)$



■When the washer fluid tank is empty

Do not press the switch continually as the washer fluid pump may overheat.

امداد مودرو فارما

تلفن شبانه روزى: ۱۵۸۰۲۹۸۸۸-۲۱

Opening the fuel tank cap

Perform the following steps to open the fuel tank cap.

Before refueling the vehicle

- Turn the engine switch to the "LOCK" position (vehicles without a smart entry & start system) or off (vehicles with smart entry & start system) and ensure that all the doors and windows are closed.
- Confirm the type of fuel.
- Fuel types

→P. 738

■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

A CAUTION

■When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

- After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.
- Always hold the grips on the fuel tank cap and turn it slowly to remove it. A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel. Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle. Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.



A CAUTION

■When refueling

Observe the following precautions to prevent fuel overflowing from the fuel

- Securely insert the fuel nozzle into the fuel filler neck.
- Stop filling the tank after the fuel nozzle automatically clicks off.
- Do not top off the fuel tank.



№ NOTICE


Refueling

Do not spill fuel during refueling.


Doing so may damage the vehicle, such as causing the emission control systems to operate abnormally or damaging fuel system components or the vehicle's painted surface.

تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۸**۸ ۲۲ ۲۸ تلفن

1 Pull up the opener to open the fuel filler door.




2 Turn the fuel tank cap slowly to open, and hang the fuel tank cap on the back of the fuel filler door.



Closing the fuel tank cap

After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.



A CAUTION

■When replacing the fuel tank cap


Do not use anything but a genuine Toyota fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

Cruise control*

Summary of functions

Use the cruise control to maintain a set speed without depressing the accelerator pedal.

- 1 Indicators
- 2 Cruise control switch




Setting the vehicle speed

1 Press the "ON-OFF" button to activate the cruise control.

Cruise control indicator will come on.


Press the button again to deactivate the cruise control.



2 Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator will come on.

The vehicle speed at the moment the lever is released becomes the set speed.




*: If equipped

To change the set speed, operate the lever until the desired set speed is obtained.

- 1 Increases the speed
- ② Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



The set speed will be increased or decreased as follows:

Fine adjustment: By approximately 1.6 km/h (1 mph) each time the lever is operated.


Large adjustment: The set speed can be increased or decreased continually until the lever is released.

Canceling and resuming the constant speed control

 Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied or the clutch pedal (manual transmission only) is depressed.

2 Pushing the lever up resumes the constant speed control.



Resuming is available when the vehicle speed is more than approximately 40 km/h (25 mph).

4

Driving

■ Cruise control can be set when

- The shift lever is in the D or range 4 or higher of S has been selected (vehicles with an automatic transmission).
- Vehicle speed is above approximately 40 km/h (25 mph).

■ Accelerating after setting the vehicle speed

- The vehicle can be accelerated normally. After acceleration, the set speed resumes.
- Even without canceling the cruise control, the set speed can be increased by first accelerating the vehicle to the desired speed and then pushing the lever down to set the new speed.

■ Automatic cruise control cancelation

Cruise control will stop maintaining the vehicle speed in any of the following situations:

- Actual vehicle speed falls more than approximately 16 km/h (10 mph) below the preset vehicle speed.
 - At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 40 km/h (25 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off by pressing the VSC OFF switch.
- Switching operation to center differential lock mode continues for 5 seconds or more after operating the center differential lock/unlock switch.
- If the warning message for the cruise control is shown on the multiinformation display or the cruise control indicator light turns to yellow

Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

A CAUTION

■ To avoid operating the cruise control by mistake

Switch the cruise control off using the "ON-OFF" button when not in use.

■ Situations unsuitable for cruise control

Do not use cruise control in any of the following situations. Doing so may result in loss of control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep hills

Vehicle speed may exceed the set speed when driving down a steep hill.

• When your vehicle is towing a trailer (with towing hitch) or during emergency towing


تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Dynamic radar cruise control*

Summary of functions

Dynamic radar cruise control supplements conventional cruise control with a vehicle-to-vehicle distance control. In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates or decelerates in order to maintain a set following distance from vehicles ahead.

- 1 Display
- ② Set speed
- (3) Indicators
- 4 Vehicle-to-vehicle distance button
- 5 Cruise control switch



FarmaSOS.com

*: If equipped

Setting the vehicle speed (vehicle-to-vehicle distance control mode)

1 Press the "ON-OFF" button to activate the dynamic radar cruise control.


Dynamic radar cruise control indicator will come on.


Press the button again to deactivate the cruise control.

2 Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator will come on.

The vehicle speed at the moment the lever is released becomes the set speed.





4

Driving

تلفن شبانه روزى: ۱۵۸۰۲۰۸۸۸-۲۱


Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is displayed.

- 1 Increases the speed
- 2 Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



In the vehicle-to-vehicle distance control mode, the set speed will be increased or decreased as follows:

- When the set speed is shown in "MPH"
 Fine adjustment: By approximately 8 km/h (5 mph) each time the lever is operated
 - Large adjustment: By approximately 8 km/h (5 mph) for each 0.6 seconds the lever is held
- · When the set speed is shown in "km/h"
 - Fine adjustment: By approximately 5 km/h (3.1 mph) each time the lever is operated

Large adjustment: By approximately 5 km/h (3.1 mph) for each 0.6 seconds the lever is held

In the constant speed control mode (\rightarrow P. 313), the set speed will be increased or decreased as follows:


Fine adjustment: By approximately 1.6 km/h (1 mph) each time the lever is operated

Large adjustment: The set speed can be increased or decreased continually until the lever is released.

Pressing the button changes the vehicle-to-vehicle distance as follows:

- 1 Long
- ② Medium
- 3 Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to IGNITION ON mode.



If a vehicle is running ahead of you, the preceding vehicle mark will be also displayed.

Vehicle-to-vehicle distance settings

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 80 km/h (50 mph). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

Distance options	Vehicle-to-vehicle distance
+ Long_\\S	Approximately 50 m (160 ft.)
Medium	Approximately 40 m (130 ft.)
Short	Approximately 30 m (100 ft.)

FarmaSOS.com

4

Driving

Canceling and resuming the speed control

1 Pulling the lever toward you cancels the dynamic radar cruise control.

The speed setting is also canceled when the brakes are applied.

② Pushing the lever up resumes the dynamic radar cruise control and returns vehicle speed to the set speed.




Resuming is available when the vehicle speed is more than approximately 40 km/h (25 mph).

Driving in vehicle-to-vehicle distance control mode

This mode employs a radar sensor to detect the presence of vehicles up to approximately 120 m (400 ft.) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



- 1 Example of constant speed cruising When there are no vehicles ahead
 - The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.
- ② Example of deceleration cruising
 When the vehicle ahead is driving slower than the set speed
 When a vehicle is detected running ahead of you the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.
- ③ Example of follow-up cruising When following a vehicle driving slower than the set speed The system continues follow-up cruising while adjusting for changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver.
- Example of acceleration
 When there are no longer are vehicles ahead driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

FarmaSOS.com

4

Driving

Approach warning

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the dynamic radar cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

■ Warnings may not occur when


In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle speed
- When the vehicle ahead is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- At the instant the accelerator is applied

تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to dirt, etc.

- 1 Press the "ON-OFF" button to activate the cruise control.
 - Press the button again to deactivate the cruise control.
- ② Switch to constant speed control mode. (Push the lever forward and hold for approximately 1 second.)



Constant speed control mode indicator will come on.

When in constant speed control mode, to return to vehicle-to-vehicle distance control mode, push the lever forward again and hold for approximately 1 second.

After the desired speed has been set, it is not possible to return to vehicle-to-vehicle distance control mode.

If the engine switch is turned off and then turned to IGNITION ON mode again, the vehicle will automatically return to vehicle-to-vehicle distance control mode.

Adjusting the speed setting: \rightarrow P. 303

Canceling and resuming the speed setting: →P. 303

FarmaSOS.com

4

Driving

■ Dynamic radar cruise control can be set when

- The shift lever is in the D or range 4 or higher of S has been selected.
- Vehicle speed is above approximately 50 km/h (30 mph).

■ Switching modes

The mode cannot be switched to constant speed control mode if vehicle-to-vehicle distance control mode has been used. The mode also cannot be switched from constant speed control to vehicle-to-vehicle distance control mode. Turn the system off by pressing the "ON-OFF" button, and turn it on again.

Accelerating after setting the vehicle speed

The vehicle can be accelerated normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

Automatic cancelation of vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations:

- Actual vehicle speed falls below approximately 40 km/h (25 mph).
- VSC is activated.
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed (when the wiper switch is set to the "AUTO" mode or the high speed wiper operation position).
- تلفن شیانه روزی: ۵۰۰ When second start mode is set.

allia

Bad weather causes the detection function to become extremely unstable.

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ Automatic cancelation of constant speed control

The cruise control will stop maintaining the vehicle speed in the following situ-

- Actual vehicle speed is more than approximately 16 km/h (10 mph) below the set vehicle speed.
 - At this time, the memorized set speed is not retained.
- Actual vehicle speed falls below approximately 40 km/h (25 mph).
- VSC is activated.
- TRC is activated for a period of time.
- •When the VSC or TRC system is turned off by pressing the VSC OFF switch.
- Switching operation to center differential lock mode continues for 5 seconds or more after operating the center differential lock/unlock switch.

■ Radar sensor and grille cover

Always keep the sensor and grille cover clean to ensure that the vehicle-tovehicle distance control operates properly. (Some obstructions, such as snow, ice and plastic objects, cannot be detected by the obstruction sensor.) Dynamic radar cruise control is canceled if an obstruction is detected.

- 1 Grille cover
- ② Radar sensor



■Warning messages and buzzers for dynamic radar cruise control

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving. (\rightarrow P. 636)

■ Certification



The latest "DECLARATION of CONFORMITY" (DoC) is available at the following address:

http://www.globaldenso.com/en/products/oem/index.html

Hereby, DENSO CORPORATION declares that this DNMWR004 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

DENSO CORPORATION vakuuttaa täten että DNMWR004 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart DENSO CORPORATION dat het toestel DNMWR004 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente DENSO CORPORATION déclare que l'appareil DNMWR004 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar DENSO CORPORATION att denna DNMWR004 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede DENSO CORPORATION erklærer herved, at følgende udstyr DNMWR004 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt DENSO CORPORATION, dass sich das Gerät DNMWR004 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ DENSO CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ DNMWR004 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ. Con la presente DENSO CORPORATION dichiara che questo DNMWR004 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente DENSO CORPORATION declara que el DNMWR004 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

DENSO CORPORATION declara que este DNMWR004 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, DENSO CORPORATION, jiddikjara li dan DNMWR004 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab DENSO CORPORATION seadme DNMWR004 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, DENSO CORPORATION nyilatkozom, hogy a DNMWR004 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

DENSO CORPORATION týmto vyhlasuje, že DNMWR004 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

DENSO CORPORATION tímto prohlašuje, že tento DNMWR004 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

DENSO CORPORATION izjavlja, da je ta DNMWR004 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo DENSO CORPORATION deklaruoja, kad šis DNMWR004 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo DENSO CORPORATION deklarē, ka DNMWR004 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym DENSO CORPORATION oświadcza, że DNMWR004 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

DENSO CORPORATION erklærer herved at utstyret DNMWR004 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, DENSO CORPORATION, декларира, че DNMWR004 е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, DENSO CORPORATION, declară că aparatul DNMWR004 este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim DENSO CORPORATION, izjavljuje da je DNMWR004 u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

CAUTION

■ Before using dynamic radar cruise control

Do not overly rely on vehicle-to-vehicle distance control.

Be aware of the set speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc.

Cautions regarding the driving assist systems

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

- Assisting the driver to measure following distance The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings.
- Assisting the driver to judge proper following distance The dynamic radar cruise control determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is appropriate or not. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.
- تلفن شبانه روزی Assisting the driver to operate the vehicle The dynamic radar cruise control has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.
- To avoid inadvertent cruise control activation Switch the cruise control off using the "ON-OFF" button when not in use.

A CAUTION

■ Situations unsuitable for dynamic radar cruise control

Do not use dynamic radar cruise control in any of the following situations.

Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- Roads where there are pedestrians, cyclers, etc.
- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On sharp inclines or declines Vehicle speed may exceed the set speed when driving down a steep hill.
- Roads with continuous inclines and declines
- At entrances to freeways and highways.
- When weather conditions are bad enough that they may prevent the sensors from detecting correctly (fog, snow, sandstorm, heavy rain, etc.)
- When an approach warning buzzer is heard often
- •When your vehicle is towing a trailer (with towing hitch) or during emergency towing

A CAUTION

■When the sensor may not be correctly detecting the vehicle ahead


In the case of the following and depending on the conditions, operate the brake pedal when deceleration of the system is insufficient or operate the accelerator pedal when acceleration is required.

As the sensor may not be able to correctly detect these types of vehicles, the approach warning (→P. 312) will not be activated, which may lead to an accident resulting in death or serious injury.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving in the same lane
- Vehicles with small rear ends (trailers with no load on board etc.)



- Motorcycles traveling in the same lane
- When water or snow thrown up by the surrounding vehicles hinders the detecting of the sensor



When the vehicle ahead of you decelerates suddenly

▲ CAUTION

Handling the radar sensor

Observe the following to ensure the cruise control system can function

Otherwise, the system may not function correctly and could result in an accident.

- Keep the sensor and grille cover clean at all times. Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the sensor needs to be replaced, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.


تلفن شبانه روزی: ۱۸۵۰ ۲۹۸۸

Toyota parking assist-sensor*

The distance from your vehicle to nearby obstacles when parallel parking or maneuvering into a garage is measured by the sensors and communicated via the indicator or displays, and a buzzer. Always check the surrounding area when using this system.

Types of sensors

- 1 Front corner sensors (if equipped)
- 2 Front center sensors (if equipped)
- 3 Rear corner sensors
- (4) Rear center sensors




Toyota parking assist-sensor switch

- 4 sensor type
- ▶ Left-hand drive

 $oldsymbol{\omega}_{-}$ تلفن شبانه روزی:





Turns Toyota parking assist-sensor on/off


When on, the indicator light come on and the buzzer sounds to inform the driver that the system is operational.

*: If equipped

■ 8 sensor type

played.


- 1 Display the Toyota parking assist-sensor on/off screen.
 - Press the menu switch.
 The multi-information display will change modes to electronic features control mode.
 - ② Press the "ENTER" switch upwards or downwards until the Toyota parking assist-sensor mark appears in the multi-information display.



Press the "ENTER" switch to change to "ON". The Toyota parking assistsensor indicator will be dis-

Each pressing of the switch turns the Toyota parking assist-sensor on and off.

When on, the buzzer sounds to inform the driver that the system is operational.



4


Driving

Press the menu switch to change to the normal display.

Display

When the sensors detect an obstacle, the following indicator or displays inform the driver of the position and distance to the obstacle.

- ► Toyota parking assist-sensor indicator (if equipped)
- 1 Vehicle indicator
- (2) Rear corner indicator
- 3 Rear center indicator



- ► Multi-information display (if equipped)
- 1 Front corner sensor operation (if equipped)
- ② Front center sensor operation (if equipped)
- 3 Rear corner sensor operation
- 4 Rear center sensor operation



- ▶ Navigation system or multimedia system screen (if equipped)
- 1 Toyota parking assist-sensor display

When the rear view monitor system*, Toyota parking assist monitor* or Multi-terrain Monitor* is not displayed.

A graphic is automatically displayed when an obstacle is detected. The screen can be set so that the graphic is not displayed. $(\rightarrow P. 330)$

2 Insert display

When the rear view monitor system*, Toyota parking assist monitor* or Multi-terrain Monitor* is displayed.

A simplified image is displayed on the upper corner of the screen when an obstacle is detected.



4

Driving

IID4PD079ME

*: If equipped

تلفن شبانه روزی: ۱-۸۸۸۶۲۰۸۵ تلفن شبانه روزی

Sensor detection display, obstacle distance

■ Distance display

Sensors that detect an obstacle will illuminate continuously or blink.

	Display	Insert display	Approximate distance to obstacle	
Indicator			Front corner sensor / front center sensor*1	Rear corner sen- sor / rear center sensor
(blinking slowly)	(continuous)	(blinking slowly)	Front center sensor: 100 cm (3.3 ft.) to 60 cm (2.0 ft.)	Rear center sensor: 150 cm (4.9 ft.) to 65 cm (2.1 ft.)
(blinking)	(continuous)	(blinking)	Front corner sensor: 50 cm (1.6 ft.) to 40 cm (1.3 ft.) Front center sensor: 60 cm (2.0 ft.) to 45 cm (1.5 ft.)	Rear corner sensor: 55 cm (1.8 ft.) to 37.5 cm (1.2 ft.) Rear center sensor: 65 cm (2.1 ft.) to 50 cm (1.6 ft.)
(blinking rapidly)	(continuous)	(blinking rapidly)	Front corner sensor: 40 cm (1.3 ft.) to 30 cm (1.0 ft.) Front center sensor: 45 cm (1.5 ft.) to 30 cm (1.0 ft.)	Rear corner sensor: 37.5 cm (1.2 ft.) to 25 cm (0.8 ft.) Rear center sensor: 50 cm (1.6 ft.) to 40 cm (1.3 ft.)
(continuous)	(blinking*2 or continuous*3)	(continuous)	Less than 30 cm (1.0 ft.)	Rear corner sensor: Less than 25 cm (0.8 ft.) Rear center sensor: Less than 40 cm (1.3 ft.)

*2: Multi-information display

*3: Navigation system or multimedia system screen

■ Buzzer operation and distance to an obstacle

A buzzer sounds when the sensors are operating.

- The buzzer sounds faster as the vehicle approaches an obstacle. When the vehicle comes within the following distance of the obstacle, the buzzer sounds continuously.
 - Front corner sensors: Approximately 30 cm (1.0 ft.)
 - Front center sensors: Approximately 30 cm (1.0 ft.)
 - Rear corner sensors: Approximately 25 cm (0.8 ft.)
 - Rear center sensors: Approximately 40 cm (1.3 ft.)
- When 2 or more obstacles are detected simultaneously, the buzzer system responds to the nearest obstacle. If one or both come within the above distances, the beep will repeat a long tone, followed by fast beeps.


Detection range of the sensors

- 1 Approximately 100 cm (3.3 ft.)
- 2 Approximately 150 cm (4.9 ft.)
- 3 Approximately 50 cm (1.6 ft.)
- 4) Approximately 55 cm (1.8 ft.)

The diagram shows the detection range of the sensors. Note that the sensors may not be able to detect obstacles that are extremely close to the vehicle.

The range of the sensors may change depending on the shape of the object etc.

*: If equipped



4

Driving

Setting up Toyota parking assist-sensor (vehicles with a navigation system or a multimedia system)

You can change the buzzer sound volume and the screen operating conditions.

- 1 Press the "SETUP" button.
- 2 Select "Vehicle" on the screen.
- 3 Select the desired item.
 - The buzzer sound volume can be adjusted.
 - On or off can be selected for Toyota parking assist-sensor display.
 - Front or rear center sensors display and tone indication can be set.

■ The Toyota parking assist-sensor can be operated when

- Front corner sensors:
 - The engine switch is in the "ON" position (vehicles without a smart entry & start system) or the engine switch is turned to IGNITION ON mode (vehicles with a smart entry & start system).
 - The shift lever is in a position other than P.
 - The vehicle speed is less than approximately 10 km/h (6 mph).
 (At any speed when the shift lever is in R)
- Front center sensors:
 - The engine switch is in the "ON" position (vehicles without a smart entry & start system) or the engine switch is turned to IGNITION ON mode (vehicles with a smart entry & start system).
 - The shift lever is in a position other than P or R.
- The vehicle speed is less than about 10 km/h (6 mph).
- Rear corner and rear center sensors:
 - The engine switch is in the "ON" position (vehicles without a smart entry & start system) or the engine switch is turned to IGNITION ON mode (vehicles with a smart entry & start system).
 - The shift lever is in R.

■ Toyota parking assist-sensor display

When an obstacle is detected while the Toyota parking assist monitor or Multi-terrain Monitor is in use, the warning indicator will appear in the top right or left of the screen even if the display setting has been set to off.

■ Sensor detection information

- The sensor's detection areas are limited to the areas around the vehicle's bumper.
- Certain vehicle conditions and the surrounding environment may affect the ability of a sensor to correctly detect an obstacle. Particular instances where this may occur are listed below.
 - There is dirt, snow or ice on the sensor. (Wiping the sensors will resolve this problem.)
 - The sensor is frozen. (Thawing the area will resolve this problem.)
 - · The sensor is covered in any way.
 - The vehicle is leaning considerably to one side.
 - · On an extremely bumpy road, on an incline, on gravel, or on grass.
 - The vicinity of the vehicle is noisy due to vehicle horns, motorcycle engines, air brakes of large vehicles, or other loud noises producing ultrasonic waves.
 - There is another vehicle equipped with parking assist sensors in the vicinity.
 - The sensor is coated with a sheet of spray or heavy rain.
 - · The vehicle is equipped with a fender pole or wireless antenna.
 - Towing eyelets are installed.
 - · The bumper or sensor receives a strong impact.
 - The vehicle is approaching a tall or curved curb.
 - · In harsh sunlight or intense cold weather.
 - The area directly under the bumpers is not detected.
 - · If obstacles draw too close to the sensor.
 - A non-genuine Toyota suspension (lowered suspension etc.) is installed.
 - When attaching a two-way radio (RF-transmitter) antenna.
 - People may not be detected if they are wearing certain types of clothing. In addition to the examples above, there are instances in which, because of their shape, signs and other objects may be judged by a sensor to be closer than they are.
- The shape of the obstacle may prevent a sensor from detecting it. Pay particular attention to the following obstacles:
 - · Wires, fences, ropes, etc.
 - · Cotton, snow and other materials that absorb sound waves
 - · Sharply-angled objects
 - · Low obstacles
 - Tall obstacles with upper sections projecting outwards in the direction of your vehicle

- The following situations may occur during use:
 - Depending on the shape of the obstacle and other factors, the detection distance may shorten, or detection may be impossible.
 - Obstacles may not be detected if they are too close to the sensor.
 - There will be a short delay between obstacle detection and indicator. Even at slow speeds, there is a possibility that the obstacle will come within the sensor's detection areas before the indicator comes on and the warning beep sounds.
 - Thin posts or objects lower than the sensor may not be detected when approached, even if they have been detected once.
 - · It might be difficult to hear beeps due to the volume of audio system or air flow noise of the air conditioning system.

■When the system malfunctions

- ▶ Vehicles with a Toyota parking assist-sensor indicator
- If the vehicle indicator remains on while the rear corner and rear center indicators flash and the malfunction beep sounds for approximately 8 seconds, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- If the vehicle indicator and the rear corner and rear center indicators flash and the malfunction beep sounds for approximately 8 seconds, clean the sensors with soft cloth.
- ▶ Vehicles with a navigation system or a multimedia system
- If N displays on the screen, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- If displays on the screen, clean the sensors with soft cloth.
- ▶ Vehicles with a multi-information display

A message is displayed on the multi-information display: →P. 636

Customization

Setting of buzzer volume can be changed. (Customizable features →P. 741)



CAUTION

■When using the Toyota parking assist-sensor

Observe the following precautions.

Failing to do so may result in the vehicle being unable to be driven safely and possibly cause an accident.

- Do not use the sensor at speeds in excess of 10 km/h (6 mph).
- The sensors' detection areas and reaction times are limited. When moving, check the areas surrounding the vehicle (especially the sides of the vehicle) for safety, and drive slowly, using the brake to control the vehicle's speed.
- Do not install accessories within the sensors' detection areas.

↑ NOTICE

■When using Toyota parking assist-sensor

In the following situations, the system may not function correctly due to a sensor malfunction etc. Have the vehicle checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

- A beep does not sound when you turn the Toyota parking assist-sensor on.
- If the area around a sensor collides with something, or is subjected to strong impact.
- If the bumper collides with something.
- ▶ With a Toyota parking assist-sensor indicator
- The rear corner and center indicators flash, and a beep sounds when no obstacles are detected.
- If the rear corner and center indicators show continuously without a beep.
- If a indicator error occurs, first check the sensor.
 If the error occurs even when there is no ice, snow or mud on the sensor, it is likely that the sensor is malfunctioning.
- ▶ Without a Toyota parking assist-sensor indicator
- The Toyota parking assist-sensor operation display flashes, and a beep sounds when no obstacles are detected.
- If the display shows continuously without a beep.
- If a display error occurs, first check the sensor. تلفن شباله و If the error occurs even when there is no ice, snow or mud on the sensor, it is likely that the sensor is malfunctioning.

■ Notes when washing the vehicle

Do not apply intensive bursts of water or steam to the sensor area. Doing so may result in the sensor malfunctioning.

Rear view monitor system*


The rear view monitor system assists the driver by displaying guide lines and an image of the view behind the vehicle while backing up, for example while parking.

The screen illustrations used in this text are intended as examples, and may differ from the image that is actually displayed on the screen.

The rear view monitor system will activate when the shift lever is in R

The rear view monitor system will be deactivated when the shift lever is in any position other than R.

When the shift lever is shifted to the R position and any mode button (such as "MENU") is pressed, the rear view monitor system is canceled, and the screen is switched to the mode of the button that was pressed.



FarmaS

*: If equipped


■ Screen description

▶ Vehicles without a smart entry & start system

The rear view monitor system screen will be displayed if the shift lever is shifted to R while the engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

The rear view monitor system screen will be displayed if the shift lever is shifted to R while the engine switch is in IGNITION ON mode.



1 Vehicle width extension guide line

The line indicates a guide path when the vehicle is being backed straight

The displayed width is wider than the actual vehicle width.

2 Vehicle center guide line

These lines indicate the estimated vehicle center on the ground.

3 Distance guide line (red)

The line shows distance behind the vehicle, a point approximately 0.5 m (1.5 ft.) from the edge of the bumper.

4 Distance guide line (blue)

The line shows distance behind the vehicle, a point approximately 1 m (3 ft.) from the edge of the bumper.

5 Toyota parking assist-sensor display (if equipped)

If an obstacle is detected while the Toyota parking assist-sensor is on, a display is shown at the top right corner of the screen.

4

Driving


Rear view monitor system precautions

■ Area displayed on screen

The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle.

The image on the rear view monitor system screen can be adjusted, refer to the "Navigation and multimedia system Owner's manual".


- The area displayed on the screen may vary according to vehicle orientation conditions.
- Objects which are close to either corner of the bumper or under the bumper cannot be displayed.
- The camera uses a special lens.
 The distance of the image that appears on the screen differs from the actual distance.




- Items which are located higher than the camera may not be displayed on the monitor.
- If your vehicle is equipped with a backlit license plate, it may interfere with the display.

■ Rear view monitor system camera

- Vehicles with back door mounted spare tire
- ► Vehicles with under floor mounted spare tire





Using the camera

If dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera, it cannot transmit a clear image. In this case, flush it with a large quantity of water and wipe the camera lens clean with a soft and wet cloth.

■ Differences between the screen and the actual road


The distance guide lines and the vehicle width extension guide lines may not actually be parallel with the dividing lines of the parking space, even when they appear to be so. Be sure to check visually.

The distances between the vehicle width extension guide lines and the left and right dividing lines of the parking space may not be equal, even when they appear to be so. Be sure to check visually.

The distance guide lines give a distance guide for flat road surfaces. In any of the following situations, there is a margin of error between the fixation guide lines on the screen and the actual distance/course on the road.

When the ground behind the vehicle slopes up sharply

The distance guide lines will appear to be closer to the vehicle than the actual distance. Because of this, objects will appear to be farther away than they actually are. In the same way, there will be a margin of error between the guide lines and the actual distance/course on the road.



IID4PD006EN


درو فارما



The distance guide lines will appear to be further from the vehicle than the actual distance. Because of this, objects will appear to be closer than they actually are. In the same way, there will be a margin of error between the guide lines and the actual distance/course on the road.



When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the fixation guide lines on the screen and the actual distance/course on the road.




■ When approaching three-dimensional objects

The distance guide lines are displayed according to flat surfaced objects (such as the road). It is not possible to determine the position of three-dimensional objects (such as vehicles) using the distance guide lines. When approaching a three-dimensional object that extends outward (such as the flatbed of a truck), be careful of the following.


Vehicle width extension guide lines

Visually check the surroundings and the area behind the vehicle. In the case shown in the illustration, the truck appears to be outside of the vehicle width extension guide lines and the vehicle does not look as if it hits the truck. However, the rear body of the truck may actually cross over the vehicle width extension guide lines. In reality if you back up as guided by the vehicle width extension guide lines, the vehicle may hit the truck.



Distance guide lines

Visually check the surroundings and the area behind the vehicle. On the screen, it appears that a truck is parking at point ②. However, in reality if you back up to point ①, you will hit the truck. On the screen, it appears that ① is closest and ③ is farthest away. However, in reality, the distance to ① and ③ is the same, and ② is farther than ① and ③.



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸ الان

Things you should know

■ If you notice any symptoms

If you notice any of the following symptoms, refer to the likely cause and the solution, and re-check.

If the symptom is not resolved by the solution, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Likely cause	Solution			
☐ The image is difficult to see				
 The vehicle is in a dark area The temperature around the lens is either high or low The outside temperature is low There are water droplets on the camera It is raining or humid Foreign matter (mud etc.) is adhering to the camera There are scratches on the camera Sunlight or headlights are shining directly into the camera The vehicle is under fluorescent lights, sodium lights, mercury lights etc. 	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings. (Use the monitor again once conditions have been improved.) The image on the rear view monitor system screen can be adjusted, refer to the "Navigation and multimedia system Owner's manual".			
☐ The image is blurry				
Dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera.	Flush the camera with a large quantity of water and wipe the camera lens clean with a soft and wet cloth.			
☐ The image is out of alignment				
The camera or surrounding area has received a strong impact.	Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.			

Likely cause	Solution			
☐ The fixed guide lines are very far out of alignment				
The camera position is out of alignment.	Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.			
 The vehicle is tilted (there is a heavy load on the vehicle, tire pressure is low due to a tire puncture, etc.) The vehicle is used on an incline. 	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings.			



تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ م

A CAUTION

■When using the rear view monitor system

The rear view monitor system is a supplemental device intended to assist the driver when backing up. When backing up, be sure to check visually behind and all around the vehicle before proceeding.

Observe the following precautions to avoid an accident that could result in death or serious injuries.

- Never depend on the rear view monitor system entirely when backing up. The image and the position of the guide lines displayed on the screen may differ from the actual state.
 - Use caution, just as you would when backing up any vehicle.
- Be sure to back up slowly, depressing the brake pedal to control vehicle speed.
- The instructions given are only guide lines. When and how much to turn the steering wheel will vary according to traffic conditions, road surface conditions, vehicle condition, etc. when parking. It is necessary to be fully aware of this before using the rear view monitor system.
- When parking, be sure to check that the parking space will accommodate your vehicle before maneuvering into it.
- Do not use the rear view monitor system in the following cases:
 - · On icy or slick road surfaces, or in snow
 - When using tire chains
 - When the back door is not closed completely
 - On roads that are not flat or straight, such as curves or slopes.
- In low temperatures, the screen may darken or the image may become faint. The image could distort when the vehicle is moving, or you may become unable to see the image on the screen. Be sure to check direct visually and with the mirrors all around the vehicle before proceeding.
- If the tire sizes are changed, the position of the fixed guide lines displayed on the screen may change.
- The camera uses a special lens. The distances between objects and pedestrians that appear in the image displayed on the screen will differ from the actual distances. (→P. 337)

↑ NOTICE

■ How to use the camera

- The rear view monitor system may not operate properly in the following cases.
 - If the back of the vehicle is hit, the position and mounting angle of the camera may change.
 - As the camera has a water proof construction, do not detach, disassemble or modify it. This may cause incorrect operation.
 - When cleaning the camera lens, flush the camera with a large quantity
 of water and wipe it with a soft and wet cloth. Strongly rubbing the camera lens may cause the camera lens to be scratched and unable to
 transmit a clear image.
 - Do not allow organic solvent, car wax, window cleaner or glass coat to adhere to the camera. If this happens, wipe it off as soon as possible.
 - If the temperature changes rapidly, such as when hot water is poured on the vehicle in cold weather, the system may not operate normally.
 - When washing the vehicle, do not apply intensive bursts of water to the camera or camera area. Doing so may result in the camera malfunctioning.
 - When the camera is used under fluorescent lights, sodium light or mercury light etc., the lights and the illuminated areas may appear to flicker.
- Do not expose the camera to strong impact as this could cause a malfunction. If this happens, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible.

The parking assist monitor assists the driver by displaying an image of the view behind the vehicle while backing up, for example while parking.

The parking assist monitor assists with the following 2 backing-up operations:

- Perpendicular parking (parking in a garage, etc.)
- Parallel parking (parking at the side of the road, etc.)


The screen illustrations used in this text are intended as examples, and may differ from the image that is actually displayed on the screen.

Parking assist monitor will activate when the shift lever is in R.

The parking assist monitor system will be deactivated when the shift lever is in any position other than R.

When the shift lever is shifted to the R position and any mode button (such as "MENU") is pressed, the parking assist monitor is canceled, and the screen is switched to the mode of the button that was pressed.

FarmaS₀



Using the Toyota parking assist monitor

■ Screen display

▶ Vehicles without a smart entry & start system

The rear view monitor system screen will be displayed if the shift lever is shifted to R while the engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

The parking assist monitor screen will be displayed if the shift lever is shifted to R while the engine switch is in IGNITION ON mode.

The parking assist monitor displays the last-used parking mode first.

Perpendicular parking

Parallel parking






- Display mode switch screen button Switches the display mode. (→P. 347)
- 2 Toyota parking assist-sensor display If an obstacle is detected while the Toyota parking assist-sensor is on, a display is shown in the top right corner of the screen.
- ③ Parking mode switch screen button Switches the parking mode (between perpendicular parking and parallel parking assist screens)
- ④ Narrow mode screen on-off button Switch the narrow mode on and off. (→P. 360)

تلفن شبانه روزی: ۲۰۸۵

■ Using the system when perpendicular parking

Use any of the following modes when perpendicular parking (for example, when parking in a garage).



Each time you select the display mode switch screen button, the display mode switches in the following order:

Estimated course line display mode

Parking assist guide line display mode

Distance guide line display mode



4

Driving

■ Estimated course line display mode (→P. 350)

Estimated course lines are displayed which move in accordance with the operation of the steering wheel.



■ Parking assist guide line display mode (→P. 352)

The steering wheel return points (parking assist guide lines) are displayed.




Distance guide line display mode

Distance guide lines only are displayed.



display Screen and beep sounds provide an estimation of the point at which you should turn the steering wheel when parallel parking. If the position the vehicle is to be parked in is narrower than usual, narrow mode can be used.




Each time you select the nar-

row mode screen on-off button, the narrow mode and the normal mode are switched.



■ Switching the parking mode screen

Each time you select the parking mode switch screen button, the perpendicular parking mode and parallel parking mode are switched.



IID4PD019EN

Perpendicular parking (estimated course line display mode)

■ Screen description



1 Vehicle width extension guide line

The line indicates a guide path when the vehicle is being backed straight up.

The displayed width is wider than the actual vehicle width.

The line aligns with the estimated course lines when the steering wheel is straight.

(2) Estimated course lines

The lines show an estimated course when the steering wheel is turned.

3 Distance guide line

The line moves, together with the estimated course lines, in sync with the steering wheel. The line shows points approximately 0.5 m (1.5 ft.) (red) and approximately 1 m (3 ft.) (yellow) from the center of the edge of the bumper.


4 Distance guide line

The line shows distance behind the vehicle, a point approximately 0.5 m (1.5 ft.) (blue) from the edge of the bumper.

When parking in a space which is in the reverse direction to the space described in the procedure below, the steering directions will be reversed.

- 1 Shift the shift lever to the R position.
- 2 Turn the steering wheel so that the estimated course lines are within the parking space, and back up slowly.
 - 1 Parking space
 - ② Estimated course lines

درو فارما




7

When the rear position of the vehicle has entered the parking space, turn the steering wheel so that the vehicle width extension guide lines are within the left and right dividing lines of the parking

③ Vehicle width extension guide line

space.



LC150_OM_OM60P18E_(EE)


4

Driving

- 4 Once the vehicle width extension guide lines and the parking space lines are parallel, straighten the steering wheel and back up slowly until the vehicle has completely entered the parking space.
- 5 Stop the vehicle in an appropriate place, and finish parking.

Perpendicular parking (parking assist guide line display mode)

■ Screen description



- ① Vehicle width extension guide lines These lines indicate a guide path when the vehicle is being backed straight up. The displayed width is wider than the actual vehicle width.
- Parking assist guide lines

 These lines indicate the path of the smallest turn possible behind the vehicle.

 These lines also indicate the approximate position of the steering
- wheel when parking.

 3 Distance guide line
 This line (red) indicates points approximately 0.5 m (1.5 ft.)


behind the rear bumper of your vehicle.


When parking in a space which is in the reverse direction to the space described in the procedure below, the steering directions will be reversed.

- 1 Shift the shift lever to the R position.
- 2 Back up until the parking assist guide line meets the edge of the left-hand dividing line of the parking space.

1 Parking assist guide line

2 Parking space dividing line








- 3 Turn the steering wheel all the way to the right, and back up slowly.
- 4 Once the vehicle is parallel with the parking space, straighten the steering wheel and back up slowly until the vehicle has completely entered the parking space.
- 5 Stop the vehicle in an appropriate place, and finish parking.

Parallel parking

■ Vehicle movement procedure




- 1 Approx. 1 m (3 ft.)
- ② Keeping parallel with the road, stop the vehicle leaving a gap of approximately 1 m (3 ft.) between your vehicle and the parked vehicle (Step 1 in "Parking operation").
- 3 Back up until the black and yellow vertical pole just overlaps the rear end of the parked vehicle. Then stop the vehicle (Step 4 in "Parking operation").
 - Leaving the vehicle stopped, move the steering wheel until the blue outline meets the desired parking space, and back up while keeping the steering wheel in that position (Step 5 in "Parking operation").
- 4 A curved blue line is displayed. Keep the steering wheel in the same position and back up until the curved blue line meets the right corner of the parking space (Step 7 in "Parking operation").
- (5) When it meets the right corner of the parking space, turn the steering wheel in the opposite direction as far as it will go (Step 8 in "Parking operation").
- 6 Keeping the steering wheel in that position, check your surroundings visually and using mirrors, and back up using the distance guide lines etc. as a reference (Step 9 in "Parking operation").
- (7) When the vehicle is approximately in the desired parking location, parallel parking assist is complete (Step 10) in "Parking operation").

The following example describes the procedure for pulling into a parking space on the right. For pulling into a parking space on the left, substitute left for right and vice versa in all steps.

- 1 Stop the vehicle in the position as described below, and straighten the steering wheel.
 - 1 Roughly half a vehicle's length
 - 2 Desired parking space
 - ③ Approx. 1 m (3 ft.)
 - (4) Parked vehicle
 - 5 Your vehicle

A position in which you are parallel with the road (or the side of the road), and in which there is approximately 1 m (3 ft.) of space between your vehicle and the parked vehicle


A position in which you are half a vehicle's length ahead of the parked vehicle



- 2 Shift the shift lever to the R position.
- 3 Make sure the monitor displays the part behind the rear tires of the parked vehicle, and select .

 If the area is not displayed, move the vehicle to forward.

- With the steering wheel straight, back up slowly to a position at which the black and yellow vertical pole just overlaps the rear end of the parked vehicle. Then stop the vehicle.
 - Black and yellow vertical pole
 - ② Back the vehicle up to here






تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱ ۰

- Turn the steering wheel with the vehicle stopped until the blue outline meets the desired parking space.
 - 1 Blue outline
 - 2 Black and yellow vertical pole
 - ③ Extended line

If the extended line from the blue outline is displayed, the parallel parking assist is operational.



درو فارما

4 Turn the steering wheel right

5 Black and yellow vertical pole

6 Blue outline




6 Keep the steering wheel in its current position and backing up.
When backing up, be careful not to hit any obstacles with the right front corner of your vehicle. Back the vehicle up slowly.

4

Driving

A curved blue line will appear on the screen. Keep the steering wheel in its current position and back up slowly. Stop when the curved blue line meets the corner of the desired parking space.

1 Curved blue line



درو فارما

- ② Back up keeping the steering wheel in its current position
- 3 Curved blue line
- 4 Curved blue line meets the corner here
 If you back up too quickly,

you may lose synchronization with the parallel parking assist.




- 8 Leaving the vehicle stopped, turn the steering wheel all the way to the left.
 - Be sure to turn the steering wheel only when the vehicle is stopped.
- 9 When the screen changes, keep the steering wheel in its current position and back up.
 - When backing up, be careful not to hit any obstacles with the right front corner of your vehicle. Back the vehicle up slowly.
- 10 When the vehicle is parallel with the road or the shoulder, straighten the steering wheel.
 - Check your surroundings visually and with the mirrors, then back up using the distance guide lines as a reference, and stop.
 - When the vehicle is approximately in the desired parking location, the parallel parking assist is complete.
- Parallel parking assist mode information
 - There is a possibility that parallel parking guidance may not be given when backing up at a very slow speed.
 - If the back door is opened during parallel parking guidance, the parallel parking assist will be interrupted and canceled. Stop the vehicle, shift the shift lever out of the R position, and restart the operation from the step 1.
- Canceling parallel parking assist Select تلفن شبانه روزی:
- Vehicles with Toyota parking assist-sensor
 - If Toyota parking assist-sensor detects an object while you attempt to park in a parking space on the left, the black and yellow vertical pole could be obscured by Toyota parking assist-sensor display. In this event, turn Toyota parking assist-sensor switch off (\rightarrow P. 324), and operate the vehicle while checking the safety of the surrounding area direct visually and with mirror. After the operation, turn the switch on.
- If the message "Steering wheel turned too far, please return." is displayed
 - The steering wheel has been turned too far, and the system cannot function. Return the steering wheel to its original position. If the message is displayed before the outline is positioned over the desired parking space, it is likely that the vehicle is too far away from the shoulder. Check that there is a gap of approximately 1 m (3 ft.) between your vehicle and the parked vehicle.

■ Narrow mode

If the position the vehicle is to be parked in is narrower than usual, narrow mode can be used.

- 1 Normal mode
- (2) Narrow mode

The engine switch is turned off when the parking assist monitor is canceled with narrow mode, the caution screen is displayed first when the parallel parking assist is selected next time.



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ۲ ۱

- Operating narrow mode
- 1 Select while in parallel parking assist mode.



- 2 Confirm the warning on the caution screen. If you agree, select "I Agree". To cancel narrow mode, select
- 3 When the system is switched to narrow mode, the indicator on



Select simple again to switch the system to the normal mode.





FarmaSOS.com

4

Driving


Toyota parking assist monitor precautions

■ Area displayed on screen

The parking assist monitor displays an image of the view from the bumper of the rear area of the vehicle.

The image on the rear view monitor system screen can be adjusted, refer to the "Navigation and multimedia system Owner's manual".


- The area displayed on the screen may vary according to vehicle orientation conditions.
- Objects which are close to either corner of the bumper or under the bumper cannot be seen on the screen.
- The camera uses a special lens.
 The distance of the image that appears on the screen differs from the actual distance.




- Items which are located higher than the camera may not be displayed on the monitor.
- If your vehicle is equipped with a backlit license plate, it may interfere with the display.

■ Toyota parking assist monitor camera

- Vehicles with back door mounted spare tire
- ➤ Vehicles with under floor mounted spare tire





Using the camera

If dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera, it cannot transmit a clear image. In this case, flush it with a large quantity of water and wipe the camera lens clean with a soft and wet cloth.

■ Differences between the screen and the actual road


The distance guide lines and the vehicle width extension guide lines may not actually be parallel with the dividing lines of the parking space, even when they appear to be so. Be sure to check visually.

The distances between the vehicle width extension guide lines and the left and right dividing lines of the parking space may not be equal, even when they appear to be so. Be sure to check visually.

The distance guide lines give a distance guide for flat road surfaces. In any of the following situations, there is a margin of error between the guide lines on the screen and the actual distance/course on the road.

When the ground behind the vehicle slopes up sharply

The distance guide lines will appear to be closer to the vehicle than the actual distance. Because of this, objects will appear to be farther away than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.








• When the ground behind the vehicle slopes down sharply

The distance guide lines will appear to be further from the vehicle than the actual distance. Because of this, objects will appear to be closer than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.



When any part of the vehicle sags

When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the guide lines on the screen and the actual distance/course on the road.




■ When approaching three-dimensional objects

The estimated course lines target a flat surfaced objects (such as the road). It is not possible to determine the position of three-dimensional objects (such as vehicles) using the estimated course lines and distance guide lines. When approaching a three-dimensional object that extends outward (such as the flatbed of a truck), be careful of the following.


Estimated course lines

Visually check the surroundings and the area behind the vehicle. In the case shown in the illustration, the truck appears to be outside of the estimated course lines and the vehicle does not look as if it hits the truck. However, the rear body of the truck may actually cross over the estimated course lines. In reality if you back up as guided by the estimated course lines, the vehicle may hit the truck.



Distance guidelines

Visually check the surroundings and the area behind the vehicle. On the screen, it appears that a truck is parking at point ②. However, in reality if you back up to point ①, you will hit the truck. On the screen, it appears that ① is closest and ③ is farthest away. However, in reality, the distance to ① and ③ is the same and ② is farther than ① and ③.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Things you should know

■ If you notice any symptoms

If you notice any of the following symptoms, refer to the likely cause and the solution, and re-check.

If the symptom is not resolved by the solution, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Likely cause	Solution	
☐ The image is difficult to see		
 The vehicle is in a dark area The temperature around the lens is either high or low The outside temperature is low There are water droplets on the camera It is raining or humid Foreign matter (mud etc.) is adhering to the camera There are scratches on the camera Sunlight or headlights are shining directly into the camera The vehicle is under fluorescent lights, sodium lights, mercury lights etc. 	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings. (Use the monitor again once conditions have been improved.) The image on the rear view monitor system screen can be adjusted, refer to the "Navigation and multimedia system Owner's manual".	
☐ The image is blurry		
Dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera.	Flush the camera with a large quantity of water and wipe the camera lens clean with a soft and wet cloth.	
☐ The image is out of alignment		
The camera or surrounding area has received a strong impact.	Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.	

Likely cause	Solution		
☐ The guide lines are very far out of alignment			
The camera position is out of alignment.	Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.		
The vehicle is tilted (there is a heavy load on the vehicle, tire pressure is low due to a tire puncture, etc.) The vehicle is used on an incline.	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings.		
☐ The estimated course lines move even though the steering wheel is straight			
There is a malfunction in the signals being output by the steering sensor.	Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.		
☐ Guide lines are not displayed			
The back door is open.	Close the back door. If this does not resolve the symptom, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.		
☐ "System is initializing." is displayed			
 The battery has been reinstalled. The steering wheel has been moved while the battery was being reinstalled. Battery power is low. The steering sensor has been reinstalled. There is a malfunction in the signals being output by the steering sensor. 	Stop the vehicle, and turn the steering wheel as far as it will go to the left and right. (Selecting "?" on the screen displays the operating procedure above.) If this does not resolve the symptom, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. On the system initialization screen, touch the "?" button to display the operating procedure.		

A CAUTION

■When using the Toyota parking assist monitor system

The parking assist monitor is a supplemental device intended to assist the driver when backing up. When backing up, be sure to check visually behind and all around the vehicle before proceeding.

Observe the following precautions to avoid an accident that could result in death or serious injuries.

- Never depend on the parking assist monitor entirely when backing up. The image and the position of the guide lines displayed on the screen may differ from the actual state.
 - Use caution, just as you would when backing up any vehicle.
- Be sure to back up slowly, depressing the brake pedal to control vehicle speed.
- If you seem likely to hit nearby vehicles, obstacles, people or mount the shoulder, depress the brake pedal to stop the vehicle, then disable the assist system by select on the screen to cancel the system.
- The instructions given are only guidelines. When and how much to turn the steering wheel will vary according to traffic conditions, road surface conditions, vehicle condition, etc. when parking. It is necessary to be fully aware of this before using the parking assist
- When parking, be sure to check that the parking space will accommodate your vehicle before maneuvering into it.
- Do not use the parking assist monitor in the following cases:
 - · On icy or slick road surfaces, or in snow
 - · When using tire chains
 - · When the back door is not closed completely
 - · On roads that are not flat or straight, such as curves or slopes.
- In low temperatures, the screen may darken or the image may become faint. The image could distort when the vehicle is moving, or you may become unable to see the image on the screen. Be sure to check direct visually and with the mirrors all around the vehicle before proceeding.

A CAUTION


- If the tire sizes are changed, the position of the guide lines displayed on the screen may change.
- The camera uses a special lens. The distances between objects and pedestrians that appear in the image displayed on the screen will differ from the actual distances. (→P. 363)

■ When using the perpendicular parking assist screen

Estimated course line display mode: If the steering wheel is straight and the vehicle width extension guide lines and the estimated course lines are not in alignment, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ When using the parallel parking assist screen

- Do not use the system if the display is incorrect due to an uneven (curvy/ hilly) road or a non-straight road.
- Make sure to operate the steering wheel only when the vehicle is stopped.
- Be sure to check that there are no obstacles inside the blue outline.
 If there are any obstacles inside the blue outline, do not use the parallel parking assist.
- When positioning the blue outline over the parking space, be sure to position it so that the extended blue line may not cross the tire of the vehicle parked in front of the empty space.
- If the extended line of the blue outline may be crossing the parked vehicle, your vehicle is too close. Check that there is a gap of approximately 1 m (3 ft.) between your vehicle and the parked vehicle.



■ How to use the camera

- The parking assist monitor may not operate properly in the following cases.
 - If the back of the vehicle is hit, the position and mounting angle of the camera may change.
 - As the camera has a water proof construction, do not detach, disassemble or modify it. This may cause incorrect operation.
 - When cleaning the camera lens, flush the camera with a large quantity
 of water and wipe it with a soft and wet cloth. Strongly rubbing the camera lens may cause the camera lens to be scratched and unable to
 transmit a clear image.
 - Do not allow organic solvent, car wax, window cleaner or glass coat to adhere to the camera. If this happens, wipe it off as soon as possible.
 - If the temperature changes rapidly, such as when hot water is poured on the vehicle in cold weather, the system may not operate normally.
 - When washing the vehicle, do not apply intensive bursts of water to the camera or camera area. Doing so may result in the camera malfunctioning.
 - When the camera is used under fluorescent lights, sodium light or mercury light etc., the lights and the illuminated areas may appear to flicker.
- Do not expose the camera to strong impact as this could cause a malfunction. If this happens, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible.

Driving assist systems

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

◆ Multi Terrain ABS (Anti-lock Brake System) (if equipped)

→Refer to the "Off-road Driving Owner's Manual"

Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

♦ VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces

◆ TRC (Traction Control) for 2TR-FE engines and H4 position on 1GR-FE, 1GD-FTV and 1KD-FTV engines

Helps to maintain drive power and prevent the 4 wheels from spinning when starting the vehicle or accelerating on slippery roads

- ◆ Active TRC (Traction Control) for L4 position on 1GR-FE, 1GD-FTV and 1KD-FTV engines*
 - →Refer to the "Off-road Driving Owner's Manual"

→Refer to the "Off-road Driving Owner's Manual"

◆ KDSS (Kinetic Dynamic Suspension System) (if equipped)

→Refer to the "Off-road Driving Owner's Manual"

PCS (Pre-Crash Safety system) (if equipped)

→P. 390

Emergency brake signal

When the brakes are applied suddenly, the stop lights automatically flash to alert the vehicle behind.

Trailer Sway Control (if equipped)


Helps the driver to control trailer sway by selectively applying brake pressure for individual wheels and reducing engine torque when trailer sway is detected.

Trailer Sway Control is part of the VSC system and will not operate if VSC turned off or experiences a malfunction.

*: The function only works in vehicles with Multi-terrain Select when Multi terrain Select is switched on

When the TRC/VSC/Trailer Sway Control systems are operating

If the vehicle is in danger of slipping or if any of the drive wheels spins, the slip indicator flashes to indicate that the TRC/VSC/Trailer Sway Control systems are operating.



4

Driving

Disabling the TRC/VSC/Trailer Sway Control systems


If the vehicle gets stuck in fresh snow or mud, the TRC/VSC/Trailer Sway Control systems may reduce power from the engine to the wheels. You may need to turn the system off to enable you to rock the vehicle in order to free it.

■ Turning off TRC system only

To turn the TRC system off, quickly press and release the switch.

The "TRC OFF" indicator light will come on.

Press the switch again to turn the system back on.




■ Turning off both TRC and VSC/Trailer Sway Control systems

To turn the TRC and VSC/ Trailer Sway Control systems off, press and hold the switch for 3 seconds and more while the vehicle is stopped.

The VSC OFF indicator light will come on and the "TRC OFF" indicator light will come on.

Press the switch again to turn the system back on.



Sounds and vibrations caused by the ABS, brake assist, TRC and VSC/ Trailer Sway Control systems

- A sound may be heard from the engine compartment when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
 - · Vibrations may be felt through the vehicle body and steering.
 - · A motor sound may be heard after the vehicle comes to a stop.
 - The brake pedal may pulsate slightly after the ABS is activated.
 - The brake pedal may move down slightly after the ABS is activated.

■ Reactivation of the TRC/VSC/Trailer Sway Control systems after turning off the engine

Turning off the engine after turning off the TRC/VSC/Trailer Sway Control systems will automatically re-enabled them.

■ Reactivation of the TRC system linked to vehicle speed

When only the TRC system is turned off, the TRC system will turn on when vehicle speed increases. However, when both TRC and VSC/Trailer Sway Control systems are turned off, the systems will not turn on even when vehicle speed increases.

■When the brake system operates continuously

The brake actuator may overheat. In this case, the TRC (vehicles other than 2TR-FE engines) will stop operating, a buzzer will sound and the "TRC OFF" indicator will come on. Refrain from using the system until the "TRC OFF" indicator turns off. (There is no problem with continuing normal driving.)

■ Operating conditions of emergency brake signal

When the following three conditions are met, the emergency brake signal will operate:

- The emergency flashers are off.
- Actual vehicle speed is over 55 km/h (35 mph).
- The brake pedal is depressed in a manner that cause the system to judge from the vehicle deceleration that this is a sudden braking operation.

■ Automatic system cancelation of emergency brake signal

The emergency brake signal will turn off in any of the following situations:

- The emergency flashers are turned on.
- The brake pedal is released.
- The system judges from the vehicle deceleration that is not a sudden braking operation.

■ If the slip indicator comes on...

It may indicate a malfunction in the TRC or VSC/Trailer Sway Control system. Consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ KDSS (if equipped)

Some difference of vehicle height between left and right side can appear. This does not indicate a malfunction in the KDSS system. For more information, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

A

CAUTION

■ The ABS does not operate effectively when

- The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
- The vehicle hydroplanes while driving at high speed on the wet or slick road

Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations:

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or roads with uneven surfaces

■ TRC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRC system is operating.

Do not drive the vehicle in conditions where stability and power may be lost.

■ When the VSC/Trailer Sway Control is activated

The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes.

■ When the TRC/VSC/Trailer Sway Control systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help ensure vehicle stability and driving force, do not turn the TRC/VSC/Trailer Sway Control systems off unless necessary.

▲ CAUTION

Replacing tires

Make sure that all tires are of the same size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS, TRC and VSC/Trailer Sway Control will not function correctly if different tires are installed on the vehicle.

Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for further information when replacing tires or wheels.

Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause the system to malfunction.

■ Trailer Sway Control precaution

The Trailer Sway Control system is not able to reduce trailer sway in all situations. Depending on many factors such as the conditions of the vehicle, trailer, road surface, and driving environment, the Trailer Sway Control system may not be effective. Refer to your trailer owner's manual for information on how to tow your trailer properly.

If trailer sway occurs

Observe the following precautions. Failing to do so may cause death or serious injury.

- Firmly grip the steering wheel. Steer straight ahead. Do not try to control trailer swaying by turning the steering wheel.
- Begin releasing the accelerator pedal immediately but very gradually to reduce speed.

Do not increase speed. Do not apply vehicle brakes.

If you make no extreme correction with the steering or brakes, your vehicle and trailer should stabilize. (→P. 241)


BSM (Blind Spot Monitor)*

Summary of the Blind Spot Monitor

The Blind Spot Monitor is a system that has 2 functions;

- The Blind Spot Monitor function
 Assists the driver in making the decision when changing lanes
- The Rear Crossing Traffic Alert function Assists the driver when backing up

These functions use same sensors.



FarmaSOS.com

*: If equipped

The Blind Spot Monitor system can be turned on/off on the multi-information display. When the system is set to on, the indicator illuminates in the meter. The Blind Spot Monitor function and the Rear Crossing Traffic Alert function are turned on/off simultaneously.

2 Outside rear view mirror indicators

Blind Spot Monitor function:

When a vehicle is detected in the blind spot, the outside rear view mirror indicator comes on while the turn signal lever is not operated. If the turn signal lever is operated toward the detected side, the outside rear view mirror indicator flashes.

Rear Crossing Traffic Alert function:

When a vehicle approaching from the right or left rear of the vehicle is detected, the outside rear view mirror indicators flash.

3 Rear Crossing Traffic Alert buzzer (Rear Crossing Traffic Alert function only)

When a vehicle approaching from the right or left rear of the vehicle is detected, a buzzer sounds from behind the rear seat.

4

Driving


تلفن شبانه روزى: ۱-۸۸۸۶۲ ۲۸۸ الفن

Turning the Blind Spot Monitor system on

- 1 Display the Blind Spot Monitor on/off screen.
 - Press the menu switch.
 The multi-information display will change modes to electronic features control mode.
 - ② Press the "ENTER" switch upwards or downwards until "BSM" appears in the multiinformation display.
- Press the "ENTER" switch to change to "ON". The Blind Spot Monitor indicator will be displayed.

Each pressing of the switch turns the Blind Spot Monitor on and off.
When on, the buzzer sounds to

When on, the buzzer sounds to inform the driver that the system is operational





Press the menu switch to change to the normal display.

■ The outside rear view mirror indicators visibility

When under strong sunlight, the outside rear view mirror indicator may be difficult to see.

■ Rear Crossing Traffic Alert buzzer hearing

Rear Crossing Traffic Alert function may be difficult to hear over loud noises such as high audio volume.

■When there is a malfunction in the Blind Spot Monitor

If a system malfunction is detected due to any of the following reasons, warning messages will be displayed: $(\rightarrow P. 639, 640)$

- There is a malfunction with the sensors
- The sensors have become dirty
- The outside temperature is extremely high or low
- The sensor voltage has become abnormal

■ Certification for the Blind Spot Monitor

► For vehicles sold in Ukraine type approval number: 10094.000966-13

الداد

تلفن شبانه روزي

FarmaSOS.com

4

Driving

▶ For vehicles sold in Europe

C € 0700

The latest "DECLARATION of CONFORMITY" (DoC) is available at the following:

DoC address:

http://continental.automotive-approvals.de/index.php?produkt=SRR2-A

CONTINENTAL tímto prohlašuje, že tento SRR2-A je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Undertegnede CONTINENTAL erklærer herved, at følgende udstyr SRR2-A overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt CONTINENTAL, dass sich das Gerät SRR2-A in Übereinstimmung mit den grundlegenden Anforderungen und den übrigeneinschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Käesolevaga kinnitab CONTINENTAL seadme SRR2-A vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Hereby, CONTINENTAL, declares that this SRR2-A is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Por medio de la presente CONTINENTAL declara que el SRR2-A cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ CONTINENTAL ΔΗΛΩΝΕΙ ΟΤΙ SRR2-Α ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Par la présente CONTINENTAL déclare que l'appareil SRR2-A est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Con la presente CONTINENTAL dichiara che questo SRR2-A è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Ar šo CONTINENTAL deklarē, ka SRR2-A atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Šiuo CONTINENTAL deklaruoja, kad šis SRR2-A atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Hawnhekk, CONTINENTAL, jiddikjara li dan SRR2-A jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Alulírott, CONTINENTAL nyilatkozom, hogy a SRR2-A megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Niniejszym CONTINENTAL oświadcza, że SRR2-A jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

CONTINENTAL declara que este SRR2-A está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

CONTINENTAL izjavlja, da je ta SRR2-A v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

CONTINENTAL týmto vyhlasuje, že SRR2-A spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

CONTINENTAL vakuuttaa täten että SRR2-A tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Härmed intygar CONTINENTAL att denna SRR2-A står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Hér með lýsir CONTINENTAL yfir því að SRR2-A er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

CONTINENTAL erklærer herved at utstyret SRR2-A er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, CONTINENTAL, декларира, че SRR2-A е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, CONTINENTAL, declară că aparatul SRR2-A este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

 $^{\prime\prime}$ Ovim , CONTINENTAL, izjavljuje da ovaj SRR2-A je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC. $^{\prime\prime}$

Ovim CONTINENTAL, izjavljuje da je SRR2-A u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi(NN25/2012)

4

Driving

FarmaSOS.com


تلفن شبانه روز<u>ی: ۱۸۸</u>

CAUTION

Handling the radar sensor

One Blind Spot Monitor sensor is installed inside the left and right side of the vehicle rear bumper respectively. Observe the following to ensure the Blind Spot Monitor can function correctly.

Keep the sensor and its surrounding area on the bumper clean at all times.



- Do not subject the sensor or surrounding area on the bumper to a strong impact. If the sensor moves even slightly off position, the system may malfunction and vehicles that enter the detection area may not be detected. If the sensor or surrounding area is subject to a strong impact, always have the area inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor or surrounding area on the bumper.
- Do not modify the sensor or surrounding area on the bumper.
- Do not paint the rear bumper any color other than an official Toyota color.
- If the sensor needs to be replaced, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

The Blind Spot Monitor function

The Blind Spot Monitor function uses radar sensors to detect vehicles that are traveling in an adjacent lane in the area that is not reflected in the outside rear view mirror (the blind spot), and advises the driver of the vehicles existence via the outside rear view mirror indicator.

The Blind Spot Monitor function detection areas


The areas that vehicles can be detected in are outlined below.

The range of the detection area extends to:

1 Approximately 3.5 m (11.5 ft.) from the side of the vehicle

> The first 0.5 m (1.6 ft.) from the side of the vehicle is not in the detection area

- (2) Approximately 3 m (9.8 ft.) from the rear bumper
- 3 Approximately 1 m (3.3 ft.) forward of the rear bumper



CAUTION

■ Cautions regarding the use of the system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Blind Spot Monitor function is a supplementary function which alerts the driver that a vehicle is present in the blind spot. Do not overly rely on the Blind Spot Monitor function. The function cannot judge if it is safe to change lanes, therefore over reliance could cause an accident resulting in death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

■ The Blind Spot Monitor function is operational when

- The Blind Spot Monitor system turned on.
- Vehicle speed is greater than approximately 16 km/h (10 mph).

■ The Blind Spot Monitor function will detect a vehicle when

- A vehicle in an adjacent lane overtakes your vehicle.
- Another vehicle enters the detection area when it changes lanes.

■ Conditions under which the Blind Spot Monitor function will not detect a vehicle

The Blind Spot Monitor function is not designed to detect the following types of vehicles and/or objects:

- Small motorcycles, bicycles, pedestrians etc.*
- Vehicles traveling in the opposite direction
- Guardrails, walls, signs, parked vehicles and similar stationary objects*
- Following vehicles that are in the same lane*
- Vehicles driving 2 lanes across from your vehicle*
- *: Depending on conditions, detection of a vehicle and/or object may occur.


Conditions under which the Blind Spot Monitor function may not function correctly

- The Blind Spot Monitor function may not detect vehicles correctly in the following conditions:
 - · During bad weather such as heavy rain, fog, snow etc.
 - When ice or mud etc. is attached to the rear bumper
 - When driving on a road surface that is wet due to rain, standing water etc.
 - When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area
 - When a vehicle is in the detection area from a stop and remains in the detection area as your vehicle accelerates
 - When driving up or down consecutive steep inclines, such as hills, a dip in the road etc.
 - When multiple vehicles approach with only a small gap between each vehicle
 - When vehicle lanes are wide, and the vehicle in the next lane is too far away from your vehicle
 - When the vehicle that enters the detection area is traveling at about the same speed as your vehicle
 - When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
 - · Directly after the Blind Spot Monitor system turned on
 - · When your vehicle is towing a trailer

- Instances of the Blind Spot Monitor function unnecessarily detecting a vehicle and/ or object may increase under the following conditions:
 - When there is only a short distance between your vehicle and a guardrail, wall etc.
 - When there is only a short distance between your vehicle and a following vehicle
 - When vehicle lanes are narrow and a vehicle driving 2 lanes across from your vehicle enters the detection area
 - When items such as a bicycle carrier are installed on the rear of the vehicle

The Rear Crossing Traffic Alert function

The Rear Crossing Traffic Alert functions when your vehicle is in reverse. It can detect other vehicles approaching from the right or left rear of the vehicle. It uses radar sensors to alert the driver of the other vehicle's existence through flashing the outside rear view mirror indicators and sounding a buzzer.



Approaching vehicles

2 Detection areas

A CAUTION

■ Cautions regarding the use of the system


The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Rear Crossing Traffic Alert function is only an assist and is not a replacement for careful driving. Driver must be careful when backing up, even when using Rear Crossing Traffic Alert function. The driver's own visual confirmation of behind you and your vehicle is necessary and be sure there are no pedestrians, other vehicles etc. before backing up. Failure to do so could cause death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

The Rear Crossing Traffic Alert function detection areas

The areas that vehicles can be detected in are outlined below.



To give the driver a more consistent time to react, the buzzer can alert for faster vehicles from farther away.

Example:

Approaching vehicle	Speed	Approximate alert distance
Fast	28 km/h (18 mph)	20 m (65 ft.)
Slow	8 km/h (5 mph)	5.5 m (18 ft.)

■ The Rear Crossing Traffic Alert function is operational when

- The Blind Spot Monitor system turned on.
- The shift lever is in R.
- Vehicle speed is less than approximately 8 km/h (5 mph).
- Approaching vehicle speed is between approximately 8 km/h (5 mph) and 28 km/h (18 mph).

The Rear Crossing Traffic Alert function is not designed to detect the following types of vehicles and/or objects.

- Small motorcycles, bicycles, pedestrians etc.*
- Vehicles approaching from directly behind
- Guardrails, walls, signs, parked vehicles and similar stationary objects*
- Vehicles moving away from your vehicle
- Vehicles approaching from the parking spaces next to your vehicle*
- Vehicles backing up in the parking space next to your vehicle*
- *: Depending on conditions, detection of a vehicle and/or object may occur.

■ Conditions under which the Rear Crossing Traffic Alert function may not function correctly

The Rear Crossing Traffic Alert function may not detect vehicles correctly in the following conditions:

- During bad weather such as heavy rain, fog, snow etc.
- When ice or mud etc. is attached to the rear bumper
- When multiple vehicles approach continuously
- Shallow angle parking
- When a vehicle is approaching at high speed
- When parking on a steep incline, such as hills, a dip in the road etc.
- Directly after the Blind Spot Monitor system turned on
- When your vehicle is towing a trailer
- When items such as a bicycle carrier are installed on the rear of the vehicle
- Directly after the engine is started with the Blind Spot Monitor system on
- When the sensors cannot detect vehicles because of obstacles



4

Driving

PCS (Pre-Crash Safety system)^{*}

When the radar sensor detects possibility of a frontal collision, the pre-crash safety system such as the brakes and seat belts are automatically engaged to lessen impact as well as vehicle damage.

Pre-crash seat belts (front seat belts only)

If the pre-crash sensor detects that a collision is unavoidable, the pre-crash safety system will retract the seat belt before the collision occurs.

The same will happen if the driver makes an emergency braking or loses control of the vehicle. $(\rightarrow P. 37)$

However, when the VSC system is disabled, the system will not operate in the event of skidding.

Pre-crash brake assist

Pre-crash braking (if equipped)


When there is a high possibility of a frontal collision, the system warns the driver using a warning light, warning display and buzzer. If the system determines that a collision is unavoidable, the brakes are automatically applied to reduce the collision speed. Pre-crash braking can be disabled using the pre-crash braking off switch.

AVS (Adaptive Variable Suspension System) control (if equipped)

When the system determines that there is a high possibility of a frontal collision, the AVS optimizes the damping effect. (→Refer to the "Off-road Driving Owner's Manual")

*: If equipped


- 1 Pre-crash braking disabled
- 2 Pre-crash braking enabled The "PCS" warning light turns on when pre-crash braking is disabled.



درو فارما

Radar sensor

The radar sensor detects vehicles or other obstacles on or near the road ahead and determines whether a collision is imminent based on the position, speed, and heading of the obstacles.



4

Driving

■The pre-crash safety system is operational when

- Pre-crash seat belts (situation 1):
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 30 km/h (19 mph).
 - The front occupants are wearing a seat belt.
- Pre-crash seat belts (situation 2):
 - Vehicle speed is greater than about 30 km/h (19 mph).
 - · The system detects sudden braking or skidding.
 - The front occupants are wearing a seat belt.
- Pre-crash brake assist:
 - Vehicle speed is greater than about 30 km/h (19 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 30 km/h (19 mph).
 - The brake pedal is depressed.
- Pre-crash braking (if equipped):
 - The pre-crash braking off switch is not pressed.
 - Vehicle speed is greater than about 15 km/h (10 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 15 km/h (10 mph).
- AVS (Adaptive Variable Suspension System) control (if equipped):
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 30 km/h (19 mph).

Conditions that may trigger the system even if there is no possibility of a collision

In any of the following situations where the frontal area of the radar sensor is interrupted, the radar sensor may detect possibility of a frontal collision and the system may be activated.

- When passing by an oncoming vehicle in a curve or a turn to the right or the left
- When rapidly approaching an obstacle ahead (e.g. preceding vehicle, toll gate barrier, etc.)
- When there is a structural object (billboard, low ceiling, fluorescent light, etc.) above the uphill road ahead
- When driving on a narrow road or through under a low overhead structure (bridge, tunnel, fly-under, etc.)
- When driving on an uneven road surface
- When there is a metal object, bump, or protrusion on the road surface
- When vehicle's front part is raised or lowered depending on loading conditions
- When the direction of radar sensor is misaligned by strong impact applied on an area around the radar sensor, etc.
- When there is an obstacle (guard rail, etc.) by the roadside at the entrance to a curve
- When the front of your vehicle is pointing upwards (caused by towing a trailer, during emergency towing or putting a heavy load in the luggage compartment etc.)

When the system is activated in the situations described above, there is also a possibility that the seat belts will retract quickly and the brakes may be applied with a force greater than normal. When the seat belt is locked in the restricted position, stop the vehicle in a safe place, release the seat belt and refasten it.

Situations in which the pre-crash safety system does not function properly

The system may not function effectively in situations such as the following:

- On roads with sharp bends or uneven surfaces
- If a vehicle suddenly moves in front of your vehicle, such as at an intersection
- If a vehicle suddenly cuts in front of your vehicle, such as when overtaking
- In inclement weather such as heavy rain, fog, snow or sand storms
- When your vehicle is skidding with the VSC system off
- When an extreme change in vehicle height occurs
- When the axis of the radar is out of adjustment

■ Automatic cancelation of pre-crash safety system

When a malfunction occurs due to sensor contaminations, etc. that results in the sensors being unable to detect obstacles, the pre-crash safety system will be automatically disabled. In this case, the system will not activate even if there is a collision possibility.

■ Obstacles not detected

The sensor cannot detect plastic obstacles such as traffic cones. There may also be occasions when the radar sensor cannot detect pedestrians, animals, bicycles, motorcycles, trees, or snowdrifts.

■When there is a malfunction in the system, or if the system is temporarily unusable

Warning lights and/or warning messages will turn on or flash. (→P. 626, 639)

■ Certification



The latest "DECLARATION of CONFORMITY" (DoC) is available at the following address: http://www.globaldenso.com/en/products/oem/index.html

Hereby, DENSO CORPORATION declares that this DNMWR004 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

DENSO CORPORATION vakuuttaa täten että DNMWR004 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart DENSO CORPORATION dat het toestel DNMWR004 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente DENSO CORPORATION déclare que l'appareil DNMWR004 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar DENSO CORPORATION att denna DNMWR004 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede DENSO CORPORATION erklærer herved, at følgende udstyr DNMWR004 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt DENSO CORPORATION, dass sich das Gerät DNMWR004 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ DENSO CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ DNMWR004 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ. Con la presente DENSO CORPORATION dichiara che questo DNMWR004 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente DENSO CORPORATION declara que el DNMWR004 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

DENSO CORPORATION declara que este DNMWR004 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, DENSO CORPORATION, jiddikjara li dan DNMWR004 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab DENSO CORPORATION seadme DNMWR004 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, DENSO CORPORATION nyilatkozom, hogy a DNMWR004 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

DENSO CORPORATION týmto vyhlasuje, že DNMWR004 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

DENSO CORPORATION tímto prohlašuje, že tento DNMWR004 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

DENSO CORPORATION izjavlja, da je ta DNMWR004 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo DENSO CORPORATION deklaruoja, kad šis DNMWR004 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo DENSO CORPORATION deklarē, ka DNMWR004 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym DENSO CORPORATION oświadcza, że DNMWR004 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

DENSO CORPORATION erklærer herved at utstyret DNMWR004 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, DENSO CORPORATION, декларира, че DNMWR004 е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, DENSO CORPORATION, declară că aparatul DNMWR004 este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim DENSO CORPORATION, izjavljuje da je DNMWR004 u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

A CAUTION

■Limitations of the pre-crash safety system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

Do not use the pre-crash safety system instead of normal braking operations under any circumstances. This system will not prevent collisions or lessen damage or injuries in all cases. Do not overly rely on this system. Failure to do so may cause an accident, resulting in death or serious injury. This system has been designed to help avoid and reduce the impact of collisions. However, the system operates differently depending on the situation $(\rightarrow P. 392, 393)$. As a result, the same level of performance may not be expected in all cases. Also, the pre-crash safety brakes may not operate if the driver is depressing the brake pedal or turning the steering wheel, as the system will determine such conditions as collision avoidance operations.

Cautions regarding the assist contents of the system

By means of alarms and brake control, the pre-crash safety system is intended to assist the driver in avoiding collisions through the process of LOOK-JUDGE-ACT. There are limits to the degree of assistance the system can provide, so please keep in mind the following important points.

- Assisting the driver in watching the road
 - The pre-crash safety system is only able to detect obstacles directly in front of the vehicle, and only within a limited range. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for the driver to pay close attention to the vehicle's surroundings.
- Assisting the driver in making correct judgment When attempting to estimate the possibility of a collision, the only data available to the pre-crash safety system is that from obstacles it has detected directly in front of the vehicle. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of collision in any given situation.
- Assisting the driver in taking action
 - The pre-crash safety system's braking assist feature is designed to help reduce the severity of a collision, and so only acts when the system has judged that a collision is unavoidable. This system is not capable of automatically avoiding a collision or bringing the vehicle to a stop safely without appropriate operations performed by the driver. For this reason, when encountering a dangerous situation the driver must take direct and immediate action in order to ensure the safety of all involved.

A CAUTION

When the sensor may not be correctly detecting the vehicle ahead Apply the brakes as necessary in any of the following situations.

- When water or snow thrown up by the surrounding vehicles hinders the functioning of the sensor
- When your vehicle is pointing upwards (caused by a heavy load in the luggage compartment etc.)
- Vehicles that cut in suddenly
- Vehicles with small rear ends (trailers with no load on board etc.)
- Motorcycles traveling in the same lane

Handling the radar sensor

Observe the following to ensure the pre-crash safety system can function effectively:

- Keep the sensor and front grille clean at all times.
 Clean the sensor and front grille with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may become inaccurate or malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the sensor needs to be replaced, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

Pre-winter preparations

- Use fluids that are appropriate to the prevailing outside temperatures.
 - Engine oil
 - · Engine coolant
 - · Washer fluid
- Have a service technician inspect the condition of the battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the rear tires.

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen.
 Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.

When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

When parking the vehicle (in the winter time or in the cold latitudes)

Park the vehicle and move the shift lever to P (automatic transmission) or 1 or R (manual transmission) without setting the parking brake. The parking brake may freeze up, preventing it from being released. If the vehicle is parked without setting the parking brake, make sure to block the wheels.


Failure to do so may be dangerous because it may cause the vehicle to move unexpectedly, possibly leading to an accident.

- For vehicles with an automatic transmission: If the vehicle is parked without setting the parking brake, confirm that the shift lever cannot be moved out of P*.
- *: The shift lever will be locked if it is attempted to be shifted from P to any other position without depressing the brake pedal. If the shift lever can be shifted from P, there may be a problem with the shift lock system. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

Selecting tire chains

Use the correct tire chain size when mounting the snow chains. Chain size is regulated for each tire size.

- ① Side chain (5 mm [0.20 in.] in diameter)
- ② Cross chain (6.3 mm [0.25 in.] in diameter)



Regulations on the use of tire chains

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

■ Tire chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location.
- Install tire chains on the rear tires. Do not install tire chains on the front tires.
- Install tire chains on rear tires as tightly as possible. Retighten chains after driving 0.5 - 1.0 km (1/4 - 1/2 mile).
- Install tire chains following the instructions provided with the tire chains.

A CAUTION

Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the specified size.
- Maintain the recommended level of air pressure.
- Do not drive at speeds in excess of the speed limit or the speed limit specified for the snow tires being used.
- Use snow tires on all, not just some wheels.

Driving with tire chains

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 50 km/h (30 mph), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.



Repairing or replacing snow tires (vehicles with the tire pressure warning system)

Request repairs or replacement of snow tires from Toyota dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

Fitting tire chains (vehicles with the tire pressure warning system)

The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.



4

Driving

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱۰



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

Audio system


5

5-1.	Basic Operations	5-6.	Using Bluetooth [®] devices
	Audio system types406		Bluetooth® audio/phone438
	Steering wheel audio switches407		Using the steering wheel switches443
	AUX port/USB port408		Registering a Bluetooth®
5-2.	Using the audio system		device444
	Optimal use of the audio	5-7.	"SETUP" menu
	system409		Using the "SETUP" menu
5-3.	Using the radio		("Bluetooth*" menu)445
	Radio operation411		Using the "SETUP" menu
5-4.	Playing an audio CD and		("TEL" menu)449
	MP3/WMA discs 1 5-8		
	CD player operation415	1ω	Operating a Bluetooth®
5-5.	Using an external device Listening to an iPod423		enabled portable player453
	Listening USB memory device	5-9.	Bluetooth [®] Phone
		7	Making a phone call455
		J 1	Receiving a phone call457
	osing the Nox port		Speaking on the phone458
		5-10	.Bluetooth [®]
			Bluetooth®460

^{*:} Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Audio system types*

- ▶ Vehicles with a navigation system or a multimedia system Refer to the "Navigation and multimedia system Owner's manual".
- ► Vehicles without a navigation system or a multimedia system CD player with AM/FM radio



This illustration is for left-hand drive vehicles. Some button positions are reversed for right-hand drive vehicles.

■Using cellular phones

Interference may be heard through the audio system's speakers if a cellular phone is being used inside or close to the vehicle while the audio system is operating.



■To prevent battery discharge

Do not leave the audio system on longer than necessary with the engine stopped.

■ To avoid damaging the audio system

Take care not to spill drinks or other fluids over the audio system.

*: If equipped


Steering wheel audio switches

Some audio features can be controlled using the switches on the steering wheel.

Operation may differ depending on the type of audio system or navigation system. For details, refer to the manual provided with the audio system or navigation system.

Operating the audio system using the steering wheel switches

- (1) Volume switch
 - · Increases/decreases volume
 - Press and hold: Continuously increases/decreases volume
- 2 Radio mode:
 - Press: Select a radio station
 - Press and hold: Seek up/ down



CD, MP3/WMA disc, Bluetooth[®], iPod or USB mode:

- · Press: Select a track/file/song
- Press and hold: Select a folder or album (MP3/WMA disc, Bluetooth[®] or USB)
- ③ "MODE" switch
 - · Turns the power on, selects audio source
 - Press and hold this switch to mute or pause the current operation. To cancel the mute or pause, press and hold the switch again.

A CAUTION

■ To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.

*: If equipped

AUX port/USB port


Connect an iPod, USB memory device or portable audio player to the AUX port/USB port as indicated below. Press the "MODE" button to select "iPod", "USB" or "AUX".

Connecting using the AUX port/USB port

■ iPod

Open the cover and connect an iPod using an iPod cable.

Turn on the power of the iPod if it is not turned on.



■ USB memory

Open the cover and connect the USB memory device.

Turn on the power of the USB memory device if it is not turned on.

■ Portable audio player

Open the cover and connect the portable audio player.

Turn on the power of the portable audio player if it is not turned on.



■ While driving

Do not connect a device or operate the device controls.

The sound quality, volume balance and ASL settings can be adjusted.


- ① Displays the "SETUP" menu/ Selecting the mode
- 2 Changes the following settings
 - Sound quality and volume balance

→P. 410

The sound quality and balance setting can be changed to produce the best sound.

Automatic Sound Levelizer

→P. 410



5

Audio system

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

Using the audio control function

■ Changing sound quality modes

- 1 Press the tune/scroll knob.
- 2 Turn the knob to select "Sound Setting".
- 3 Press the knob.
- Turn the knob as corresponds to the desired mode.

 "BASS", "TREBLE", "FADER", "BALANCE", or "ASL" can be selected.
- 5 Press the knob.

■ Adjusting sound quality

Turning the tune/scroll knob adjusts the level.

Sound quality mode	Mode displayed	Level	Turn to the left	Turn to the right
Bass*	"BASS"	-5 to 5	Low	High
Treble*	"TREBLE"	-5 to 5	LOW	riigii
Front/rear volume balance	"FADER"	F7 to R7	Shifts to rear	Shifts to front
Left/right volume balance	"BALANCE"	L7 to R7	Shifts to left ن سبانه روری	Shifts to right

^{*:} The sound quality level is adjusted individually in each audio mode.

Press the knob or	_	(BACK)	to return	to the	sound	setting
menu.		3 U	3.0	:Or	n	

■ Adjusting the Automatic Sound Levelizer (ASL)

When ASL is selected, turn the tune/scroll knob to change the amount of ASL.


"LOW", "MID", "HIGH", or "OFF" can be selected.

ASL automatically adjusts the volume and tone quality according to vehicle speed.

Press the knob or ____ (BACK) to return to the sound setting menu.

Radio operation

Press the "MODE" button until "AM" or "FM" is displayed.



- 1 AM/FM mode button
- ② Tune/scroll knob Press: AF/region code/TA mode setup Turn: Adjusting the frequency
- 3 Seeking the frequency
- 4 Station selectors
- 5 Displaying the station list (FM mode only)
- Power/volume knob
 Press: Turning the audio system on or off
 Turn: Adjusting the volume

Setting station presets

- 1 Search for the desired stations by turning the tune/scroll knob or pressing the "<" or ">" button of "SEEK TRACK".
- 2 Press and hold a desired station selector button until you hear a beep.

Using the station list

Updating the station list

1 Press — (LIST).

The station list will be displayed.

2 Press — (UPDATE) to update the list.

"Updating" is displayed while the searching is in process, and then available stations will be listed on the display.

To cancel the updating process, press — (BACK).

■ Selecting a station from the station list

1 Press — (LIST).

The station list will be displayed.

- 2 Turn the tune/scroll knob to select a station.
- 3 Press the knob to tune in the station.

To return to the previous display, press (BACK)

RDS (Radio Data System)

This feature allows your radio to receive station.

■ Listening to stations of the same network

- 1 Press the tune/scroll knob.
- 2 Turn the knob to "RADIO" and press the knob.
- 3 Turn the knob as corresponds to the desired mode: "FM AF" or "Region code".
- 4 Press the knob to select "ON" or "OFF".

FM AF ON mode:

The station among those of the same network with strong reception is selected.

Region code ON mode:

The station among those of the same network with strong reception and broadcasting the same program is selected.

Audio system

■ Traffic information

- 1 Press the tune/scroll knob.
- 2 Turn the knob to "RADIO" and press the knob.
- 3 Turn the knob to "FM TA" mode.
- 4 Press the knob to select "ON" or "OFF".

TP mode:

The system automatically switches to traffic information when a broadcast with a traffic information signal is received.

The station returns to the previous one when the traffic information ends.

TA mode:

The system automatically switches to traffic information when a broadcast with a traffic information signal is received. In FM modes, the system will be mute unless traffic information is being broadcast.

The audio system returns to the previous mode when the traffic information ends.

تلفن شبانه روزی: ۱۹۲۰ میلا - ۲۱ - ۲۱

■EON (Enhanced Other Network) system (for traffic announcement function)

If the RDS station (with EON data) you are listening to is not broadcasting a traffic information program and the audio system is in the TA (traffic announcement) mode, the radio will be switched automatically to a station broadcasting a traffic information program in the EON AF list when traffic information begins.

■ When the battery is disconnected

Stations presets are erased.

■ Reception sensitivity


- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- The radio antenna is mounted inside the rear quarter window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear quarter window.

ומנול צרופ טונו

تلفن شبانه روزى: ۱۵۸۰۲۹۸۸۸-۲۱

Audio system

Insert a disc, press the "MODE" button to begin listening to a CD.



- 1 Disc eject
- ② Changing the audio source/ playback
- 3 Tune/scroll knob Selecting a track/file
- 4 Selecting a track/file, fast-forwarding or rewinding
- (5) Random play or back button

- 6 Repeat play
- ↑ Selecting a folder (MP3/WMA discs only)
- 8 Displaying track/folder list
- 9 Displaying text message
- Power/volume knobPress: Turning the audio sys-

tem on or off
Turn: Adjusting the volume

Loading CDs or MP3 and WMA discs

Insert a disc.

Ejecting CDs or MP3 and WMA discs

Press and remove the disc.

Using the CD player

■ Selecting a track

Turn the tune/scroll knob or press the "<" or ">" button of "SEEK TRACK" to move up or down until the desired track number is displayed.

■ Selecting a track from a track list				
1 Press — (LIST).				
The track list will be displayed.				
2 Turn and press the tune/scroll knob to select a track.				
To return to the previous display, press (BACK).				
■ Fast-forwarding and rewinding tracks				
Press and hold the "<" or ">" button of "SEEK TRACK".				
■ Random play Press — (RDM).				
To cancel, press the button again.				
■ Repeat play				
Press (RPT).				
To cancel, press the button again.				
تلفن شبانه روزی: Switching the display				
Press (TEXT) to display or hide the CD title.				
If there are continuing texts, is displayed. Press and hold the button to display the remaining texts.				

Playing back MP3 and WMA discs						
■ Selecting folders one at a time						
Press (<folder) (folder="" or="">) to select the desired folder.</folder)>						
■ Selecting a folder and file from folder list						
1 Press (LIST).						
The folder list will be displayed. 2 Turn and press the tune/scroll knob to select a folder and a file.						
To return to the previous display, press (BACK).						
■ Returning to the first folder						
Press and hold (<folder) "="" "<"="" a="" beep.="" file="" hear="" knob="" or="" press="" scroll="" selecting="" the="" tune="" turn="" until="" you="">" button of "SEEK TRACK" to select the desired file.</folder)>						
■ Fast-forwarding and rewinding files						
Press and hold the "<" or ">" button of "SEEK TRACK". ■ Random play						
Pressing — (RDM) changes modes in the following order: Folder random→Disc random→Off						
Repeat play rmaSOS.com						
Pressing — (RPT) changes modes in the following order: File repeat→Folder repeat*→Off						
*: Available except when RDM (random play) is selected						
■ Switching the display						
Press (TEXT) to display or hide the album title.						
If there are continuing texts, \rightarrow is displayed. Press and hold the button to display the remaining texts.						

■ Display

Depending on the contents recorded, the characters may not be displayed properly or may not be displayed at all.

■ Error messages

If an error message is displayed, refer to the following table and take the appropriate measures. If the problem is not rectified, take the vehicle to any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Message	Cause	Correction procedures		
"CD CHECK"	The disc is dirty or damaged.The disc is inserted upside down.	Clean the disc. Insert the disc correctly.		
"ERROR"	There is a malfunction within the system.	Eject the disc.		
"WAIT"	Operation has stopped due to a high temperature inside the player.	Wait for a while and then press the "MODE" button. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer if the CD still cannot be played.		
"NO SUPPORT"	MP3/WMA files are not included in the CD.	Eject the disc.		

■ Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.









CDs with copy-protect features may not play correctly.

■CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected while the CD player is being used.

■ If a CD is left inside the CD player or in the ejected position for extended periods

The CD may be damaged and may not play properly.

■Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

■ MP3 and WMA files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards and to the media/formats recorded by them that can be used.

MP3 file compatibility

- Compatible standards MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)
- Compatible sampling frequencies MPEG1 LAYER3: 32, 44.1, 48 (kHz) MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)
- Compatible bit rates (compatible with VBR)
 MPEG1 LAYER3: 32—320 (kbps)
 MPEG2 LSF LAYER3: 8—160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural

WMA file compatibility

- Compatible standards WMA Ver. 7, 8, 9
- Compatible sampling frequencies
 32, 44.1, 48 (kHz)
- Compatible bit rates (only compatible with 2-channel playback)
 Ver. 7, 8: CBR 48—192 (kbps)
 Ver. 9: CBR 48—320 (kbps)

Compatible media

Media that can be used for MP3 and WMA playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible, depending on the status of the CD-R or CD-RW. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

Compatible disc formats

The following disc formats can be used.

- Disc formats: CD-ROM Mode 1 and Mode 2 CD-ROM XA Mode 2, Form 1 and Form 2
- File formats:ISO9660 Level 1, Level 2, (Romeo, Joliet)
 MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows.

- · Maximum directory hierarchy: 8 levels
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- Maximum number of files per disc: 255

File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

Multi-sessions

As the audio system is compatible with multi-sessions, it is possible to play discs that contain MP3 and WMA files. However, only the first session can be played.

ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title and artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3, 2.4 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

When a disc containing MP3 or WMA files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend you do not write in any files other than MP3 or WMA files or create any unnecessary folders.

If the discs contain a mixture of music data and MP3 or WMA format data, only music data can be played.

Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

Playback

- To play MP3 file with steady sound quality, we recommend a fixed bit rate of 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- When files other than MP3 or WMA files are recorded on a disc, it may take more time to recognize the disc and in some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S. and other countries.

FarmaSOS.com

5


Audio system



■ Discs and adapters that cannot be used

Do not use the following types of discs.

Also, do not use 8 cm (3 in.) disc adapters, DualDiscs or printable discs. Doing so may damage the player and/or the disc insert/eject function.



- Discs that have a diameter that is not 12 cm (4.7 in.).
- Low-quality or deformed discs.
- Discs with a transparent or translucent recording area.
- Discs that have tape, stickers or CD-R labels attached to them, or that have had the label peeled off.

■ Player precautions

Failure to follow the precautions below may result in serious damage to the discs or the player itself.

- Do not insert anything other than discs into the disc slot.
- Do not apply oil to the player.
- Store discs away from direct sunlight.
- Never try to disassemble any part of the player.

Audio system


Listening to an iPod

Connecting an iPod enables you to enjoy music from the vehicle speakers. Press the "MODE" button until "iPod" is displayed.

Connecting an iPod

→P. 408

Control panel



- ① Changing the audio source/ playback
- Tune/scroll knob
 Selecting an iPod menu/song
- 3 Selecting a song, fast-forwarding or rewinding
- 4 Random play or back button
- (5) Repeat play

- ⑥ iPod menu mode, playback
- Oisplaying song list
- 8 Displaying text message
- Power/volume knob
 Press: Turning the audio system on or off

Turn: Adjusting the volume

Selecting a play mode

- 1 Press (MENU) to select iPod menu mode.
- 2 Turning the tune/scroll knob clockwise changes the play mode in the following order:
 - "Playlists" \to "Artists" \to "Albums" \to "Songs" \to "Podcasts" \to "Genres" \to "Composers" \to "Audiobooks"
- 3 Press the knob to select the desired play mode.

■ Play mode list

Play mode	First selection	Second selection	Third selection	Fourth selection	
"Playlists" Playlists select		Songs select -		-	
"Artists"	Artists select	Albums select	Songs select	-	
"Albums"	Albums select	Songs select	-	-	
"Songs" Songs select		-	-	-	
"Podcasts"	Podcasts select	Episodes select	ىن شبان ه روزى	- تل	
"Genres"	Genre select	Artists select	Albums select	Songs select	
"Composers"	Composers select	Albums select	Songs select	1 -	
"Audiobooks"	Audiobooks select	Chapter select	-	-	

■ Selecting a list

- 1 Turn the tune/scroll knob to display the first selection list.
- 2 Press the knob to select the desired item and display the second selection list.
- Repeat the same procedure to select the desired item.

 To return to the previous selection list, press (BACK).

 Press (PLAY) to play the desired selection.

Turn the tune/scroll knob or press the "<" or ">" button of "SEEK TRACK" to select the desired song.

Selecting a song from the song list

1 Press — (LIST).

The song list will be displayed.

- 2 Turn the tune/scroll knob to select a song.
- 3 Press the knob to play the song.

To return to the previous display, press — (BACK).

Fast-forwarding and rewinding songs

Press and hold the "<" or ">" button of "SEEK TRACK".

Repeat play

Press (RPT)

To cancel, press the button again.

Random play

Pressing (RDM) changes modes in the following order:

Track random→Album random→Off

Switching the display

Press (TEXT) display or hide the album title

If there are continuing texts, | is displayed.

Press and hold the button to display the remaining texts.

5

Audio system

■About iPod



- "Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance.
- iPhone, iPod, iPod classic, iPod nano, iPod shuffle, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

■iPod functions

- When an iPod is connected and the audio source is changed to iPod mode, the iPod will resume play from the same point in which it was last used.
- Depending on the iPod that is connected to the system, certain functions may not be available. Disconnecting the device and reconnecting it once again may resolve some malfunctions.
- While connected to the system, the iPod cannot be operated with its own controls. It is necessary to use the controls of the vehicle's audio system instead.

■iPod problems

To resolve most problems encountered when using your iPod, disconnect your iPod from the vehicle iPod connection and reset it.

For instructions on how to reset your iPod, refer to your iPod Owner's Man-

■ Display

→P. 418

If an error message is displayed, refer to the following table and take the appropriate measures. If the problem is not rectified, take the vehicle to any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Message	Cause/Correction procedures		
"ERROR"	This indicates a problem in the iPod or its connection.		
"NO SONGS"	This indicates that there is no music data in the iPod.		
"NO PLAYLIST"	This indicates that some available songs are not found in a selected playlist.		
"UPDATE YOUR iPod"	This indicates that the version of the iPod is not compatible. Upgrade your iPod software to the latest version.		
וארול לונול טונו			

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

FarmaSOS.com

5

Audio system

■ Compatible models

The following iPod®, iPod nano®, iPod classic®, iPod touch® and iPhone® devices can be used with this system.

Made for

- iPod touch (5th generation)
- iPod touch (4th generation)
- iPod touch (3rd generation)
- iPod touch (1st generation)
- · iPod classic
- · iPod with video
- iPod nano (7th generation)
- iPod nano (6th generation)
- iPod nano (5th generation)
- iPod nano (4th generation)
- iPod nano (3rd generation)
- iPod nano (2nd generation)

- iPhone 4S

- · iPhone 3G
- iPhone

Depending on differences between models or software versions etc., some تلف ر شیانه روزی models might be incompatible with this system.

Items related to standards and limitations are as follows:

- Maximum number of lists in device: 9999
- Maximum number of songs in device: 65535
- Maximum number of songs per list: 65535

- iPod touch (2nd generation)

- iPod nano (1st generation)
- iPhone 5
- iPhone 4
- · iPhone 3GS

A CAUTION

■While driving

Do not connect iPod or operate the controls. Doing so may cause an accident, resulting in death or serious injury.

№ NOTICE

■ To prevent damage to iPod or its terminal

- Do not leave iPod in the vehicle. The temperature inside the vehicle may become high.
- Do not push down on or apply unnecessary pressure to the iPod while it is connected.
- Do not insert foreign objects into the port.

تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۱** ۲۸ تلفن شبانه روزی

Audio system


Listening USB memory device

Connecting a USB memory enables you to enjoy music from the vehicle speakers. Press the "MODE" button until "USB" is displayed.

Connecting a USB memory

→P. 408

Control panel



- 1) Changing the audio source/playback
- ② Tune/scroll knob Selecting a file
- ③ Selecting a song, fast-forwarding or rewinding
- 4 Random play or back button
- ⑤ Repeat play

- 6 Selecting a folder
- 7 Displaying folder list
- 8 Displaying text message
- 9 Power/volume knob

Press: Turning the audio system on or off

Turn: Adjusting the volume

Audio system

(FOLDER>) to select the

Selecting a file

Press and hold

Selecting a folder

desired folder.

1 Press — (LIST).

■ Selecting folders one at a time

The folder list will be displayed.

■ Returning to the first folder

— (<FOLDER) or

■ Selecting a folder and file from folder list

Turn the tune/scroll knob or press the "<" or ">" button of "SEEK TRACK" to select the desired file.

2 Turn and press the tune/scroll knob to select a folder and file.

تلفن شبانه روزی: ۱۵۸۰۲۶۸۸۸–۲۱

Fast-forwarding and rewinding files Press and hold the "<" or ">" button of "SEEK TRACK". Random play Pressing — (RDM) changes modes in the following order: Folder random→All folder random→Off Repeat play Pressing — (RPT) changes modes in the following order: File repeat→Folder repeat*→Off *: Available except when RDM (random play) is selected Switching the display Press — (TEXT) to display or hide the album title. If there are continuing texts, ▶ is displayed.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Press and hold the button to display the remaining texts.

■USB memory functions

- Depending on the USB memory that is connected to the system, the device itself may not be operable and certain functions may not be available. If the device is inoperable or a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it once again may resolve the problem.
- If the USB memory still does not begin operation after being disconnected and reconnected, format the memory.

■ Display

→P. 418

■ Error messages

If an error message is displayed, refer to the following table and take the appropriate measures. If the problem is not rectified, take the vehicle to any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Message	Cause/Correction procedures
"ERROR"	This indicates a problem in the USB memory or its connection.
"NO MUSIC"	This indicates that no MP3/WMA files are included in the USB memory.

تلفن شبانه روزی: ۸۵ • ۲۶۸.

■USB memory

Compatible devices

USB memory that can be used for MP3 and WMA playback

Compatible device formats

The following device formats can be used:

- USB communication formats: USB2.0 FS (12mbps)
- File formats: FAT12/16/32 (Windows)
- · Correspondence class: Mass storage class

MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- · Maximum directory hierarchy: 8 levels
- Maximum number of folders in a device: 999 (including the root)
- · Maximum number of files in a device: 9999
- Maximum number of files per folder: 255

MP3 and WMA files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards and to the media/formats recorded by them that can be used.

MP3 file compatibility

 Compatible standards MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)

Compatible sampling frequencies
 MPEG1 LAYER3: 32, 44.1, 48 (kHz)
 MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)

 Compatible bit rates (compatible with VBR) MPEG1 LAYER3: 32—320 (kbps) MPEG2 LSF LAYER3: 8—160 (kbps)

 Compatible channel modes: stereo, joint stereo, dual channel and monaural

WMA file compatibility

- Compatible standards WMA Ver. 7, 8, 9
- Compatible sampling frequencies
 32, 44.1, 48 (kHz)
- Compatible bit rates (only compatible with 2-channel playback)
 Ver. 7, 8: CBR 48—192 (kbps)
 Ver. 9: CBR 48—320 (kbps)

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3, 2.4 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

MP3 and WMA playback

- · When a device containing MP3 or WMA files is connected, all files in the USB memory device are checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend that you do not include any files other than MP3 or WMA files or create any unnecessary folders.
- · When the USB device is connected and the audio source is changed to USB memory mode, the USB device will start playing the first file in the first folder. If the same device is removed and reinserted (and the contents have not been changed), the USB memory will resume play from the same point in which it was last used.

Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be skipped (not played). تلفن شبانه روزي

FarmaSOS.com

Audio system

Playback

- · To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- · Microsoft, Windows, and Windows Media are registered trademarks of Microsoft Corporation in the U.S.A. and other countries.



CAUTION

While driving

Do not connect USB memory or operate the controls. Doing so may cause an accident, resulting in death or serious injury.

NOTICE

■ To prevent damage to USB memory or its terminal

- Do not leave USB memory in the vehicle. The temperature inside the vehicle may become high.
- Do not push down on or apply unnecessary pressure to the USB memory while it is connected.
- Do not insert foreign objects into the port.

تلفن شبانه روزی:

This port can be used to connect a portable audio device and listen to it using the vehicle's speakers. Press the "MODE" button until "AUX" is displayed.

Connecting a portable player

→P. 408

- Operating portable audio devices connected to the audio system

 The volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio device itself.
- When using a portable audio device connected to the power outlet

 Noise may occur during playback. Use the power source of the portable audio device.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ – ۲۱

FarmaSOS.com

5

Audio system

Bluetooth® audio/phone*

The following can be performed using Bluetooth® wireless communication:

◆ Bluetooth[®] audio

The Bluetooth[®] audio system enables you to enjoy music played on a portable digital audio player (portable player) from the vehicle speakers via wireless communication.

This audio system supports Bluetooth[®], a wireless data system capable of playing portable audio music without cables. If your portable player does not support Bluetooth[®], the Bluetooth[®] audio system will not function.

◆ Bluetooth® phone (hands-free phone system)

This system supports Bluetooth[®], which allows you to make or receive calls without using cables to connect a cellular phone and the system, and without operating the cellular phone.

تلفن شبانه روزى: ۱۵۸۰۲۰۸۸ - ۲۱

Device registration/connection flow

1. Register the Bluetooth[®] device to be used with audio system (→P. 444)



2. Connect the registered Bluetooth[®] device to be used (→P. 445, 446)



3. Set automatic connection of the device (→P. 447)



4. Check Bluetooth[®] connection condition (→P. 440)

To be used for audio

To be used for hands-free phone



5. Use Bluetooth[®] audio (→P. 453)

5. Use Bluetooth[®] phone (→P. 455)

Audio unit


1 Power/volume knob Press: Turning the audio sys-

tem on or off

Turn: Adjusting the volume

Bluetooth[®] connection condition

If "BT" is not displayed, the Bluetooth $^{\circledR}$ audio/phone cannot be used.



3 Display

A message, name, number, etc. is displayed.

Lower-case characters and special characters may not be displayed.

4 Tune/scroll knob

Displays set up menu or selects items such as menu and number

Turn: Selects an item

Press: Displays set up menu or inputs the selected item

- (5) Selects speed dials (Bluetooth® phone operation)
- 6 On-hook switch

تلفن شبانه روزی: ۸۵ off/ends a call/refuses a call


Turns the hands-free system off/ends a call/refuses a call

(7) Off-hook switch

Turns the hands-free system on/starts a call

8 Press and hold: Displays information that is too long to be displayed at one time on the display (Bluetooth® audio operation)

Microphone



Menu list of the Bluetooth® audio/phone

To enter a menu, press the tune/scroll knob and navigate menus by using the knob.

First menu	Second menu	Third menu	Operation details
	"Pairing"	-	Registering a Bluetooth® device
	"List phone"	-	Listing the registered cellular phones
"Bluetooth*"	"List audio"	-	Listing the registered portable players
	"Passkey"	-	Changing the pass- key
	"BT Power"	393	Setting automatic connection of the device on or off
	"Bluetooth* info"	"Device name" "Device address"	Displaying the device status
+ 7	"Display setting"	ه روزی : ٔ ۸۵ + '	Setting the automatic connection confirmation display to on or off
	"Initialize"	-	Initializing the set- tings

^{*:} Bluetooth is a registered trademark of Bluetooth SIG, Inc.

First menu	Second menu	Third menu	Operation details
		"Add contacts"	Adding a new number
"TEL"	"Phonebook"	"Add SD"	Registering a speed dial
		"Delete call history"	Deleting a number stored in the call history
		"Delete contacts"	Deleting a number stored in the phone-book
		"Delete other PB"	Deleting a phone-book's data
		"Call volume"	Setting call volume
"HF sound setting"		"Ringtone volume"	Setting ring tone vol- ume
		"Ringtone"	Setting the ring tone
	"Transfer histories"	-	Transferring the call histories


■ Bluetooth® audio/phone system functions

Depending on the Bluetooth® device, certain functions may not be available.

The steering wheel switches can be used to operate a connected cellular phone, or portable digital audio player (portable player).

Operating Bluetooth® phone using the steering wheel switches

- Volume
 The voice guidance volume cannot be adjusted using this button.
- ② On-hook switch
 Turns the hands-free system
 off/ends a call/refuse a call
- ③ Off-hook switch Turns the hands-free system on/start a call



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

Registering a Bluetooth® device

Before using the Bluetooth[®] audio/phone, it is necessary to register a Bluetooth[®] device in the system. You can register up to 5 Bluetooth[®] devices.

How to register a Bluetooth® device

- 1 Press the tune/scroll knob and select "Bluetooth*" using the knob.
- 2 Press the knob and select "Pairing" using the knob.
 A passkey will be displayed.
- 3 SSP (Secure Simple Pairing) incompatible Bluetooth[®] devices: Input the passkey into the device.

 SSP (Secure Simple Pairing) compatible Bluetooth[®] devices: Select "YES" to register the device. Depending on the type of device, it may register automatically.

If a Bluetooth[®] device has both music player and cellular phone functions, both functions will be registered at the same time. When deleting the device, both functions will be deleted at the same time.

If the off-hook switch is pressed and the "TEL" mode is entered when no phones have been registered, the registration screen will be automatically displayed.

^{*:} Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Audio system

Using the "SETUP" menu ("Bluetooth*" menu)

Registering a Bluetooth[®] device in the system allows the system to function. The following functions can be used for registered devices:

Registering a portable player

Select "Pairing" using the tune/scroll knob (\rightarrow P. 441), and perform the procedure for registering a portable player. (\rightarrow P. 444)

Listing the registered cellular phones

Select "List Phone" using the tune/scroll knob. (→P. 441) The list of registered cellular phones will be displayed.

- Connecting the registered cellular phone to the audio system
- 1 Select the name of the cellular phone to be connected using the tune/scroll knob.
- 2 Select "Select" using the knob.
- Deleting a registered cellular phone
- 1 Select the name of the cellular phone to be deleted using the tune/scroll knob.
- 2 Select "Delete" using the knob.
- 3 Press (YES).
- Disconnecting the registered cellular phone from the audio system
- 1 Select the name of the cellular phone to be disconnected using the tune/scroll knob.
- 2 Select "Disconnect" using the knob.
- 3 Press (YES).

^{*:} Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Listing the registered portable players

Select "List Audio" using the tune/scroll knob. (\rightarrow P. 441) The list of registered portable players will be displayed.

- Connecting the registered portable player to the audio system
- 1 Select the name of the portable player to be connected using the tune/scroll knob.
- 2 Select "Select" using the knob.
- Deleting the registered portable player
- 1 Select the name of the portable player to be deleted using the tune/scroll knob.
- 2 Select "Delete" using the knob.
- 3 Press (YES).
- Disconnecting the registered portable player from the audio system
- 1 Select the name of the portable player to be disconnected using the tune/scroll knob.
- 2 Select "Disconnect" using the knob.
- 3 Press (YES).
- تلفن شبائه روزی: ۵ Selecting the connection method
- 1 Select the name of the desired portable player using the tune/ scroll knob.
- 2 Select "Connection method" using the knob.
- 3 Select "From vehicle" or "From audio" using the knob.

Changing the passkey

- Select "Passkey" using the tune/scroll knob. (→P. 441)
- 2 Select a 4 to 8-digit passkey using the knob. Input the number 1 digit at a time.
- 3 When the entire number to be registered as a passkey has been input, press (ENTER).

If the passkey to be registered has 8 digits, pressing ____ (ENTER) is not necessary.

Setting automatic connection of the device on or off

If "BT Power" is set to on, the registered device will be connected automatically when the engine switch is turned to the "ACC" position (vehicles without a smart entry & start system) or ACCESSORY mode (vehicles with a smart entry & start system).

- 1 Select "BT Power" using the tune/scroll knob. (→P. 441)
- 2 Select "ON" or "OFF" using the knob.

Displaying the device status

Select "Bluetooth* info" using the tune/scroll knob. (→P. 441)

- Displaying the device name
 Select "Device name" using the tune/scroll knob.
- Displaying the device address
 Select "Device address" using the tune/scroll knob.

Setting the automatic connection confirmation display to on or off

If the "Display setting" is set to on, the portable player connection status will be displayed when the engine switch is turned to the "ACC" or "ON" position (vehicles without a smart entry & start system) or ACCESSORY or IGNITION ON mode (vehicles with a smart entry & start system).

- 1 Select "Display setting" using the tune/scroll knob. (→P. 441)
- 2 Select "ON" or "OFF" using the knob.

^{*:} Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Initialization

Select "Initialize" using the tune/scroll knob. (→P. 441)

Initializing the sound settings

Select "Sound setting" using the tune/scroll knob and press — (YES).

For details about sound settings: \rightarrow P. 409

Initializing the device information

Select "Car device info" using the tune/scroll knob and press — (YES).

Automatic connection of a portable device, automatic connection confirmation display and the passkey will be initialized.

Initializing the all settings

Select "All initialize" using the tune/scroll knob and press — (YES).

تلفن شبانه روزی: ۱۹۲۰ میلار - ۲۱ - ۲۱

[1] to

Using the "SETUP" menu ("TEL" menu)

Adding a new phone number Select "Add contacts" using the tune/scroll knob. (→P. 441) Transferring all contacts from the cellular phone Select "Overwrite all" using the tune/scroll knob and press — (YES). Transferring one contact from the cellular phone Select "Add one contact" using the tune/scroll knob and press — (YES). Setting speed dials Select "Add SD" using the tune/scroll knob. (→P. 441) Select the desired data using the knob.

Deleting call histories

Select "Delete call history" using the tune/scroll knob. (→P. 441)

For details about setting speed dials from the call history: →P. 456

Deleting outgoing call history

3 Press the desired preset button (from -

For details about deleting speed dials: →P. 455

- 1 Select "Outgoing Calls" using the tune/scroll knob.
- 2 Select the desired phone number using the knob and press (YES).

To delete all outgoing call history data, press — (ALL) and then press — (YES).

Deleting incoming call history
Select "Incoming Calls" using the tune/scroll knob.
2 Select the desired phone number using the knob and press
— (YES).
To delete all incoming call history data, press (ALL) and then
press (YES).
Deleting missed call history
Select "Missed Calls" using the tune/scroll knob.
2 Select the desired phone number using the knob and press
(YES).
To delete all missed call history data, press — (ALL) and then
press (YES).
 Deleting a number from all call histories (Outgoing calls, Incoming calls and Missed calls)
Select "All Calls" using the tune/scroll knob.
2 Select the desired phone number using the knob and press
— (YES).
To delete all of the call histories data, press (ALL) and then
press (YES). 12SOS COM

Deleting a registered phone number

- Select "Delete contacts" using the tune/scroll knob. (→P. 441)
- 2 Select the desired phone number using the knob and press (YES).

To delete all the registered phone numbers, press — (ALL) and then press — (YES).

Press — (A-Z) to display the registered names in alphabetical order of the initial.

Deleting another cellular phone's phonebook

- Select "Delete other PB" using the tune/scroll knob. (→P. 441)
- 2 Select the desired phonebook using the knob and press (YES).

Setting call volume

- 1 Select "Call volume" using the tune/scroll knob. (→P. 441)
- 2 Change the call volume.

To decrease the volume: Turn the knob counterclockwise.

To increase the volume: Turn the knob clockwise.

To set the volume, press ____ (BACK).

Setting	ring	tone	VΩ	lume
Setting	IIIIg	tone	VU	lullle

- 1 Select "Ringtone volume" using the tune/scroll knob. (→P. 441)
- 2 Change the ring tone volume.

To decrease the volume: Turn the knob counterclockwise.

To increase the volume: Turn the knob clockwise.

To set the volume, press (BACK).

Setting ring tone

- Select "Ringtone" using the tune/scroll knob. (→P. 441)
- 2 Using the knob, select a ring tone (1 3). To set the selected ring tone, press (BACK).

Transferring call histories

Select "Transfer histories" using the tune/scroll knob (\rightarrow P. 441) and press $\boxed{\ }$ (YES).

■ Phone number

Up to 1000 names can be stored.

■ Call history


Up to 10 numbers can be stored in each of the outgoing, incoming and missed call history memories.

 Δ :تلفن شیانه روزی

■ Limitation of number of digits

A phone number that exceeds 24 digits cannot be registered.

Operating a Bluetooth[®] enabled portable player



- 1) Changing the audio source/ playback
- ② Selecting a track, fast-forward-ing or rewinding
- 3 Random play or back button
- 4 Repeat play

- Selecting an album
- ⑥ Playback/pause
- O Displaying text message
- 8 Power/volume knob

Press: Turning the audio sys-

tem on or off

Turn: Adjusting the volume

FarmaSOS.com

5

Audio system

Selecting an album		
Press (<folder) (folder="" or="">) to select desired album.</folder)>		
Selecting a track		
Press the "<" or ">" button of "SEEK TRACK" to select the desired track.		
Fast-forwarding and rewinding tracks		
Press and hold the "<" or ">" button of "SEEK TRACK".		
Repeat play		
Pressing — (RPT) changes modes in the following order: Track repeat→Album repeat→Off Random play		
ixandom piay		
Pressing — (RDM) changes modes in the following order: Album random→All track random→Off		
Playing and pausing tracks ۱۰۸۵ : دوزی: کام		
Press (▶).		
Switching the display		
Press (TEXT) to display or hide the album title.		
If there are continuing texts, 🕨 is displayed.		
Press and hold the button to display the remaining texts.		
 ■ Bluetooth® audio system functions Depending on the portable player that is connected to the system, certain functions may not be available. ■ Display →P. 418 		

Making a phone call

To enter the "TEL" mode, press the off-hook switch.

Dialing by selecting a name

- 1 Select "Phonebook" using the tune/scroll knob.
- 2 Select the desired name using the knob and press the off-hook switch.

By pressing ____ (Add S. Dial) and one of the speed dial buttons (from ____ [1] to ____ [5]) while the desired name is selected, it can be registered as a speed dial.

Press (A-Z) to display the registered names in alphabetical order of the initial.

Speed dialing

- 1 Select "Speed dials" using the tune/scroll knob.
- Press the desired preset button (from ____ [1] to ____ [5]) and press the off-hook switch.

To delete a registered speed dial, after selecting the desired preset button (from ____ [1] to ____ [5]) press ____ (DELETE) and then

Dialing by entering the number

- 1 Select "Dial by number" using the tune/scroll knob.
- 2 Enter the phone number and press the off-hook switch.

Dialing from call histories

- 1 Select "All Calls", "Missed Calls", "Incoming Calls" or "Outgoing Calls" using the tune/scroll knob.
- 2 Select a desired number using the knob and press the off-hook switch.

The following operations can be performed:

Registering a number as a speed dial

Press (Add S. Dial) and then press the desired p	reset buttor
(from [1] to [5]).	
Deleting the selected number	
Press — (DELETE) and press — (YES).	

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Receiving a phone call

Press the off-hook switch.

Refusing the call

Press the on-hook switch.

Receiving a call when on another call

Press the off-hook switch.

Pressing the off-hook switch again returns you to the previous call.

Adjusting the ring tone volume when receiving a call

To decrease the volume: Turn the power/volume knob counterclockwise.

To increase the volume: Turn the power/volume knob clockwise.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

FarmaSOS.com

5

Audio syste

Speaking on the phone

Transferring a call

A call can be transferred between the cellular phone and system while dialing, receiving a call, or during a call. Use one of the following methods:

a.	Operate the cellular phone.
	Refer to the manual that comes with the cellular phone for the operation of the phone.

b. Press t	the —	PHONE).*
------------	-------	----------

the cellular phone to the system during a call.
Muting your voice
Press (MUTE).
Inputting digits
Press (0-9) and use the tune/scroll knob to input the desired digits.
• To send the input digits press (SEND)

- To send the input digits press ____ (SEND).
- When finished, press (EXIT) to return to the previous

Setting call volume

To decrease the volume: Turn the power/volume knob counterclockwise.

To increase the volume: Turn the power/volume knob clockwise.

- Do not talk simultaneously with the other party.
- Keep the volume of the received voice down. Otherwise, voice echo will increase.

■ Automatic volume adjustment

When vehicle speed is 80 km/h (50 mph) or more, the volume automatically increases. The volume returns to the previous volume setting when vehicle speed drops to 70 km/h (43 mph) or less.

■ Phone call system functions

Depending on the cellular phone, certain functions may not be available.

- Situations where the system may not recognize your voice
 - When driving on a rough road
 - When driving at high speeds
 - When air is blowing out of the vents onto the microphone
 - When the air conditioning fan emits a loud noise

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱۰

FarmaSOS.com

5

Audio system

Bluetooth®

■ When using the Bluetooth® audio/phone

- In the following situations, the system may not function.
 - The portable player does not support Bluetooth[®]
 - The cellular phone is located outside the service area
 - The Bluetooth® device is switched off
 - The Bluetooth® device has a low battery
 - The Bluetooth[®] device is not connected to the system
 - The Bluetooth[®] device is behind the seat or in the glove box or console box, or metal material covers or touches the device
- There may be a delay if a cellular phone connection is made during Bluetooth[®] audio play.
- Depending on the type of portable audio player that is connected to the system, operation may differ slightly and certain functions may not be available.

تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

Audio system

■ When transferring ownership of the vehicle

Be sure to initialize the system to prevent personal data from being improperly accessed. (→P. 448)

■ About Bluetooth®

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Fujitsu Ten Limited is under license. Other trademarks and trade names are those of their respective owners.



■ Compatible models

- Bluetooth[®] specifications:
 Ver. 1.1, or higher (Recommended: Ver. 2.1 + EDR or higher)
- Following Profiles:
 - A2DP (Advanced Audio Distribution Profile) Ver. 1.0 or higher (recommended: Ver. 1.2 or higher)
 - AVRCP (Audio/Video Remote Control Profile) Ver. 1.0 or higher (recommended: Ver. 1.3 or higher)

Portable players must correspond to the above specifications in order to be connected to the Bluetooth[®] audio/phone. However, please note that some functions may be limited depending on the type of portable player.

- Cellular phone
 - HFP (Hands Free Profile) Ver. 1.0 or higher (Recommended: Ver. 1.5)
 - OPP (Object Push Profile) Ver. 1.1
 - PBAP (Phone Book Access Profile) Ver. 1.0

■ Certification



The latest "DECLARATION of CONFORMITY" (DoC) is available at the following:

DoC address: FUJITSU TEN LIMITED

2-28, Gosho-dori 1-chome, Hyogo-ku, Kobe, 652-8510, Japan

С настоящето, FUJITSU TEN LIMITED, декларира, че FT0052A в в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.
UJITSU TEN LIMITED tímto prohlašuje, že tento FT0052A je ve shodě se rákladními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES
Dvim FUJITSU TEN LIMITED, izjavljuje da je FT0052A u sklau s bitnim zahtjevima drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).
Undertegnede FUJITSU TEN LIMITED erklærer herved, at følgende udstyr FT0052A overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
liermit erklärt FUJITSU TEN LIMITED, dass sich das Gerät FT0052A in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Käesolevaga kinnitab FUJITSU TEN LIMITED seadme FT0052A vastavust lirektiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
Hereby, FUJITSU TEN LIMITED, declares that this FT0052A is in compliance vith the essential requirements and other relevant provisions of Directive 999/5/EC.
Por medio de la presente FUJITSU TEN LIMITED declara que el FT0052A cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ FUJITSU TEN LIMITED ΔΗΛΩΝΕΙ ΟΤΙ FT0052Α ΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
Par la présente FUJITSU TEN LIMITED déclare que l'appareil FT0052A est conforme aux exigences essentielles et aux autres dispositions pertinentes le la directive 1999/5/CE.
Con la presente FUJITSU TEN LIMITED dichiara che questo FT0052A è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite lalla direttiva 1999/5/CE.
Ar šo FUJITSU TEN LIMITED deklarē, ka FT0052A atbilst Direktīvas 999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
siuo FUJITSU TEN LIMITED deklaruoja, kad šis FT0052A atitinka esminius eikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Nederlands [Dutch]	Hierbij verklaart FUJITSU TEN LIMITED dat het toestel FT0052A in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Malti [Maltese]	Hawnhekk, FUJITSU TEN LIMITED, jiddikjara li dan FT0052A jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.
Magyar [Hungarian]	Alulírott, FUJITSU TEN LIMITED nyilatkozom, hogy a FT0052A megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.
Polski [Polish]	Niniejszym FUJITSU TEN LIMITED oświadcza, że FT0052A jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.
Português [Portuguese]	FUJITSU TEN LIMITED declara que este FT0052A está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.
Română [Romanian]	Prin prezenta, FUJITSU TEN LIMITED, declară că aparatul FT0052A este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.
Slovensko [Slovenian]	FUJITSU TEN LIMITED izjavlja, da je ta FT0052A v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.
Slovensky [Slovak]	FUJITSU TEN LIMITED týmto vyhlasuje, že FT0052A spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.
Suomi [Finnish]	FUJITSU TEN LIMITED vakuuttaa täten että FT0052A tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.
Svenska [Swedish]	Härmed intygar FUJITSU TEN LIMITED att denna FT0052A står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.
Íslenska [Icelandic]	Hér með lýsir FUJITSU TEN LIMITED yfir því að FT0052A er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.
Norsk [Norwegian]	FUJITSU TEN LIMITED erklærer herved at utstyre FT0052A er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.
[Montenegro]	Ovim , FUJITSU TEN LIMITED, izjavljuje da ovaj FT0052A je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

CAUTION

■While driving

Do not use the portable audio player, cellular phone or connect a device to the Bluetooth® system.

■ Caution regarding interference with electronic devices

- Your audio unit is fitted with Bluetooth[®] antennas. People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the Bluetooth[®] antennas. The radio waves may affect the operation of such devices.
- Before using Bluetooth[®] devices, users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical devices.



NOTICE

When leaving the vehicle

Do not leave portable audio player or cellular phone in the vehicle. The inside of the vehicle may become hot, causing damage to the portable audio player or cellular phone.


6-1.	Using the air conditioning	6-3.	Using the storage features
	system and defogger Front manual air conditioning system	ĝ	List of storage features
	 Personal/interior lights main switch	0	• Clock

6


Front manual air conditioning system³

The illustration below is for left-hand drive vehicles.

The button positions and shapes may differ slightly for right-hand drive vehicles.



■ Adjusting the temperature setting



Vehicles with the "A/C" button: If the "A/C" button is not pressed, the system will blow ambient temperature air or heated air.

Adjusting the fan speed setting



Turning the knob to "OFF" turns off the fan.

■ Changing the air flow mode

Press any button of $\begin{bmatrix} \overline{x} \end{bmatrix}$, $\begin{bmatrix} \overline{x} \end{bmatrix}$, $\begin{bmatrix} \overline{x} \end{bmatrix}$ or $\begin{bmatrix} \overline{x} \end{bmatrix}$.

*: If equipped

Other functions

■ Switching between outside air and recirculated air modes

Press 👨

The mode switches between outside air mode (indicator off) and recirculated air mode (indicator on) each time the button is pressed.

Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Press PRONT

Set the outside/recirculated air mode button to outside air mode if the recirculated air mode is used. (It may switch automatically.)

To defog the windshield and the side windows early, turn the air flow and temperature up.

To return to the previous mode, press again when the windshield is defogged.

Vehicles with the "A/C" button: If the dehumidification function is not operating, press to operate the dehumidification function.

■ Defogging the rear window and outside rear view mirrors

▶ Vehicles without outside rear view mirror defoggers

Defoggers are used to defog the rear window.

▶ Vehicles with outside rear view mirror defoggers

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press 🗐 .

The defoggers will automatically turn off after a period of time.


■ Windshield wiper de-icer (if equipped)


This feature is used to prevent ice from building up on the windshield and wiper blades.


Turns on/off

The windshield wiper de-icer will automatically turn off after a period of time

▶ Left-hand drive vehicles








■ Heater idle up (if equipped)

This feature is used to boost heating effect in extremely cold conditions when the vehicle is not moving.

Press the switch to increase engine speed.

Press the switch again to return the engine to the normal idle speed. If you do not turn the switch to off, the engine speed is increased whenever the engine is started.




Air outlets

■ Location of air outlets


The air outlets and air volume changes according to the selected air flow mode.


← : Some models



- Adjusting the position of and opening and closing the air outlets
 - ► Front outlets







- 1 Direct air flow to the left or right, up or down.
- ② Turn the knob to open or close the vent.
 - *: Vehicles without rear manual air conditioning system

6

■ Fogging up of the windows

- Vehicles with the "A/C" button: The windows will easily fog up when the humidity in the vehicle is high. Turning the "A/C" button on will dehumidify the air from the outlets and defog the windshield effectively.
- Vehicles with the "A/C" button: If you turn the "A/C" button off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

■ Outside/recirculated air mode

When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode button to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.

When outside air temperature is low (vehicles with the "A/C" button)

The cooling and dehumidification function may not operate even when the "A/C" button is pressed.

■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring: It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.

■ Air conditioning filter

→P. 586

FarmaSOS.com

A CAUTION

■ To prevent the windshield from fogging up

- Do not use during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- Do not place anything on the instrument panel which may cover the air outlets.
 Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



■To prevent burns

- Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on. (vehicles with outside rear view mirror defoggers)
- Do not touch the glass at lower part of the windshield or to the side of the front pillars when the windshield wiper de-icer is on. (vehicles with windshield wiper de-icer)



NOTICE

■To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.


6

Front automatic air conditioning system^{*}

Air outlets and fan speed are automatically adjusted according to the temperature setting.

The illustration below is for left-hand drive vehicles.

The button positions and shapes may differ slightly for right-hand drive vehicles.



■ Adjusting the temperature setting



knob counterclockwise to decrease the temperature.

Adjusting the fan speed setting

Press "^" on to increase the fan speed and "\" to decrease the fan speed.

Press the "OFF" button to turn the fan off.

■ Changing the air flow mode

Press 😇 .

The air flow mode switch each time the button is pressed.

*: If equipped

Air conditioning controls

- Using the automatic mode
- 1 Press the "AUTO" button.
- 2 Adjust the temperature setting.
- 3 To stop the operation, press the "OFF" button.
- Automatic mode indicator

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated is maintained.

■ Adjusting the temperature for driver and passenger seats separately ("DUAL" mode)

To turn on the "DUAL" mode, perform any of the following procedures:

- Press the "DUAL" button.
- Adjust the passenger's side temperature setting.

The indicator comes on when the "DUAL" mode is on.

While in "DUAL" mode, the temperature of the rear air outlets is set at the passenger's side temperature setting.

تلفن شبانه روزى: ۱۵۸۰۶۲۰۸۵ - ۲۱ م

FarmaSOS.com

Changing the rear seat settings (vehicles with rear automatic air conditioning system)

■ Adjusting the temperature setting

1 Press the "REAR" button.

"REAR" is shown on the display.

2 Turn clockwise to increase the temperature and turn the knob counterclockwise to decrease the temperature.

■ Adjusting the fan speed setting

Press " \wedge " on $\begin{tabular}{c} $\hat{\begin{tabular}{c} $\hat{\begi$

Press the "OFF" button to turn the fan off.

■ Changing the air flow mode

Press 🖘 .

The air flow mode switch each time the button is pressed.

• المحافق

FarmaSOS.com

Other functions

■ Switching between outside air and recirculated air modes

The mode switches between outside air mode (indicator off) and recirculated air mode (indicator on) each time the button is pressed.

■ Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Set the outside/recirculated air mode button to outside air mode if the recirculated air mode is used. (It may switch automatically.)

To defog the windshield and the side windows early, turn the air flow and temperature up.

To return to the previous mode, press again when the windshield is defogged.

■ Defogging the rear window and outside rear view mirrors

Vehicles without outside rear view mirror defoggers

Defoggers are used to defog the rear window.

▶ Vehicles with outside rear view mirror defoggers

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press armaSOS.com

The defoggers will automatically turn off after a period of time.

■ Pollen removal mode

Pollen is removed from the air and the air flows to the upper part of the body.

Press 🖟 .

In order to prevent the windshield from fogging up when the outside air is cold, the dehumidification function may operate.

The pollens are filtered out even if the pollen removal mode is turned off

■ Windshield wiper de-icer (if equipped)


This feature is used to prevent ice from building up on the wind-shield and wiper blades.


Turns on/off

The windshield wiper de-icer will automatically turn off after a period of time.

▶ Left-hand drive vehicles

Right-hand drive vehicles






This feature is used to boost heating effect in extremely cold conditions when the vehicle is not moving.

Press the switch to increase engine speed.

Press the switch again to return the engine to the normal idle speed. If you do not turn the switch to off, the engine speed is increased whenever the engine is started.



■ Power heater (if equipped)

→P. 486

امداد حودرو فارما

تلفن شبانه روزی: ۱۳۹۵ ۱۳۹۸ ۱۳۹۸ ۲۲۰

FarmaSOS.com


6

Air outlets

■ Location of air outlets


The air outlets and air volume changes according to the selected air flow mode.

: Some models




Adjusting the position of and opening and closing the air outlets

▶ Front outlets



Rear outlets*



- ① Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.
 - *: Vehicles without rear automatic air conditioning system

Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and ambient conditions.

Therefore, the fan may stop for a while until warm or cool air is ready to flow immediately after the "AUTO" button is pressed.

■ Fogging up of the windows

- The windows will easily fog up when the humidity in the vehicle is high. Turning the "A/C" button on will dehumidify the air from the outlets and defog the windshield effectively.
- If you turn the "A/C" button off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

■ Outside/recirculated air mode

- When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode button to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.
- Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.

■When outside air temperature is low

The cooling and dehumidification function may not operate even when the "A/C" button is pressed.

Using the rear automatic air conditioning system (vehicles with rear automatic air conditioning system)

- When the rear automatic air conditioning system is on, the indicator light on the "REAR" button is turned on.
- If the system is left untouched for approximately 10 seconds after changing to the rear automatic air conditioning system, the control mode in the front control panel returns to the front.

■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
 - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
 - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

■Air conditioning filter

→P. 586

■ Customization

Settings (e.g. A/C automatic mode button operation) can be changed. (Customizable features →P. 741)

A CAUTION

■ To prevent the windshield from fogging up

- Do not use ☐ during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



■ To prevent burns

- Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on. (vehicles with outside rear view mirror defoggers)
- Do not touch the glass at lower part of the windshield or to the side of the front pillars when the windshield wiper de-icer is on. (vehicles with windshield wiper de-icer)




■ To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

Rear manual air conditioning system'


Press the "REAR" button on the front manual air conditioning control panel to use the rear manual air conditioning system.



Adjusting the temperature setting



■ Adjusting the fan speed setting



■ Changing the air flow mode

Turn


Press any button of $\boxed{}$, $\boxed{}$, or $\boxed{}$.

*: If equipped

Air outlets


■ Location of air outlets

The air outlets and air volume changes according to the selected air flow mode.



Adjusting the position of and opening and closing the air outlets

- ① Direct air flow to the left or right, up or down.
- ② Turn the knob fully to the back of the vehicle to close the vent.





№ NOTICE


■To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

Rear automatic air conditioning system³

Air outlets and fan speed are automatically adjusted according to the temperature setting.

- Vehicles without outer second seat heaters
- Vehicles with outer second seat heaters





تلفن شبانه روزی: Adjusting the temperature setting

Press " \wedge " on the "TEMP" button to increase the temperature and " \vee " to decrease the temperature.

■ Adjusting the fan speed setting

Press " \wedge " on $\boxed{\ \ }$ * \wedge to increase the fan speed and " \vee " to decrease the fan speed.

Press the "OFF" button to turn the fan off.

■ Changing the air flow mode

▶ Vehicles without outer second seat heaters

Press any button of , for or .

▶ Vehicles with outer second seat heaters

Press 🙃

The air flow mode switch each time the button is pressed.

*: If equipped

Air conditioning controls

■ Using the automatic mode

- 1 Press the "AUTO" button.
- 2 Adjust the temperature setting.
- 3 To stop the operation, press the "OFF" button.


■ If the system is operated manually in automatic mode

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated are maintained.

Air outlets


■ Location of air outlets

The air outlets and air volume changes according to the selected air flow mode.



Adjusting the position of and opening and closing the air outlets

- 1 Direct air flow to the left or right, up or down.
- ② Turn the knob fully to the back of the vehicle to close the vent.



■To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

FarmaSOS.com


6

Power heater*

This feature is used to keep the cab warm in cold conditions.

On/off

The power heater turns on about 30 seconds after you press the switch and it takes about another 55 seconds to warm up.



■ Power heater can be operated when

- The engine is running.
- The outside temperature is low.
- The engine coolant temperature is low.

■ Normal characteristics of power heater operation

The following cases do not indicate a malfunction.

- When the power heater is turned on or off, some white smoke and a slight odor may be emitted from the power heater exhaust that is located under the floor.
- When the power heater is being used under extremely cold conditions, vapor may be visible from its exhaust.
- When the power heater is turned off, you may hear a sound in the engine compartment for about 2 minutes until the power heater turns off completely.

■ After the heater is off

We recommend not restarting the heater for 10 minutes after you turn it off. Otherwise, a noise may be heard as the heater ignites.

■When refueling your vehicle


The engine must be turned off. Turning the engine off turns the power heater off.

*: If equipped

A CAUTION

■ To prevent burns or damage on your vehicle

- Do not touch the heater or its exhaust pipe as they are hot.
- Keep flammable items such as fuel away from the heater and its exhaust pipe. This may cause a fire.



↑ NOTICE

■ To prevent damage to your vehicle

- Do not turn the heater on and off repeatedly in 5 minute intervals as this can shorten the life of the heater components. If the engine must be turned on and off repeatedly within short intervals (such as when the vehicle is being used for delivery purposes), turn the heater off.
- Do not modify or open the heater without consulting any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. This may cause a heater malfunction or a fire.
- Be careful not to splash water or spill liquid directly on the heater or on the heater fuel pump. This may cause the heater to malfunction.
- Keep the intake and exhaust pipes of the heater free from water, snow, ice, mud, etc. If the pipes become clogged, this can cause the heater to malfunction.
- If you notice anything unusual, such as a fluid leak, smoke or poor operation, turn off the heater and have your vehicle checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Heated steering wheel*/seat heaters*/ seat ventilators'

Heated steering wheel and seat heaters heat the side grips of the steering wheel and seats. Seat ventilators maintain good airflow by blowing air from the seats.

A CAUTION

- Care should be taken to prevent injury if anyone in the following categories comes in contact with the steering wheel and seats when the heater is on:
 - · Babies, small children, the elderly, the sick and the physically challenged
 - Persons with sensitive skin
 - Persons who are fatigued
 - · Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)
- Observe the following precautions to prevent the minor burns or overheat-
 - · Do not cover the seat with a blanket or cushion when using the seat heater.
 - · Do not use seat heater more than necessary.




NOTICE.

- Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.
- To prevent battery discharge, do not use the functions when the engine is off.

*: If equipped

Turns the steering wheel heater on/off

The indicator light comes on when the heater is operating.



■ The heated steering wheel can be used when

- ▶ Vehicles without a smart entry & start system The engine switch is in the "ON" position.
- ▶ Vehicles with a smart entry & start system
 The engine switch is in IGNITION ON mode.
- ■Timer

The heated steering wheel will automatically turn off after about 30 minutes.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا


FarmaSOS.com

6


Seat heaters (if equipped)

■ Front seats

▶ Vehicles with an automatic transmission



▶ Vehicles with a manual transmission




- ① Turns the seat heater on The indicator light comes on.
- ② Adjusts the seat temperature
 The further you turn the dial upward, the warmer the seat becomes.

■ Outer second seats


- 1 For left second seat
- ② For right second seat
- 3 High heating temperature
- 4 Low heating temperature

 To turn on the seat heater, press
 "HI" or "LO".
- ⑤ Off




Seat ventilators (if equipped)

▶ Vehicles with an automatic transmission



Vehicles with a manual transmission



- 2 Adjusts the fan speed

■ The seat heaters/seat ventilators can be used when


▶ Vehicles without a smart entry & start system

The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system


The engine switch is in IGNITION ON mode.

Interior lights list



- ① Personal/interior lights (→P. 493)
- ② Ornament illumination* (if equipped)
- 4 Shift lever light (if equipped)
- 5 Footwell lights* (if equipped)
- 6 Engine switch light
- ⑦ Door pocket lights* (if equipped)
- 8 Running board lights (if equipped)
- *: The brightness of the lights can be adjusted (→P. 494)


Personal/interior lights main switch




- 1) Off
 - The personal/Interior lights and interior light can be individually turned on or off.
- ② Door position The personal/interior lights come on when a door is opened. They turn off when the doors are closed.
- ③ On The personal/interior lights cannot be individually turned off.

Personal/interior lights

Turns the lights on/off




- ► Rear (without personal lights)
- 1 Turns the lights on
- 2 Turns the door position on Door position: When the personal/ interior light main switch is in the "OFF" position, the lights will not turn on.



► Rear (with personal lights)


Turns the lights on/off



Lounge illumination control switches (if equipped)

The brightness of the following lights can be adjusted:

- Inside door handle lights
- Ornament illumination
- Door pocket lights
- Footwell lights SOS. COM
 - 1 Brighter
 - 2 Darker



▶ Vehicles without a smart entry & start system

The lights automatically turn on/off according to the engine switch position, whether the doors are locked/unlocked, and whether the doors are open/closed.

▶ Vehicles with a smart entry & start system

The lights automatically turn on/off according to the engine switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are open/closed.

■ To prevent battery discharge

If the following lights remain on when the engine switch is turned off the lights will go off automatically after 20 minutes:

- Personal/interior light
- Inside door handle lights (if equipped)
- Ornament illumination (if equipped)
- Door pocket lights (if equipped)
- Footwell lights (if equipped)



Settings (e.g. time elapsed before the interior lights turn off) can be changed. (Customizable features \rightarrow P. 745)




To prevent battery discharge, do not leave the lights on longer than necessary when the engine is not running.

FarmaSOS.com

6

List of storage features




- ① Cup holders (\rightarrow P. 500)
- ② Bottle holders/door pockets (→P. 501)
 تلفن شبانه روزی
- ③ Auxiliary boxes (→P. 503)
- ④ Glove box (→P. 497) Card holder (right-hand drive vehicles) (→P. 498)
- (5) Console box (if equipped) (→P. 498) Cool box (if equipped) (→P. 509)

A CAUTION

- Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:
 - · Glasses may be deformed by heat or cracked if they come into contact with other stored items.
 - Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.
- Keep the storage compartments lids closed when driving or not in use. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open lid or the items stored inside.

Glove box

- 1 Unlock with the master key or the mechanical key
- 2 Lock with the master key or the mechanical key
- ③ Open (pull the lever)




The glove box light turns on when the tail lights are on.

FarmaSOS.com


Card holder (right-hand drive vehicles)

The card holder is located in the glove box.



Console box (if equipped)

Your vehicle is equipped with either a console box or cool box. For vehicles with the cool box, refer to P. 509.




Lift the lid while pulling up the knob to release the lock.

- 1 Lifts the lid and tray
- ② Lifts the lid Pull the tray up to open the console box.

■ Using the console box vent (if equipped)

Air from the air conditioner can be distributed into the console box by opening and closing the vent.

- ① Open
- ② Close



■ Items unsuitable for the console box

- Drinks in unsealed containers
- Fragile items, perishables or anything with strong odor
- Owner's manual, electronic devices, CDs, etc. (when using the console box vent)

■When using the console box lid as an armrest

Slide the console box lid forward or backward as needed. Slide the lid while pulling up the lever to release the lock.





NOTICE

Make sure of the following when the lid or tray of the console box does not close, or when the tray sticks while opening the lid.


Operating them forcibly may cause damage to the console box or the stored items.


- The stored items in the console box do not interfere with the tray.
- The stored items in the tray do not interfere with the lid of the console box.

Cup holders/bottle holders/door pockets

■ Cup holders

- matic transmission)
- ▶ Front (vehicles with an auto- ▶ Front (vehicles with a manual transmission)





Press down and release the cup holder lid.

► Rear (type A) (if equipped)

Press down and release the cup holder lid.

Rear (type B) (if equipped)









Pull the armrest down and press in and release the button.

- ► Rear (type C) (if equipped)
- ► Rear (type D) (if equipped)







Push the lid.

- Bottle holders/door pockets
 - ▶ Front




▶ Rear (if equipped)






- Removing the holder, separate tray and adapter of the cup holder
 - ▶ Front (vehicles with an automatic transmission)

Pull up the holder.




▶ Front (vehicles with a manual transmission)

Pull up the separate tray.



► Rear (type A)

Pull up the adapter.



- ■When storing a bottle in the bottle holder
 - Close the cap.
 - The bottle may not be stored depending on its size or shape.



CAUTION

■ Items unsuitable for the cup holder

Do not place anything other than cups, mugs or beverage cans in the cup holders.

Other items may be thrown out of the holders in the event of sudden braking, sudden swerving or an accident, cause injury. If possible, cover hot drinks to prevent burns.

■ Items unsuitable for the bottle holder

Do not place anything other than a bottle in the bottle holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury.



NOTICE

■ To prevent damage to the rear cup holders (rear [type B])


Stow the cup holders before stowing the armrest.

Items that should not be stowed in the bottle holders


Do not place open bottles in the bottle holders, or glasses and paper cups containing liquid. The contents may spill and glasses may break.

Auxiliary boxes

▶ Type A



► Type B (if equipped)





Press in the lid.

The auxiliary box is useful for temporarily storing sunglasses and similar small items.

► Type C (if equipped)











- ► Type E (vehicles with an automatic transmission)
- ► Type F (vehicles with a manual transmission)





A CAUTION

- Do not place cups, beverage cans or bottles in the box. They may be thrown out of the box in the event of sudden braking, sudden swerving or an accident, resulting in injury. (type E and F)
- Do not store items heavier than 0.2 kg (0.4 lb.).
 Doing so may cause the auxiliary box to open and the items inside may fall out, resulting in an accident. (type A)
- Do not put large items in the overhead console.
 The overhead console may not be able to be shut from the conversation mirror state. (type A)


FarmaSOS.com

Deck rail (if equipped)

To attach the deck hooks, use the deck rails.

The deck hook itself is not included as an original equipment.

Vehicles with the third seats (power seat): When using the deck rail, the third seat must be fold down. $(\rightarrow P.~188)$




Cargo hooks (if equipped)

Raise the hook to use.


The cargo hooks are provided for securing loose items.

Vehicles with the third seats (manual seat): When using the deck hooks, the third seat must be fold down. (\rightarrow P. 186)



Warning reflector holder

- 1 Open the cover.
 - 1) Turn the knob clockwise.
 - ② Open the cover.




6


Interior features

2 Secure the warning reflector.

The warning reflector itself is not included as an original equipment.



Cargo net hooks



To hang the cargo net, use the cargo net hooks.


The cargo net itself is not included as an original equipment.

Auxiliary box (if equipped)


▶ Type A



▶ Type B



Remove the cover.




Luggage cover (if equipped)

■ Installing the luggage cover


- 1 Attach the hooks to the head restraints.


 Vehicles with the third seats: When using the luggage cover, the third seat must be fold down. (→P. 186, 188)
 - ▶ 3-doors models

► 5-doors models



2 Pull out the luggage cover and hook it on the anchors.






6

Interior features

■ Removing the luggage cover

Retract the cover and release both ends, then lift it out.

After removing the luggage cover, place it somewhere other than the passenger compartment.



■ Adjusting the sub cover (if equipped)



Fasten the button when the second seats are in the rear-most position. Unfasten the buttons before sliding the second seats forward.


▲ CAUTION

- To avoid injury, always return the cargo hooks to their stowed positions.
- Keep the auxiliary box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open auxiliary box or the items stored inside.
- Do not allow children to climb on the luggage cover. Climbing on the luggage cover could result in damage to the luggage cover, possibly causing death or serious injury to the child.


Other interior features

Cool box (if equipped)

1 Lift the lid while pulling up the knob to release the lock.



Turns the cool box on/off When on, the indicator light comes on.



■ The cool box can be operated when

▶ Vehicles with a manual air conditioning system

Vehicles without a smart entry & start system:

The engine switch is in the "ON" position, and the front air conditioning system is turned on.

Vehicles with a smart entry & start system:

The engine switch is in IGNITION ON mode, and the front air conditioning system is turned on.

▶ Vehicles with an automatic air conditioning system

Vehicles without a smart entry & start system:

The engine switch is in the "ON" position.

Vehicles with a smart entry & start system:

The engine switch is in IGNITION ON mode.

■If the front air conditioning system is not in use when the cool box is turned on (vehicles with an automatic air conditioning system)

The front air conditioning system is automatically turned on.

■ Items unsuitable for the cool box

- Drinks in unsealed containers
- Fragile items, perishables or anything with strong odor
- Owner's manual, electronic devices, CDs, etc.

■When the indicator light flashes

The cool box is not operated when any of the following conditions occurs.

- When the air conditioning system is off
 Turn the air conditioning system on also turns on the cool box.
- When outside air temperature is about 0°C (32°F) or below

If the indicator light continues to flash, there may be a malfunction in the system. Turn the air conditioning system off and have it inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■When using the cool box lid as an armrest

Slide the cool box lid forward or backward as needed. Slide the lid while pulling up the lever to release the lock.



A CAUTION


Keep the cool box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open cool box or the items stored inside.

№ NOTICE


To prevent battery discharge, do not leave the cool box on longer than necessary when the engine is stopped.

Sun visors

- ▶ Type A
- 1) To set the visor in the forward position, flip it down.
- ② To set the visor in the side position, flip down, unhook, and swing it to the side.




- ▶ Type B
- 1) To set the visor in the forward position, flip it down.
- ② To set the visor in the side position, flip down, unhook, and swing it to the side.
- To use the side extender, place the visor in the side position, then slide it backward.



Vanity mirror

Slide the cover to open.

The light turns on when the cover is opened.



If the vanity lights remain on when the engine switch is turned off, the lights will go off automatically after 20 minutes.



To prevent battery discharge, do not leave the vanity lights on for extended periods when the engine is not running.

Conversation mirror


The conversation mirror can provide the driver and the front passenger with a view of the rear seat area without the need to turn around.




To use the overhead console when the conversation mirror is open, further extend down the lid. $(\rightarrow P. 503)$

Clock

- ▶ Vehicles with a front manual air conditioning system
- 1 Adjusts the hours
- 2 Adjusts the minutes



- ▶ Vehicles with a front automatic air conditioning system
- 1 Adjusts the hours
- 2 Adjusts the minutes
- 3 Rounds the nearest hour
 - *: e.g. 1:00 to 1:29 \rightarrow 1:00 1:30 to 1:59 \rightarrow 2:00



■The clock is displayed when

▶ Vehicles without a smart entry & start system

The engine switch is in the "ACC" or "ON" position.

▶ Vehicles with a smart entry & start system

The engine switch is in ACCESSORY or IGNITION ON mode.

■ When disconnecting and reconnecting battery terminals
The clock data will be reset.

Interior features

Power outlet

The power outlet can be used for the following components:

12 V DC:

Accessories that run on less than 10 A.

Accessories that run on less than 10 A should be used when using several power outlets at the same time.


220 V AC:

Accessories that use less than 100 W.


■ Center of console (12 V DC)

transmission

▶ Vehicles with an automatic ▶ Vehicles with a manual transmission





▶ Rear of console box




■ Luggage compartment (12 V DC) (if equipped)

▶ 3 door models










■ Luggage compartment (220 V AC) (if equipped)

▶ 3 door models







■The power outlet can be used when

▶ Vehicles without a smart entry & start system

12 V DC: The engine switch is in the "ACC" or "ON" position.

220 V AC: The engine switch is in the "ON" position.

▶ Vehicles with a smart entry & start system

12 V DC: The engine switch is in ACCESSORY or IGNITION ON mode.

220 V AC: The engine switch is in IGNITION ON mode.

⚠ NOTICE

■To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit

■To prevent blown fuse

▶ 12 V DC

Do not use an accessory that uses more than 12 V 10 A.

▶ 220 V AC

Do not use a 220 V AC appliance that requires more than 100 W.

If a 220 V AC appliance that consumes more than 100 W is used, the protection circuit will cut the power supply.

■ To prevent battery discharge

Do not use the power outlet longer than necessary when the engine is not running.


Appliances that may not operate properly (220 V AC)

The following 220 V AC appliances may not operate properly even if their power consumption is under 100 W:

- Appliances with high initial peak wattage
- Measuring devices that process precise data
- Other appliances that require an extremely stable power supply

Armrest (if equipped)

Fold down the armrest for use.



NOTICE

To prevent damage, do not apply too heavy a load on the armrest.

Coat hooks

The coat hooks are provided with the rear assist grips.



CAUTION


Vehicles with SRS curtain shield airbags: Do not hang coat hangers or other hard or sharp objects on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.

Assist grips

An assist grip (Type A) can be used to support your body while sitting

An assist grip (Type B) can be used when getting in or out of the vehicle and others.

- 1 Assist grip (Type A)
- 2 Assist grip (Type B)





A CAUTION


Do not use the assist grip (Type A) when getting in or out of the vehicle or rising from your seat.



NOTICE

To prevent damage, do not hang heavy objects or put a heavy load on the assist grip.

The ashtray can be installed in the auxiliary box (type E and F: \rightarrow P. 503) or cup holder (\rightarrow P. 500).



CAUTION

■When not in use

Keep the ashtray closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open ashtray or ash flying out.

■ To prevent fire

- Fully extinguish matches and cigarettes before putting them in the ashtray, then make sure the ashtray is fully closed.
- Do not place paper or any other type of flammable object in the ashtray.




ERA-GLONASS*

ERA-GLONASS is a telematics service that uses Global Navigation Satellite System (GLONASS) data and embedded cellular technology to enable the following emergency calls to be made: Automatic emergency calls (Automatic Collision Notification) and manual emergency calls (by pressing the "SOS" button). This service is required by Eurasian Customs Union Regulations.

System components

- 1 Microphone
- 2 "SOS" button
- ③ Indicator lights



Emergency Notification Services

■ Automatic Collision Notification

If any airbag deploys, the system is designed to automatically call the Public Safety Answering Point (PSAP)*. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

*: If equipped

^{*:} In some cases, the call cannot be made. $(\rightarrow P. 522)$

■ Emergency Assistance Button ("SOS")

In the event of an emergency, push the "SOS" button to reach the Public Safety Answering Point (PSAP). The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the agent that you are not experiencing an emergency.

Indicator lights

When the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system), the red indicator light will illuminate for 10 seconds and then the green indicator light will illuminate for 2 seconds, indicating that the system is enabled. The indicator lights indicate the following:

- If the green indicator light illuminates and stays on, the system is enabled
- If the green indicator light flashes, an emergency call is being made (either automatically or manually).
- If no indicator lights illuminate, the system is not enabled.
- If the red indicator light illuminates any time other than immediately after the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system), the system may be malfunctioning or the backup battery may be depleted. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

The service life of the backup battery is 3 years or more.

CAUTION

■ When the Emergency Call may not be made

- Any of the followings may occur. In such cases, report to the Public Safety Answering Point (PSAP) by other means such as nearby public phones.
 - · It may sometimes be difficult to connect to the Public Safety Answering Point (PSAP) even in the reception area of the cellular phone due to the reception level, or if the line is busy. In such cases, you may not be able to connect to the Public Safety Answering Point (PSAP) and thus will not be able to make emergency calls and report to the emergency departments even though the system tries to connect to the Public Safety Answering Point (PSAP).
 - · When the vehicle is out of the cellular phone service area, the Emergency Call cannot be made.
 - When any related equipment (such as the "SOS" button panel, indicator lights, microphone, speaker, DCM, antenna, or any wires connecting the equipment.) has an abnormality, is damaged or broken, the Emergency Call cannot be made.
 - · During the Emergency Call, the system makes repeated attempts to connect to the Public Safety Answering Point (PSAP). However, if it cannot connect to the Public Safety Answering Point (PSAP) due to poor radio wave reception, the system may not be able to connect to the cellular network and the call may finish without connecting. The red indicator light will blink for approximately 30 seconds to indicate this disconnection.
 - This device may not function if a shock is applied to it.
- If the battery's voltage decreases or there is a disconnection, the system may not be able to access the Public Safety Answering Point (PSAP).

A CAUTION

■When replacing DCM to a new one

ERA-GLONASS have to be activated. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

For your safety

Please drive safely.

The function of this system is to assist you in making the Emergency Call in case of accidents as traffic accidents or sudden medical emergencies, and it does not protect the driver or the passengers in any way. Please drive safely and fasten your seatbelts at all times for your safety.

- In case of an emergency, make lives the top priority.
- If you smell anything burning or another unusual smell, do not stay inside the vehicle and evacuate to a safe area immediately.
- Since the system detects shocks, the automatic reporting may not always occur synchronized with the operation of the airbag system. (If the vehicle is bumped from behind, etc.)
- The airbag may not inflate even in case of an accident, if it does not involve high impact.
 - In such cases, the system may not make emergency calls automatically. The system may also not make automatic emergency calls even if the airbag has been inflated. If any of these should occur, please report to the Public Safety Answering Point (PSAP) by operating the "SOS" button.
- For safety, do not make the Emergency Call while driving.
 Making calls during driving may cause mishandling of the steering wheel, which may lead to unexpected accidents. Stop the vehicle and confirm the safety of the area before making the Emergency Call.
- When changing fuses, please use fuses that correspond to the described standard.
 - If you use fuses other than those described, it may cause ignition or smoke in the circuit and may lead to a fire.
- Using the system while there is smoke or an unusual smell may cause a fire. Stop using the system immediately and consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

⚠ NOTICE

■ To prevent damage

Do not pour any liquid on to the "SOS" button panel etc. and make any impact to it.

■ If the "SOS" button panel malfunctions

It may not be able to make the Emergency Call or inform you of the correct condition of the system. If the "SOS" button panel has been broken, please consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

If there is any malfunction of the speaker or the microphone during the Emergency Call or the Manual Maintenance Check

You will not be able to communicate with the Public Safety Answering Point (PSAP) operator.

If any of this equipment has been broken, please consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

7-1.	Maintenance and care Cleaning and protecting	7-3.	Do-it-yourself maintena Do-it-yourself service	nce
	the vehicle exterior526		precautions	536
	Cleaning and protecting		Hood	539
	the vehicle interior530		Engine compartment	540
7-2.	Maintenance		Tires	565
	Maintenance requirements533	7	Tire inflation pressure	581
			Wheels	583
			Air conditioning filter	586
			Wireless remote control/electronic	
	UN ALACO	ı k	key battery	588
	*Y\-\\\\\\\	1	تلفن Checking and	
			replacing fuses	592
			Light bulbs	596

Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.
 If water does not bead on a clean surface, apply wax when the vehicle body is cool.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

■ Automatic car washes

- Fold the mirrors back before washing the vehicle. Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows and the air suspension unit.
- Before using the car wash, check that the fuel filler door on your vehicle is closed properly.

■ Aluminum wheels

- Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners. Use the same mild detergent and wax as used on the paint.
- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

Bumpers

Do not scrub with abrasive cleaners.

■ Notes for a smart entry & start system (if equipped)

- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. Place the key in a position 2 m (6 ft.) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.

A CAUTION


■When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components etc. to catch fire.

■When cleaning the windshield (vehicles with rain-sensing windshield wiper)

Set the wiper switch to off.

If the wiper switch is in "AUTO", the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.



- •When the upper part of the windshield where the raindrop sensor is located is touched by hand
- •When a wet rag or similar is held close to the raindrop sensor
- If something bumps against the windshield
- If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor

■ Precautions regarding the exhaust pipe

Exhaust gasses cause the exhaust pipe to become quite hot.

When washing the vehicle, be careful not to touch the pipe until it has cooled sufficiently, as touching a hot exhaust pipe can cause burns.

■ Precautions regarding the Blind Spot Monitor (if equipped)

If the paint of the rear bumper is chipped or scratched, the system may malfunction.

If this occurs, consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

⚠ NOTICE

■ To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

- Wash the vehicle immediately in the following cases:
 - · After driving near the sea coast
 - · After driving on salted roads
 - If coal tar or tree sap is present on the paint surface
 - If you see dead insects, insect droppings or bird droppings on the paint
 - After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
 - · If the vehicle becomes heavily soiled in dust or mud
 - If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing wheels.

Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush.
 This may damage the surfaces of the lights.
- Do not apply wax on the surfaces of the lights. Wax may cause damage to the lenses.

■ To prevent damage to the windshield wiper arms

When lifting the wiper arms away from the windshield, pull the driver side wiper arm upward first, and repeat for the passenger side. When returning the wipers to their original position, do so from the passenger side first.

When using an automatic car wash (vehicles with rain sensing windshield wipers)

Set the wiper switch to the off position.

If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

When using a high pressure car wash

Do not bring the nozzle tip close to boots (rubber or resin manufactured cover), connectors or the following parts. The parts may be damages if they come into contact with high-pressure water.

- Traction related parts
- Steering parts
- Suspension parts
- Brake parts

Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

Protecting the vehicle interior

- Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.
- If dirt cannot be removed, wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe any excess dirt and dust with a soft cloth dampened with diluted detergent.
 - Use a diluted water solution of approximately 5 % neutral wool detergent.
- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded ventilated area.

Cleaning the synthetic leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

■ Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

■ Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. The excellent results are obtained when keeping the carpet as dry as possible.

■ Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.



CAUTION

■ Water in the vehicle

- Do not splash or spill liquid in the vehicle. Doing so may cause electrical components etc. to malfunction or catch
- Do not get any of the SRS components or wiring in the vehicle interior wet. (→P. 43)

An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.

■ Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

⚠ NOTICE

■ Cleaning detergents

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
 - Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach
 - Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

■ Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- Remove any dust or dirt from leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time.
 Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

■ Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

■ Cleaning the inside of the rear window

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.
- Be careful not to scratch or damage the heater wires or antenna.

Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. Toyota recommends the following maintenance:

Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For full details of your maintenance schedule, refer to the "Toyota Service Booklet" or "Toyota Warranty Booklet".

Do-it-yourself maintenance

What about do-it-yourself maintenance?

Many maintenance items are easy to do yourself if you have a little mechanical ability and a few basic automotive tools.

Note, however, that some maintenance tasks require special tools and skills. These are best performed by qualified technicians. Even if you're an experienced do-it-yourself mechanic, we recommend that repairs and maintenance be conducted by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. Any authorized Toyota retailer or repairer will keep a record of maintenance, which could be useful should you ever require Warranty Service. Should you choose to select a qualified and equipped professional other than an authorized Toyota repairer to service or maintain your vehicle, we recommend that you request that a record of maintenance be kept.

■Where to go for maintenance service?

In order to maintain your vehicle in the best possible condition, Toyota recommends that maintenance service operations as well as other inspections and repairs be carried out by authorized Toyota retailers or Toyota authorized repairers, or any reliable repairers. For repairs and services covered by your warranty, please visit an authorized Toyota retailer or repairer, who will use genuine Toyota parts in repairing any difficulties you may encounter. There can also be advantages in utilizing authorized Toyota retailers or repairers for non-warranty repairs and services, as members of the Toyota network will be able to expertly assist you with any difficulties you may encounter.

Your Toyota retailer or Toyota authorized repairer, or any reliable repairer will perform all of the scheduled maintenance on your vehicle reliably and economically due to their experience with Toyota vehicles.

■ Does your vehicle need repairs?

Be on the alert for changes in performance and sounds, and visual tip-offs that indicate service is needed. Some important clues are:

- Engine missing, stumbling or pinging
- Appreciable loss of power
- Strange engine noises
- A fluid leak under the vehicle (However, water dripping from the air conditioning system after use is normal.)
- Change in exhaust sound (This may indicate a dangerous carbon monoxide leak. Drive with the windows open and have the exhaust system checked immediately.)
- Flat-looking tires, excessive tire squeal when cornering, uneven tire wear
- Vehicle pulls to one side when driven straight on a level road
- Strange noises related to suspension movement
- Loss of brake effectiveness, spongy feeling brake pedal or clutch pedal, pedal almost touches the floor, vehicle pulls to one side when braking
- Engine coolant temperature continually higher than normal (\rightarrow P. 107)

If you notice any of these clues, take your vehicle to any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible. Your vehicle may need adjustment or repair.

A CAUTION

■ If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

Handling of the battery

Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. $(\rightarrow P. 552)$



تلفن شبانه روزی: ۱-۸۸۸۶۲۰۸۵ ا

Do-it-yourself service precautions

If you perform maintenance yourself, be sure to follow the correct procedures as given in these sections.

Items	Parts and tools			
	Warm water Baking soda Grease			
Battery condition (→P. 552)	Conventional wrench (for terminal clamp bolts)			
,	Distilled water			
Engine coolant level (→P. 549)	 "Toyota Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non- amine, non-nitrite and non-borate coolant with long- life hybrid organic acid technology. "Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water. 			
	Funnel (used only for adding coolant)			
	"Toyota Genuine Motor Oil" or equivalent			
Engine oil level (→P. 545)	Rag or paper towel			
+ 71-	Funnel (used only for adding engine oil)			
Fuses (→P. 592)	Fuse with same amperage rating as original			
Light bulbs	Bulb with same number and wattage rating as original			
(→P. 596)	Phillips-head screwdriver			
	Flathead screwdriver Wrench			
Radiator, condenser and intercooler (→P. 551)				
Tire inflation pressure (→P. 581)	Tire pressure gauge Compressed air source			
Washer fluid (→P. 556)	Water or washer fluid containing antifreeze (for winter use)			
(-71 . 330)	Funnel (used only for adding water or washer fluid)			

A CAUTION

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions:

When working on the engine compartment

- Keep hands, clothing and tools away from the moving fan and engine drive belt.
- Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper or rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel or the battery. Fuel and battery fumes are flammable.
- Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.
- Take care because brake fluid can harm your hands or eyes and damage painted surfaces. If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately. If you still experience discomfort, consult a doctor.

■ When working near the electric cooling fans or radiator grille

Vehicles without a smart entry & start system: Be sure the engine switch is off. With the engine switch in the "ON" position, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high. $(\rightarrow P. 551)$

Vehicles with a smart entry & start system: Be sure the engine switch is off. With the engine switch in IGNITION ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high. (\rightarrow P. 551)

■When working on or under the vehicle

Do not get under the vehicle with just the jack supporting it. Always use automotive jack stands or other solid supports.

■ Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.

№ NOTICE

■ If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air.

If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.


If the reservoir needs frequent refilling, it may indicate a serious problem.




تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Release the lock from the inside of the vehicle to open the hood.

1 Pull the hood lock release lever. The hood will pop up slightly.



2 Move the auxiliary catch lever to side direction and lift the hood.



A CAUTION


■ Pre-driving check

Check that the hood is fully closed and locked. If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

Maintenance and care

Engine compartment

▶ 2TR-FE engine




- 1 Discharging dust valve (→P. 558)
- 2 Engine coolant reservoir (→P. 549)
- 3 Radiator cooling fan
- ④ Engine oil filler cap (→P. 547)
- (5) Engine oil level dipstick

(→P. 545)


- 6 Fuse box (→P. 592)
- 7 Battery (→P. 552)
- 8 Radiator (→P. 551)
- ① Condenser $(\rightarrow P. 551)$
- Washer fluid tank (→P. 556)

▶ 1GR-FE engine



- ① Discharging dust valve (if equipped) (→P
 - (→P. 558)
- ② Engine oil level dipstick— (→P. 545)
- ③ Engine coolant reservoir
 - (→P. 549)
- (→P. 551)
- ⑤ Engine oil filler cap (→P. 547)
- ⑥ Fuse box (→P. 592)
- ⑦ Battery (→P. 552)
- 8 Radiator cooling fan
- ① Condenser $(\rightarrow P. 551)$
- Washer fluid tank (→P. 556)

▶ 1GD-FTV engine



① Discharging dust valve


(→P. 558)

- ② Battery (if equipped) (→P. 552)
- ③ Engine coolant reservoir(→P. 549)
- ④ Engine oil filler cap (→P. 547)
- ⑤ Radiator (→P. 551)
- 6 Engine oil level dipstick

(→P. 545)

- ⑦ AdBlue™ tank cap (if equipped) (→P. 560)
- (→P. 559, 704)
- ① Battery (→P. 552)
- ① Intercooler (→P. 551)
- \bigcirc Condenser $(\rightarrow P. 551)$
- 13 Radiator cooling fan
- (14) Cooling fan
- (15) Washer fluid tank (→P. 556)

▶ 1KD-FTV engine



1 Discharging dust valve

(→P. 558)


(→P. 545)

- ② Battery (if equipped) (→P. 552
- ③ Engine coolant reservoir (→P. 549)
- 4 Engine oil level dipstick
- ⑤ Engine oil filler cap (→P. 547)

- (→ P. 551)
- \bigcirc Fuse box (→P. 592)
- 8 Fuel filter (→P. 559, 704)
- (→P. 552) في شبانه (Battery)
- 10 Intercooler $(\rightarrow P. 551)$
- ① Condenser $(\rightarrow P. 551)$
- 12 Radiator cooling fan
- (13) Cooling fan
- (14) Washer fluid tank (→P. 556)


Engine compartment cover

■ Removing the engine compartment cover



■ Installing the clips

- 1 Push up center portion
- 2 Insert
- 3 Press





■ After installing an engine compartment cover


Make sure the cover is securely installed in its original position.

With the engine at operating temperature and turned off, check the oil level on the dipstick.

■ Checking the engine oil

- 1 Park the vehicle on level ground. After warming up the engine and turning it off, wait more than 5 minutes for the oil to drain back into the bottom of the engine.
- 2 Remove the sand and dust from around the dipstick.
- 3 Holding a rag under the end, pull the dipstick out.






- 4 Wipe the dipstick clean.
- 5 Reinsert the dipstick fully.


تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ م

- 6 Holding a rag under the end, pull the dipstick out and check the oil level.
 - 1) Low
 - ② Normal
 - ③ Excessive

▶ Type A

▶ Type B






The shape of the dipstick may differ depending on the type of vehicle or engine.

7 Wipe the dipstick and reinsert it fully.

تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۸**۸ ۲۲ ۲۸ تلفن

If the oil level is below or near the low level mark, add engine oil of the same type as already in the engine.



Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection		→P. 715	
Oil quantity (Low → Full)	1KD-FTV engine	1.3 L (1.4 qt., 1.1 Imp.qt.)	
	1GD-FTV engine	1.2 L (1.3 qt., 1.1 Imp.qt.)	
	1GR-FE and 2TR-FE engines	1.5 L (1.6 qt., 1.3 lmp.qt.)	
Items		Clean funnel	

- 1 Remove the sand and dust from around the oil filler cap.
- 2 Remove the oil filler cap by turning it counterclockwise.

- 3 Add engine oil slowly, checking the dipstick.
- 4 Install the oil filler cap by turning it clockwise.

■ Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance intervals.

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used
- When driving at high engine speeds or with a heavy load, when towing, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

■ After changing the engine oil (1GD-FTV engine only)

The oil maintenance data should be reset. Perform the following procedures:

- Switch the display to the trip meter "A" when the engine is running. (→P. 105)
- 2 Turn the engine switch off.
- 3 While pressing the "ODO TRIP" button (→P. 105), set the engine switch to IGNITION ON mode (but do not start the engine because otherwise the reset mode will be canceled). Continue to press and hold the button until the multi-information display indicates that the reset is complete.

A CAUTION

■Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation or skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.

■To prevent serious engine damage

Check the oil level on regular basis.

- ■When replacing the engine oil
 - Be careful not to spill engine oil on the vehicle components.
 - Avoid overfilling, or the engine could be damaged.
 - Check the oil level on the dipstick every time you refill the vehicle.
 - Be sure the engine oil filler cap is properly tightened.


Engine coolant

▶ Gasoline engine

The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir when the engine is cold.

- 1 Reservoir cap
- ② "F" line
- ③ "L" line

If the level is on or below the "L" line, add coolant up to the "F" line.



FarmaSOS.com


7

▶ Diesel engine

The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir when the engine is cold.

- 1 Reservoir cap
- ② "FULL" line
- ③ "LOW" line

If the level is on or below the "LOW" line, add coolant up to the "FULL" line.



■ Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Enabled: -35°C [-31°F])

For more details about engine coolant, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ If the coolant level drops within a short time of replenishing

Visually check the radiator, hoses, engine coolant reservoir cap, radiator cap, drain cock and water pump. If you cannot find a leak, have any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer test the cap and check for leaks in the cooling system.

A CAUTION

■When the engine is hot

Do not remove the radiator cap, or the coolant reservoir cap. The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.

NOTICE

■When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

If you spill coolant

Be sure to wash it off with water to prevent it from damage to parts or paint.

Radiator, condenser and intercooler

Check the radiator, condenser and intercooler (if equipped) and clear any foreign objects. If any of the above parts are extremely dirty or you are not sure of their condition, have your vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable تلفن شبانه روزی: **۵۸۰ ۱−۸۸۸/**−۱



CAUTION

■ When the engine is hot

Do not touch the radiator, condenser or intercooler as they may be hot and cause serious injuries, such as burns.

Maintenance and care

Battery

Check the battery as follows.

■ Caution symbols


The meanings of each caution symbol on the top of the battery are as follows:

(S)	No smoking, no naked flames, no sparks	Battery acid
6	Shield eyes	Note operating instructions
(49)	Keep away from children	Explosive gas

■ Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.


- 1 Terminals
- ② Hold-down clamp



Check that the level is between the "UPPER LEVEL" and "LOWER LEVEL" lines.

- 1 "UPPER LEVEL" line
- ② "LOWER LEVEL" line


If the fluid level is at or below the "LOWER LEVEL" line, add distilled water.



■ Adding distilled water

- 1 Remove the vent plug.
- 2 Add distilled water. If the "UPPER LEVEL" line cannot be seen, check the fluid

level by looking directly at the cell.



3 Put the vent plug back on and close securely.

■ Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.

After recharging/reconnecting the battery (vehicles with a smart entry & start system)

The engine may not start. Follow the procedure below to initialize the system.

- 1 Shift the shift lever to P (automatic transmission) or depress the brake pedal with the shift lever in N (manual transmission).
- 2 Open and close any of the doors.
- 3 Restart the engine.
- Unlocking the doors using the smart entry & start system may not be possible immediately after reconnecting the battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- Start the engine with the engine switch in ACCESSORY mode. The engine may not start with the engine switch turned off. However, the engine will operate normally from the second attempt.
- The engine switch mode is recorded by the vehicle. If the battery is reconnected, the vehicle will return the engine switch mode to the status it was in before the battery was disconnected. Make sure to turn off the engine before disconnect the battery. Take extra care when connecting the battery if the engine switch mode prior to discharge is unknown.

If the system will not start even after multiple attempts, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

A CAUTION

Chemicals in the battery

Batteries contain poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.

■Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is not sufficient ventilation.

■ Emergency measures regarding electrolyte

- If electrolyte gets in your eyes Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte Drink a large quantity of water or milk. Get emergency medical attention immediately.

№ NOTICE

■When recharging the battery

Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.


■When adding distilled water


Avoid overfilling. Water spilled during battery recharging may cause corrosion.

Washer fluid

Add washer fluid in any of the following situations:

- A washer does not work.
- The low washer fluid warning light comes on (→P. 630)
- The warning message appears on the multi-information display (vehicles with multi-information display type B and C only: →P. 641)
- The washer fluid level is at "LOW"








The washer fluid level is checked by observing the position of the level on the liquid covered holes in the gauge.

If the level falls below the second hole from the bottom ("LOW" position), refill the washer fluid.



A CAUTION

■When adding washer fluid

Do not add washer fluid when the engine is hot or running as washer fluid contains alcohol and may catch fire if spilled on the engine etc.

NOTICE

Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.

Diluting washer fluid


Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.

Discharging dust valve (if equipped)

Squeeze the rubber cap to remove the dust if the discharging dust valve is dirty.

Shape of the valve differs slightly in accordance with the engine.





■ To prevent damaging the engine

Do not drive with the discharging dust valve removed. Doing so causes excessive engine wear.

تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۸**۸ ۲۲ ۲۸ تلفن

Draining the fuel filter water (diesel engine only)

The water in the fuel filter must be drained immediately if the following symptom occurs:

▶ Vehicles with the multi-information display type A

The fuel system warning light flashes and buzzer sounds or the fuel filter warning light comes on.


▶ Vehicles with the multi-information display type B and C

When the warning message "DRAIN WATER FROM FUEL FILTER" appears on the instrument cluster and buzzer* sounds.

- *: On some models
- 1 Remove the drain plug from the clamp and place a small tray to catch the water.
- 2 Perform the draining as shown in the illustration.
 - 1 Turn the drain plug about 2-2-1/2 turns.

Loosening more than this will cause water oozing from around the drain plug.

② Operate the priming pump until the fuel begins to run out.



3 After draining, retighten the drain plug. Do not use a tool.

-armaSi

AdBlue™ (if equipped)

AdBlueTM is used to reduce the amount of nitrogen oxides in exhaust gas. AdBlueTM is consumed in the process of driving. Therefore, observe the following precautions.

- 1 L (1.1 qt., 0.9 lmp.qt.) of AdBlue™ is consumed every 1000 km (621 miles) to 1500 km (932 miles). Normally, after a full refill, the vehicle can be driven for approximately 15000 km (9321 miles) before all AdBlue™ is depleted.
 - However, $AdBlue^{TM}$ may become completely depleted sooner depending on driving conditions.
- When the possible driving range based on the remaining amount of AdBlue™ reaches approximately 2400 km (1492 miles), the low AdBlue™ level warning light turns on and a warning message is displayed.
- When AdBlue[™] is depleted, the engine cannot be restarted.
- If AdBlue[™] is accidentally spilled while refilling, vehicle parts, paint, etc. may be damaged.


When AdBlue™ needs to be refilled, have it refilled at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

It may be a criminal offence to use a vehicle that does not consume any reagent if it is required for the reduction of emissions.

■ AdBlue[™] warning light and warning message

When AdBlue™ is low, the low AdBlue™ level warning light turns on and a warning message appears on the multi-information display. (→P. 645)

When refilling AdBlue™ by yourself in an emergency, be sure to follow the correct refill procedures. (→P. 562)



- Use AdBlue™ (compliant with ISO 22241-1). AdBlue™ is a trademark of the German Association of the Automotive Industry (VDA).
- Before driving for a long period of time in an area where AdBlue[™] cannot be refilled, consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



When AdBlue™ is low

When AdBlue™ is depleted, the engine cannot be restarted. Be sure to have AdBlue™ refilled at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer before it is completely depleted.



تلفن شبانه روزى: ۱۵۸۰۲۹۸۸۸-۲۱

FarmaSOS.com


7

■ Refilling AdBlue[™] by yourself in an emergency

When the engine cannot be restarted due to the depletion of AdBlueTM, adding approximately 3.8 L (4.0 qt., 3.3 lmp.qt.) or more of AdBlueTM will allow the engine to be started again. Perform the following procedures to refill AdBlueTM. (The AdBlueTM tank has a capacity of 12 L [12.7 qt., 10.6 lmp.qt.].)


- 1 Park the vehicle on a level surface, turn the engine switch off, and then open the hood. (\rightarrow P. 539)
- 2 Open the AdBlue™ tank cap.





Insert a bottle of AdBlue™ and fully tighten it.






AdBlue™ will begin to refill.


Refill AdBlue™ slowly so that it does not spill. Do not remove

the bottle until it is empty.




5 Check that no AdBlue™ remains in the bottle, and then remove it.

Repeat steps 3 to 5 until approximately 3.8 L (4.0 qt., 3.3 lmp.qt.) or more of AdBlueTM have been refilled.



6 Close the AdBlue™ tank cap. Turn the cap until you hear a click.



7 Check that the engine starts.

■When refilling AdBlue™

After refilling AdBlue™, the engine may take a few seconds longer than normal to start. علفن شبانه روزی:



■When refilling AdBlue™

Observe the following precautions.

Failure to do so may result in damage to the vehicle parts, paint, etc.

- Do not use urea solution other than AdBlue™.
- If AdBlue™ is added at a rate of more than 3 L (3.2 qt., 2.6 lmp.qt.) per minute, the AdBlue™ may overflow from the refill port.
 Do not use refilling equipment available at gas stations or elsewhere, as the equipment will add more than 3 L (3.2 qt., 2.6 lmp.qt.) of AdBlue™ per minute.
- If AdBlue™ comes into contact with any painted surfaces on the vehicle, immediately wash the affected areas with water.
- If AdBlue™ is spilled inside the engine compartment, immediately wipe it with a wet cloth.

■When storing AdBlue™

Observe the following precautions.

Failure to do so may result in damage to vehicle parts, paint, etc., and changes in the chemical compounds of $AdBlue^{TM}$ may cause unpleasant odors.


- Do not leave AdBlue™ inside the vehicle.
- Tightly seal AdBlue™ containers and store them in a cool, dry location with good ventilation and no exposure to direct sunlight.

Replace or rotate the tires in accordance with maintenance schedules and treadwear.

Checking tires

Check if the treadwear indicators are showing on the tires. Also check the tires for uneven wear, such as excessive wear on one side of the tread.

Check the spare tire condition and pressure if not rotated.



- 1 New tread
- 2 Worn tread
- (3) Treadwear indicator

The location of treadwear indicators is shown by the "TWI" or " \triangle " marks, etc., molded on the sidewall of each tire.

Replace the tire if the treadwear indicators are showing on a tire.

7


Tire rotation

Rotate the tires in the order shown.

To equalize tire wear and help extend tire life, Toyota recommends that you rotate your tires approximately every 5000 km (3000 miles).

Do not fail to initialize the tire pressure warning system after tire rotation.

- Vehicles with a standard spare tire
- ► Vehicles with an emergency tire puncture repair kit



تلفن شبانه روزی: ۱۳۰۵ - ۲۱ **۸**۸ ۲۲ ۲۸ تلفن

Tire pressure warning system (if equipped)

Your vehicle is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise.

If the tire pressure drops below a predetermined level, the driver is warned by a warning light. $(\rightarrow P. 629)$

Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.


When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. Have tire pressure warning valve and transmitter ID codes registered by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. $(\rightarrow P. 569)$

- ◆ Initializing the tire pressure warning system
- The tire pressure warning system must be initialized in the following circumstances:
 - When changing the tire size. ما تلفن شبانه روزی:
 - When the tire inflation pressure is changed such as when changing traveling speed.

When the tire pressure warning system is initialized, the current tire inflation pressure is set as the benchmark pressure.

■ How to initialize the tire pressure warning system

- 1 Park the vehicle in a safe place and turn the engine switch to the "LOCK" position (vehicles without a smart entry & start system) or off (vehicles with a smart entry & start system).
 - Initialization cannot be performed while the vehicle is moving.
- 2 Adjust the tire inflation pressure to the specified cold tire inflation pressure level. (→P. 735)
 - Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.
- 3 Turn the engine switch to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system).



5 Vehicles without a smart entry & start system: Wait for a few minutes with the engine switch in the "ON" position and then turn the engine switch to the "ACC" or "LOCK" position.

Vehicles with a smart entry & start system: Wait for a few minutes with the engine switch in IGNITION ON mode and then turn the engine switch off.

Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code. Have the ID code registered by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■When to replace your vehicle's tires

Tires should be replaced if:

- The treadwear indicators are showing on a tire.
- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult with any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Replacing tires and wheels (vehicles with the tire pressure warning system)

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 10 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.

■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.

Routine tire inflation pressure checks (vehicles with the tire pressure warning system)

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

■ If the tread on snow tires wears down below 4 mm (0.16 in.)

The effectiveness of the tires as snow tires is lost.

■ Situations in which the tire pressure warning system may not operate properly (if equipped)

- In the following cases, the tire pressure warning system may not operate properly.
 - · If non-genuine Toyota wheels are used.
 - A tire has been replaced with a tire that is not an OE (Original Equipment) tire
 - A tire has been replaced with a tire that is not of the specified size.
 - · Tire chains etc. are equipped.
 - · An auxiliary-supported run-flat tire is equipped.
 - If a window tint that affects the radio wave signals is installed.
 - If there is a lot of snow or ice on the vehicle, particularly around the wheels or wheel housings.
 - If the tire inflation pressure is extremely higher than the specified level.
 - If the spare tire is in a location subject to poor radio wave signal reception.*
 - If a large metallic object which can interfere with signal reception is put near the spare tire.*
 - If tires not equipped with the tire pressure warning valves and transmitters are used.
 - If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
 - *: Vehicles with the spare tire only
- Performance may be affected in the following situations.
 - Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
 - When carrying a portable radio, cellular phone, cordless phone or other wireless communication device
- When the vehicle is parked, the time taken for the warning to start or go off could be extended.
- When tire inflation pressure declines rapidly for example when a tire has burst, the warning may not function.

■ The initialization operation (vehicles with the tire pressure warning system)

- Make sure to carry out initialization after adjusting the tire inflation pressure. Also, make sure the tires are cold before carrying out initialization or tire inflation pressure adjustment.
- If you have accidentally turned the engine switch to the "LOCK" position (vehicles without a smart entry & start system) or off (vehicles with a smart entry & start system) during initialization, it is not necessary to press the reset switch again as initialization will restart automatically when the engine switch has been turned to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system) for the next time.
- If you accidentally press the reset switch when initialization is not necessary, adjust the tire inflation pressure to the specified level when the tires are cold, and conduct initialization again.
- Warning performance of the tire pressure warning system (if equipped)
 The warning of the tire pressure warning system will change in accordance with the conditions under which it was initialized. For this reason, the system may give a warning even if the tire pressure does not reach a low enough level, or if the pressure is higher than the pressure that was adjusted to when the system was initialized.
- ■When initialization of the tire pressure warning system has failed (if equipped)

Initialization can be completed in a few minutes. However, in the following cases, the settings have not been recorded and the system will not operate properly. If repeated attempts to record tire inflation pressure settings are unsuccessful, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

- When operating the tire pressure warning reset switch, the tire pressure warning light does not blink 3 times.
- After driving for a certain period of time since the initialization has been completed, the warning light comes on after blinking for 1 minute.

■ Certification for tire pressure warning system

The latest "DECLARATION of CONFORMITY "(DoC) is available at the following:DoC address: http://www.pacific-ind.co.jp/eng/products/car/tpms/doc/

€0891

Hereby, PACIFIC INDUSTRIAL CO.,LTD., declares that this PMV-C210 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

PACIFIC INDUSTRIAL CO.,LTD. vakuuttaa täten että PMV-C210 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart PACIFIC INDUSTRIAL CO.,LTD. dat het toestel PMV-C210 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente PACIFIC INDUSTRIAL CO.,LTD. déclare que l'appareil PMV-C210 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar PACIFIC INDUSTRIAL CO.,LTD. att denna PMV-C210 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framg år av direktiv 1999/5/EG

Undertegnede PACIFIC INDUSTRIAL CO.,LTD. erklærer herved, at følgende udstyr PMV-C210 overholder de væ sentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

تلفن شبانه روزی: 🔾

Hiermit erklärt PACIFIC INDUSTRIAL CO.,LTD., dass sich das Gerät PMV-C210 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigeneinschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ME THN ПАРОУ Σ A PACIFIC INDUSTRIAL CO.,LTD. Δ H Λ Ω NE | OT | PMV-C210 Σ Y M M O P Φ Ω N E T A | ПРО Σ Т | Σ O Y Σ | Ω Δ E | Σ A П A | T H Σ E | Σ K A | T | Σ Λ O | П E Σ Σ X E T | K E Σ Δ | A T A Ξ E | Σ T H Σ O Δ H Γ | A Σ 1999/5/E K.

Con la presente PACIFIC INDUSTRIAL CO.,LTD. dichiara che questo PMV-C210 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente PACIFIC INDUSTRIAL CO.,LTD. declara que el PMV-C210 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

PACIFIC INDUSTRIAL CO.,LTD. declara que este PMV-C210 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, PACIFIC INDUSTRIAL CO.,LTD., jiddikjara li dan PMV-C210 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab PACIFIC INDUSTRIAL CO.,LTD. seadme PMV-C210 vastavust direktiivi 1999/5/EÜ põhinõ uetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, PACIFIC INDUSTRIAL CO.,LTD. nyilatkozom, hogy a PMV-C210 megfelel a vonatkozó alapvető követelmé nyeknek és az 1999/5/EC irányelv egyéb előírásainak.

PACIFIC INDUSTRIAL CO.,LTD. týmto vyhlasuje, že PMV-C210 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

PACIFIC INDUSTRIAL CO.,LTD. tímto prohlašuje, že tento PMV-C210 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

PACIFIC INDUSTRIAL CO.,LTD. izjavlja, da je ta PMV-C210 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določ ili direktive 1999/5/ES.

Šiuo PACIFIC INDUSTRIAL CO.,LTD. deklaruoja, kad šis PMV-C210 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo PACIFIC INDUSTRIAL CO.,LTD. deklarē, ka PMV-C210 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym PACIFIC INDUSTRIAL CO.,LTD. oświadcza, że PMV-C210 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir PACIFIC INDUSTRIAL CO.,LTD. yfir því að PMV-C210 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

PACIFIC INDUSTRIAL CO.,LTD. erklærer herved at utstyret PMV-C210 er i samsvar med de grunnleggende krav og ø vrige relevante krav i direktiv 1999/5/EF.

С настоящето, PACIFIC INDUSTRIAL CO.,LTD., дек ларира, че PMV-C210 е в съответствие със съществените изисквания и д ругите приложими разпоредби на Директива 1999/5/ЕС.

Prin prezenta, PACIFIC INDUSTRIAL CO.,LTD., declară că aparatul PMV-C210 este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim , PACIFIC INDUSTRIAL CO.,LTD., izjavljuje da ovaj PMV-C210 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Ovim, PACIFIC INDUSTRIAL CO.,LTD., deklariše da je PMV-C210 u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

Ovim PACIFIC INDUSTRIAL CO.,LTD., izjavljuje da je PMV-C210 u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Me anë të kësaj, PACIFIC INDUSTRIAL CO, LTD., Deklaron se ky PMV-C210 është në përputhje me kërkesat themelore dhe dispozitat e tjera përkatëse të direktivës 1999/5/EC.



The latest "DECLARATION of CONFORMITY" (DoC) is available at the following address: http://www.globaldenso.com/en/products/oem/index.html

Hereby, DENSO CORPORATION declares that this 13BDX is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

DENSO CORPORATION vakuuttaa täten että 13BDX tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart DENSO CORPORATION dat het toestel 13BDX in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente DENSO CORPORATION déclare que l'appareil 13BDX est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar DENSO CORPORATION att denna 13BDX står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede DENSO CORPORATION erklærer herved, at følgende udstyr 13BDX overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt DENSO CORPORATION, dass sich das Gerät 13BDX in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ DENSO CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ 13BDX ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/EK.

Con la presente DENSO CORPORATION dichiara che questo 13BDX è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente DENSO CORPORATION declara que el 13BDX cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

DENSO CORPORATION declara que este 13BDX está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, DENSO CORPORATION, jiddikjara li dan 13BDX jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab DENSO CORPORATION seadme 13BDX vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, DENSO CORPORATION nyilatkozom, hogy a 13BDX megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

DENSO CORPORATION týmto vyhlasuje, že 13BDX spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

DENSO CORPORATION tímto prohlašuje, že tento 13BDX je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

DENSO CORPORATION izjavlja, da je ta 13BDX v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo DENSO CORPORATION deklaruoja, kad šis 13BDX atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo DENSO CORPORATION deklarē, ka 13BDX atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym DENSO CORPORATION oświadcza, że 13BDX jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir DENSO CORPORATION yfir því að 13BDX er í samræmi við grunnkröfur og aðrar kröfur; sem gerðar eru í tilskipun 1999/5/EC.

DENSO CORPORATION erklærer herved at utstyret 13BDX er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF. С настоящето, DENSO CORPORATION, декларира, че 13BDX е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, DENSO CORPORATION, declară că aparatul 13BDX este in conformitate cu cerinţele esenţiale şi cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, DENSO CORPORATION, izjavljuje da ovaj 13BDX je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Ovim, DENSO CORPORATION, deklariše da je 13BDX u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

Ovim DENSO CORPORATION, izjavljuje da je 13BDX u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Nepermjet kesaj, DENSO CORPORATION, deklaroj qe ky 13BDX eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tjera perkatese te Direktives 1999/5/EC.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ الفن شبانه روزی



CAUTION

■When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Toyota.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle. Do not use tires if you do not know how they were used previously.

■ When initializing the tire pressure warning system (if equipped)

Do not operate the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

↑ NOTICE

- Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps (vehicles with the tire pressure warning system)
 - When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.
 - Make sure to install the tire valve caps. If the tire valve caps are not installed, water could enter the tire pressure warning valves and the tire pressure warning valves could be bound.
 - When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.
- To avoid damage to the tire pressure warning valves and transmitters (vehicles with the tire pressure warning system)

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer or other qualified service shop as soon as possible. After use of liquid sealant, make sure to replace the tire pressure warning valve and transmitter when repairing or replacing the tire. (\rightarrow P. 567)

■ Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes. These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

If tire inflation pressure of each tire becomes low while driving Do not continue driving, or your tires and/or wheels may be ruined.

Tire inflation pressure

Make sure to maintain the proper tire inflation pressure. Tire inflation pressure should be checked at least once per month. However, Toyota recommends that tire inflation pressure be checked once every two weeks. $(\rightarrow P. 735)$

■ Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel economy
- Reduced driving comfort and poor handling
- Reduced tire life due to wear
- Reduced safety
- Damage to the drive train

If a tire needs frequent refilling, have it checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold. If your vehicle has been parked for at least 3 hours and has not been driven for more than 1.5 km or 1 mile, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge.
 It is difficult to judge if a tire is properly inflated based only on its appearance.
- It is normal for the tire inflation pressure to be higher after driving as heat is generated in the tire. Do not reduce tire inflation pressure after driving.
- Passengers and luggage weight should be placed so that the vehicle is balanced.

A CAUTION

■ Proper inflation is critical to save tire performance

Keep your tires properly inflated.

If the tires are not properly inflated, the following conditions may occur which could lead to an accident resulting in death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Air leaking from between tire and wheel
- Wheel deformation and/or tire damage
- Greater possibility of tire damage while driving (due to road hazards, expansion joints, sharp edges in the road, etc.)



■When inspecting and adjusting tire inflation pressure

Be sure to put the tire valve caps back on.

If a valve cap is not installed, dirt or moisture may get into the valve and cause an air leak, resulting in decreased tire inflation pressure.

Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced.

Otherwise, the tire may separate from the wheel or cause loss of handling control.

Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width, and inset*.

Replacement wheels are available at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Toyota does not recommend using the following:

- *: Conventionally referred to as "offset".
- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

Aluminum wheel precautions (if equipped)

- Use only Toyota wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1600 km (1000 miles).
- Be careful not to damage the aluminum wheels when using tire chains.
- When balancing your wheels, use only Toyota genuine balance weights or the equivalent. If clip-on balance weights are being used, use a plastic or rubber hammer to install the weight.

■When replacing wheels (vehicles with the tire pressure warning system)

The wheels of your Toyota are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. (\rightarrow P. 567)


A CAUTION

When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

■When installing the wheel nuts

• Be sure to install the wheel nuts with the tapered ends facing inward. Installing the nuts with the tapered ends facing outward can cause wheel to break and eventually cause the wheel to come off while driving, which could lead to an accident resulting in death or serious injury.



• Never use oil or grease on the wheel bolts or wheel nuts.
Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts.

■ Use of defective wheels prohibited

Do not use cracked or deformed wheels.

Doing so could cause the tire to leak air during driving, possibly causing an accident.

- Replacing tire pressure warning valves and transmitters (vehicles with the tire pressure warning system)
 - Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
 - Ensure that only genuine Toyota wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.

امداد حودرو فارما


تلفن شبانه روزی: ۱-۲۱-۸۸۸۶۲ ۲۲ م

Air conditioning filter

The air conditioning filter must be changed regularly to maintain air conditioning efficiency.


Removal method

- 1 Vehicles without a smart entry & start system: Turn the engine switch to the "LOCK" position. Vehicles with a smart entry & start system: Turn the engine switch off.
- 2 Open the glove box. Slide off the damper.




3 Push in each side of the glove box to disconnect the claws.





The "↑UP" marks shown on the filter should be pointing up.



■ Changing interval

Inspect and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, early replacement may be required. (For scheduled maintenance information, please refer to the "Toyota Service Booklet" or "Toyota Warranty Booklet".)

■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.



■When using the air conditioning system

Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

7

Maintenance and care

Wireless remote control/electronic key battery

Replace the battery with a new one if it is depleted.

You will need the following items:

- Flathead screwdriver
- Small flathead screwdriver (vehicles with a smart entry & start system)
- Lithium battery

Vehicles without a smart entry & start system (type A): CR2032 Vehicles without a smart entry & start system (type B): CR2016 Vehicles with a smart entry & start system: CR1632


Replacing the battery

- ▶ Vehicles without a smart entry & start system (type A)
- 1 Remove the cover using a coin protected with tape etc.




Remove the depleted battery using the tip of a ball-point pen or a similar pointed object.

Insert a new battery with the "+" terminal facing up.



1 Remove the cover.

To prevent damage to the key, cover the tip of the screwdriver with a rag.




2 Remove the module.




3 Open the case cover using a coin protected with tape etc. and remove the depleted battery.

Insert a new battery with the "+" terminal facing up.






- ▶ Vehicles with a smart entry & start system
- 1 Take out the mechanical key.




2 Remove the cover.

To prevent damage to the key, cover the tip of the screwdriver with a rag.



3 Remove the depleted battery. Insert a new battery with the "+" terminal facing up.



■ Use the following types of lithium battery

Vehicles without a smart entry & start system (type A): CR2032 Vehicles without a smart entry & start system (type B): CR2016 Vehicles with a smart entry & start system: CR1632

- Batteries can be purchased at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer, local electrical appliance shops or camera stores.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the local laws.

■ If the key battery is depleted

The following symptoms may occur:

- The smart entry & start system (if equipped) and wireless remote control will not function properly.
- The operational range will be reduced.



■ Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.

Certification for the key battery

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

NOTICE ALMS

For normal operation after replacing the battery

Observe the following precautions to prevent accidents:


- Always work with dry hands.
 Moisture may cause the battery to rust.
- Do not touch or move any other component inside the remote control.
- Do not bend either of the battery terminals.

Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.


- 1 Vehicles without a smart entry & start system: Turn the engine switch to the "LOCK" position. Vehicles with a smart entry & start system: Turn the engine switch off.
- 2 Open the fuse box cover.
 - ► Engine compartment

Push the tab in and lift the lid off.




▶ Driver's side instrument panel

Remove the lid.



Only type A fuse can be removed using the pullout tool.



- 4 Check if the fuse is blown.
 - 1 Normal fuse
 - 2 Blown fuse

Type A


Replace the blown fuse with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

Type B, C, D and E

Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.


▶ Type A









▶ Type C



▶ Type D



▶ Type E



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

■ After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P. 596)
- If the replaced fuse blows again, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ If there is an overload in a circuit

The fuses are designed to blow, protecting the wiring harness from damage.



■ To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than indicated, or use any other object in place of a fuse.
- Always use a genuine Toyota fuse or equivalent.
 Never replace a fuse with a wire, even as a temporary fix.
- Do not modify the fuses or fuse boxes.



■ Before replacing fuses

Have the cause of electrical overload determined and repaired by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible.

Light bulbs

You may replace the following bulbs yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

For more information about replacing other light bulbs, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Preparing for light bulb replacement


Check the wattage of the light bulb being replaced. (→P. 737)

Removing the engine compartment covers

→P. 544

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸ الا


■ Front




- 1 Headlight high beam
- 4 Front fog light (if equipped)
- 2 Front position light (halogen headlights)
- (5) Front turn signal light
- ③ Headlight low beam/daytime running lights (halogen headlights)
 - تلفن شبانه روزی: ۱۵۸ ۲۶

■ Rear

▶ Vehicles with under floor mounted spare tire




- 1 Running board lights (if equipped)
- 3 Back-up light
- 4 Rear fog light (if equipped)
- ② Rear turn signal light
- 5 License plate lights
- ▶ Vehicles with back door mounted spare tire




- ① Running board lights (if equipped)
- ② Rear turn signal light
- 3 Back-up light
- 4 Rear fog light (if equipped)
- 5 License plate lights

Replacing light bulbs

- Headlight low beams/daytime running lights (halogen headlights)
- 1 Turn the bulb base counterclockwise.



2 Unplug the connector while pushing the lock release.



3 Replace the light bulb, and install the bulb base.

Align the 3 tabs on the light bulb with the mounting, and insert.






Shake the bulb base gently to check that it is not loose, turn the headlights on once and visually confirm that no light is leaking through the mounting.




■ Headlight high beams

1 Turn the bulb base counterclockwise.




2 Unplug the connector while pushing the lock release.





3 Replace the light bulb, and install the bulb base.


Align the 3 tabs on the light bulb with the mounting, and insert.



FarmaS

4 Turn and secure the bulb base.


Shake the bulb base gently to check that it is not loose, turn the headlights on once and visually confirm that no light is leaking through the mounting.




■ Front position lights (halogen headlights)

1 Turn the bulb base counterclockwise.

The shape of the bulb base differs slightly on the left and right



2 Remove the light bulb.




3 When installing, reverse the steps listed.



■ Front turn signal lights

1 Remove the fender liner bolts.


To allow enough working space, turn the steering wheel to the opposite side of the bulb to be replaced.




2 Open the fender liner.




- 3 Turn the bulb base counterclockwise.
 - ► Vehicles with halogen head-
 ► Vehicles with LED headlights lights





- 4 Remove the light bulb.
- ► Vehicles with halogen headlights
- ▶ Vehicles with LED headlights






5 When installing, reverse the steps listed.

■ Front fog lights (if equipped)

- 1 Remove the fender liner bolts and open the fender liner. (→P. 602)
- 2 Unplug the connector while pushing the lock release.




3 Turn the light bulb counterclockwise.



4 Replace the light bulb. Align the 3 tabs on the light bulb with the mounting, and insert.




5 Turn and secure the bulb base.



6 Install the bulb base.

Shake the bulb base gently to check that it is not loose, turn the fog lights on once and visually confirm that no light is leaking through the mounting.




7 When installing the cover, conduct 1 in reverse.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

■ Rear turn signal lights and back-up lights

- 1 Open the back door.
 - ▶ Left-hand side

Remove the bolts and lamp assembly.



- ▶ Right-hand side ▲
- 1 Remove the bolts.




2 Close the back door half way and remove the lamp


assembly.



- 2 Unplug the connector while pushing the lock release.
- IIB6PD024
- 3 Turn the bulb bases counterclockwise.
 - ① Rear turn signal light
 - 2 Back-up light



- 4 Remove the light bulb.
 - 1 Rear turn signal light
 - ② Back-up light




5 When installing, reverse the steps listed.


Maintenance and care

■ Rear fog lights (if equipped)


1 Remove the under cover bolts and pull down the under cover.



2 Turn the bulb base counter-clockwise.



3 Remove the light bulb.



4 When installing, reverse the steps listed.


- ▶ Vehicles with under floor mounted spare tire and without spare tire
- Remove the screws.

 Remove the lens and

Remove the lens and the license plate light unit.




2 Remove the light bulb.



3 When installing, reverse the steps listed. تلفن شبانه روزي

- ▶ Vehicles with back door mounted spare tire
- 1 Remove the screws.

Remove the lens and the license plate light unit.



2 Remove the light bulb.




3 When installing, reverse the steps listed.


تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ م

■ Running board lights (if equipped)

1 Turn the bulb bases counterclockwise.



2 Remove the light bulb.



- 3 When installing, reverse the steps listed.
- Lights other than the above

If any of the lights listed below has burnt out, have it replaced by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

- Headlight low beams (LED headlights)
- Front position lights/daytime running lights (LED headlights)
- Side turn signal lights
- High mounted stoplight
- Stop/tail lights

■ LED lights

The headlight low beams (LED headlights), front position lights/daytime running lights (LED headlights), side turn signal lights, high mounted stoplight, stop/tail lights consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer to have the light replaced.

■ Condensation build-up on the inside of the lens

Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for more information in the following situations:

- Large drops of water are built up on the inside of the lens.
- Water has built up inside the headlight.



A CAUTION

Replacing light bulbs

- Turn off the headlights. Do not attempt to replace the bulb immediately after turning off the headlights.
 - The bulbs become very hot and may cause burns.
- Do not touch the glass portion of the light bulb with bare hands. When it is unavoidable to hold the glass portion, use and hold with a clean dry cloth to avoid getting moisture and oils on the bulb.
 - Also, if the bulb is scratched or dropped, it may blow out or crack.
- Fully install light bulbs and any parts used to secure them. Failure to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.
- Do not attempt to repair or disassemble light bulbs, connectors, electric circuits or component parts.
 - Doing so may result in death or serious injury due to electric shock.

To prevent damage or fire

- Make sure bulbs are fully seated and locked.
- Check the wattage of the bulb before installing to prevent heat damage.

When trouble arises


8-1.	Essential information	If you have a flat tire
	Emergency flashers614	(vehicles with a
	If your vehicle has to	spare tire)653
	be stopped in an _	If you have a flat tire
	emergency615	(vehicles without a
8-2.	Steps to take in an	spare tire)672
	emergency	If the engine will
	If your vehicle needs	not start689
	to be towed617	If the electronic key does
	If you think something	not operate properly
	is wrong623	(vehicles with a
	Fuel pump shut off system	smart entry & start system)691
	(gasoline engine only)624	If the vehicle battery
	If a warning light	is discharged694
	turns on or a warning	If your vehicle
	buzzer sounds625	overheats701
	If a warning message	If you run out of fuel
	is displayed636	and the engine stalls
		(diesel engine only)704
		If the vehicle becomes
		stuck705

Emergency flashers

The emergency flashers are used to warn other drivers when the vehicle has to be stopped in the road due to a breakdown, etc.

Press the switch.

All the turn signal lights will flash. To turn them off, press the switch once again.



■ Emergency flashers

If the emergency flashers are used for a long time while the engine is not operating, the battery may discharge.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸ الا


If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

- 1 Steadily step on the brake pedal with both feet and firmly depress it.

 Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.
- 2 Shift the shift lever to N.
- ▶ If the shift lever is shifted to N
- 3 After slowing down, stop the vehicle in a safe place by the road.
- 4 Stop the engine.
- ▶ If the shift lever cannot be shifted to N
- 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- Wehicles without a smart entry & start system:


 Stop the engine by turning the engine switch to the "ACC" position.



When trouble arises

Vehicles with a smart entry & start system:

To stop the engine, press and hold the engine switch for 2 consecutive seconds or more, or press it briefly 3 times or more in succession.



5 Stop the vehicle in a safe place by the road.



A CAUTION

■ If the engine has to be turned off while driving

- Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.
- Vehicles without a smart entry & start system: Never attempt to remove the key, as doing so will lock the steering wheel.

تلفن شبانه روزی: ۱۵۸۰۲۶۸۸۸–۲۱۰

If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer or commercial towing service, using a wheel-lift type truck or a flatbed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

Situations when it is necessary to contact dealers before towing

The following may indicate a problem with your transmission. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer or commercial towing service before towing.

- The engine is running but the vehicle does not move.
- The vehicle makes an abnormal sound.

Towing with a sling-type truck


Do not tow with a sling-type truck to prevent body damage.




8

Towing with a wheel-lift type truck

▶ From the front



▶ From the rear




Use a towing dolly under the rear wheels.

Use a towing dolly under the front wheels.

Using a flatbed truck


If your vehicle is transported by a flatbed truck, it should be tied down at the locations shown in the illustration.





If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.



Emergency towing

If a tow truck is not available in an emergency, your vehicle may be temporarily towed using cables or chains secured to the emergency towing hooks. This should only be attempted on hard surfaced roads for at most 80 km (50 miles) at under 30 km/h (18 mph).


A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.

For vehicles with an automatic transmission, only the front towing hooks may be used.


Emergency towing procedure

1 Securely attach cables or chains to the towing hooks.

Take care not to damage the vehicle body.







2 Vehicles without a smart entry & start system: Enter the vehicle being towed and start the engine.

If the engine does not start, turn the engine switch to the "ON" position.

Vehicles with a smart entry & start system: Enter the vehicle being towed and start the engine.

If the engine does not start, turn the engine switch to IGNITION ON mode

- 3 2TR-FE engine: Put the four-wheel drive control switch in H4F. (The center differential is unlocked.)*
 - 1GR-FE, 1GD-FTV and 1KD-FTV engines: Put the four-wheel drive control switch in H4 and push the center differential lock/unlock switch to unlock the center differential.*
- 4 Vehicles with the rear height control air suspension: Put the vehicle height in the N mode and press the height control OFF button to turn off the rear height control air suspension.*
- Shift the shift lever to N and release the parking brake. When the shift lever cannot be shifted (vehicles with an automatic transmission): →P. 262
 - *: Refer to the "Off-road Driving Owner's Manual"

■While towing

If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.




A CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

■When towing the vehicle

Be sure to transport the vehicle with all four wheels raised off the ground. If the vehicle is towed with the tires contacting the ground, the drivetrain or related parts may be damaged, the vehicle may fly off the truck.





■While towing

- When towing using cables or chains, avoid sudden starts, etc. which place excessive stress on the towing hook, cables or chains. The towing hook, cables or chains may become damaged, broken debris may hit people, and cause serious damage.
- Vehicles without a smart entry & start system: Do not turn the engine switch to the "LOCK" position.
 - There is a possibility that the steering wheel is locked and cannot be operated.
- Vehicles with a smart entry & start system: Do not turn the engine switch to the off.

There is a possibility that the steering wheel is locked and cannot be operated.

↑ NOTICE

- ■To prevent damage to the vehicle when towing using a wheel-lift type truck
 - Vehicles without a smart entry & start system: Do not tow the vehicle from the rear when the engine switch is in the "LOCK" position or the key is removed. The steering lock mechanism is not strong enough to hold the front wheels straight.
 - Vehicles with a smart entry & start system: Do not tow the vehicle from the rear when the engine switch is off. The steering lock mechanism is not strong enough to hold the front wheels straight.
 - When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.
- To prevent damage to the vehicle when towing with a sling-type truck

 Do not tow with a sling-type truck, either from the front or rear.
- To prevent damage to the vehicle during emergency towing

 Do not secure cables or chains to the suspension components.

تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible.

Visible symptoms

- Fluid leaks under the vehicle (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points higher than normal

Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

Operational symptoms

- Engine missing, stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

Fuel pump shut off system (gasoline engine only)

To minimize the risk of fuel leakage when the engine stalls or when an airbag inflates upon collision, the fuel pump shut off system stops the supply fuel to the engine.

Follow the procedure below to restart the engine after the system is activated.

- ▶ Vehicles without a smart entry & start system
- 1 Turn the engine switch to the "ACC" or "LOCK" position.
- 2 Restart the engine.
- ▶ Vehicles with a smart entry & start system
- 1 Turn the engine switch to ACCESSORY mode or turn it off.
- 2 Restart the engine.

↑ NOTICE

■ Before starting the engine

Inspect the ground under the vehicle.

If you find that fuel has leaked onto the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Warning light and warning buzzer list

Warning light	Warning light/Details/Actions			
(①)	Brake system warning light (warning buzzer)*1 Indicates that: • The brake fluid level is low; or • The brake system is malfunctioning. → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. Continuing to drive the vehicle may be dangerous.			
	Charging system warning light Indicates a malfunction in the vehicle's charging system. → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.			
(If equipped)	Low engine oil pressure warning light Indicates that the engine oil pressure is too low → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.			
Ţ	 Malfunction indicator lamp Indicates a malfunction in: • The electronic engine control system; • The electronic throttle control system; or • The electronic automatic transmission control system. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately. 			

Warning light	Warning light/Details/Actions
×	SRS warning light Indicates a malfunction in: • The SRS airbag system; or • The seat belt pretensioner system. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
(ABS)	 ABS warning light Indicates a malfunction in: • The ABS; or • The brake assist system → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
(If equipped)	Power steering system warning light Indicates a malfunction in the power steering system → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
PCS (Flashes) (If equipped)	Pre-crash safety system warning light Indicates a malfunction in the pre-crash safety system. The warning light will operate as follows, even when the system is not malfunctioning: • The light will flash quickly when the system is operating. (→P. 390) • The light will turn on when the pre-crash braking is disabled. (→P. 391) • The light will turn on when the system cannot temporarily be used. (→P. 642) → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
(yellow) (If equipped)	Cruise control warning light Indicates a malfunction in the cruise control → P. 304

Warning light	Warning light/Details/Actions
	Slip indicator light Indicates a malfunction in: • The VSC system; • The trailer sway control system (If equipped); • The TRC system; • Active TRC system; • The downhill assist control system (If equipped); • The hill-start assist control (If equipped); • The Multi-terrain Select (If equipped); • The Crawl Control. The light will flash when any of the above systems other than the Multi-terrain Select are operating. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
A/T OIL TEMP (If equipped)	Automatic transmission fluid temperature warning light Indicates that the automatic transmission fluid temperature is too high if the light comes on. Immediately stop the vehicle in a safe place, shift the shift lever to P and wait until the light goes off. If the light goes off, you may start the vehicle again. If the warning light do not go off, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. Indicates a malfunction in the automatic transmission system if the light flashes. Immediately stop the vehicle in a safe place, shift the shift lever to P and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
KDSS warning light Indicates a malfunction in KDSS → Have the vehicle inspected by any authorized To retailer or Toyota authorized repairer, or any rel repairer immediately.	
T-BELT (If equipped)	Timing belt replacement warning light Indicates that the timing belt should be replaced. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Warning light	Warning light/Details/Actions
(If equipped)	Fuel filter warning light Indicates that the amount of accumulated water in the fuel filter has reached the specified level → P. 559
AdBlue (If equipped)	Low AdBlue™ level warning light Insufficient level of AdBlue™ → Have AdBlue™ refilled at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
(If equipped) (Comes on or flashes)	 Fuel system warning light (warning buzzer) The amount of accumulated water in the fuel filter has reached the specified level if the light flashes. → P. 559 Malfunction in the fuel system if the light comes on. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately. The buzzer will sound at the same time the warning light flashes.
	Open door warning light (warning buzzer)*2 Indicates that a side door, the hood or the back door is not fully closed → Check that all the doors, the hood and the back door are closed.
	Low fuel level warning light Vehicles without sub fuel tank: Indicates that remaining fuel is approximately 13.0 L (3.4 gal., 2.8 lmp.gal.) or less if the light comes on. Vehicles with sub fuel tank: Indicates that remaining fuel is approximately 22.0 L (5.8 gal., 4.8 lmp.gal.) or less if the light comes on.
	Indicates a malfunction in the fuel pump of the sub fuel tank if the light flashes. → Refuel the vehicle.

Warning light	Warning light/Details/Actions
Å	Driver's and front passenger's seat belt reminder light (warning buzzer)*3 Warns the driver and/or front passenger to fasten their seat belts → Fasten the seat belt. If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.
(If equipped)	Low engine oil level warning light Indicates that engine oil level is low (This warning light may come on if the vehicle is stopped on a slope. Move the vehicle to a level surface and check to see if the light goes off.) → Check the level of engine oil and add more oil if nec- essary.
(If equipped)	Master warning light A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunction. → P. 636
(If equipped)	Tire pressure warning light When the light comes on: Low tire inflation pressure such as • Natural causes (→P. 634) • Flat tire (→P. 653, 672) → Adjust the tire inflation pressure to the specified level. The light will turn off after a few minutes. In case the light does not turn off even if the tire inflation pressure is adjusted, have the system checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. When the light comes on after blinking for 1 minute: Malfunction in the tire pressure warning system → Have the system checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Warning light	Warning light/Details/Actions		
(If equipped)	Low windshield washer fluid warning light Low level of washer fluid → Fill the tank.		
(If equipped)	LED headlight warning light Indicates a malfunction in the LED headlights The LED headlights will not normally illuminate when there is a malfunction, however it may be able to illuminate depending on the nature of the problem. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately. Automatic headlight leveling system warning light Indicates a malfunction in the automatic headlight leveling system → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.		
(If equipped)			
(Flashes) (If equipped)	Toyota parking assist-sensor indicator (warning buzzer)*4 Indicates a malfunction in Toyota parking assist-sensor → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.		
(If equipped)	Toyota parking assist-sensor indicator (warning buzzer)*5 Indicates that Toyota parking assist-sensor is dirty or covered with ice. → Clean the sensors.		

When trouble arises

- *1: Parking brake engaged warning buzzer:A buzzer will sound if the vehicle is driven at a speed of approximately 5 km/h (3 mph) or more.
- *2: Open door warning buzzer:

 The open door warning buzzer sounds to alert one or more of the doors is not fully closed (with the vehicle having reached a speed of 5 km/h [3 mph]).
- *3: Driver's and front passenger's seat belt reminders:

 The driver's and front passenger's seat belts reminder sounds to alert the driver and front passenger that his/her seat belt is not fastened. The buzzer sounds for 30 seconds after the vehicle has reached a speed of at least 20 km/h (12 mph). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 90 more seconds.
- *4: The corner and center indicators flash after the indicator for the malfunctioning sensor flashes and the vehicle indicator turns off while the buzzer sounds for approximately 8 seconds.
- *5: The corner and center indicators turn on and remain on after the indicator for the malfunctioning sensor turns on and the vehicle indicator turns off while the buzzer sounds for approximately 7 seconds.



Smart entry & start system warning light and buzzer procedures (If equipped)

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Interior buzzer	Exterior buzzer	Warning light	Details/Actions
Continu- ous	Continu- ous	-i-a	Indicates that the driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was not in P (automatic transmission) or N (manual transmission) and the engine switch was not turned off. → Shift the shift lever to P. Bring the electronic key back into the vehicle.
Once	3 times	- ! -1	Indicates that the driver's door has been opened or closed with the engine switch in any mode other than off, the shift lever was in P (automatic transmission) or N (manual transmission) and the electronic key outside of the detection area. → Turn the engine switch off. Bring the electronic key back into the vehicle.
Once	Sounds once for 5 sec- onds	(Comes on for about 60 seconds.)	Indicates that the engine switch in any mode other than off, the shift lever was in P (automatic transmission), the electronic key outside of the detection area and attempt to lock the vehicle with smart entry & start system. → Turn the engine switch off. Bring the electronic key back into the vehicle.

Interior buzzer	Exterior buzzer	Warning light	Details/Actions
Once	Sounds 3 times	~ i •0	Indicates that a door other than the driver's door has been opened or closed with the engine switch in any mode other than off, the shift lever was in P (automatic transmission) or N (manual transmission) and the electronic key outside of the detection area. → Turn the engine switch off. Bring the electronic key back into the vehicle.
Once	_	⊸j- a	Indicates the electronic key is not present when attempting to start the engine. → Confirm the location of the electronic key

Front passenger detection sensor and passenger seat belt reminder

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash, even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.
- If the low speed four-wheel drive indicator light or the center differential lock indicator light blinks

Take the specified steps. (→Refer to the "Off-road Driving Owner's Manual")

■When the tire pressure warning light comes on (vehicles with the tire pressure warning system)

Inspect the appearance of the tire to check that the tire is not punctured.

If the tire is punctured: \rightarrow P. 653, 672

If the tire is not punctured:

Carry out the following procedure after the tire temperature has lowered sufficiently.

- Check the tire inflation pressure and adjust to the appropriate level.
- If the warning light does not go out even after several minutes, check that the tire inflation pressure is at the specified level and carry out initialization.(→P. 568)

The warning light may come on again if the above operations are conducted without first allowing the tire temperature to lower sufficiently.

■The tire pressure warning light may come on due to natural causes (vehicles with the tire pressure warning system)

The tire pressure warning light may come on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

■When a tire is replaced with a spare tire (vehicles with a spare tire and the tire pressure warning system)

The tire pressure warning light will turn on if the tire inflation pressure of the spare tire is low. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire.

■ Conditions that the tire pressure warning system may not function properly (vehicles with the tire pressure warning system)

→P. 570

■ If the tire pressure warning light frequently comes on after blinking for 1 minute (vehicles with the tire pressure warning system)

If the tire pressure warning light frequently comes on after blinking for 1 minute when the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or IGNITION ON mode (vehicles with a smart entry & start system), have it checked by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ Warning buzzer

In some cases, the buzzer may not be heard because of noisy place or an audio sound. ٢ ١ – ٨ ٨ ٤ ٢ + ٨ ٨ تلفن شبانه روزي:

A CAUTION

■ If both the ABS and the brake system warning lights remain on

Stop your vehicle in a safe place immediately and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. The vehicle will become extremely unstable during braking, and the ABS system may fail, which could cause an accident resulting in death or serious injury.

■When the power steering system warning light comes on

The steering wheel may become extremely heavy.

If the steering wheel becomes heavier than usual when operating, hold firmly and operate using more force than usual.

If the tire pressure warning light comes on (vehicles with the tire pressure warning system)

Be sure to observe the following precautions. Failure to do so could cause a loss of vehicle control and result in death or serious injury.

- Stop your vehicle in a safe place as soon as possible. Adjust the tire inflation pressure immediately.
- If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If a tire is flat, change it with the spare tire and have the flat tire repaired by the nearest authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Avoid abrupt maneuvering and braking. If the vehicle tires deteriorate, you
 could lose control of the steering wheel or the brakes.
- If a blowout or sudden air leakage should occur (vehicles with the tire pressure warning system)

The tire pressure warning system may not activate immediately.



NOTICE

■ To ensure the tire pressure warning system operates properly (vehicles with the tire pressure warning system)

Do not install tires with different specifications or makers, as the tire pressure warning system may not operate properly.

If the fuel filter warning light comes on

Never drive the vehicle with the warning light on. Continued driving with water accumulated in the fuel filter will damage the fuel injection pump.

8

If a warning message is displayed*


The multi-information display shows warnings of system malfunctions, incorrectly performed operations, or shows messages that indicate a need for maintenance.

If a warning is shown on the multi-information display, stay calm and perform the following actions:

Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

2 Multi-information display



If any of the warning lights comes on again after the following actions have been performed, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

تلفن شبانه روزی: ۲۱-۸۸۸۶۲۰۲۵

Warning message and warning buzzer list

Warning message	Details/Actions
BRAKE! PCS (Flashes rapidly) (If equipped)	 Indicates that: There is a high possibility of a frontal collision; or The pre-crash braking function is operating A buzzer also sounds. → Slow the vehicle by applying the brakes.
100 km/h	Indicates that your vehicle is nearing the vehicle ahead (in vehicle-to-vehicle distance mode) A buzzer also sounds. → Slow the vehicle by applying the brakes.
	Indicates that one or more of the doors is not fully closed The system also indicates which doors are not fully closed. If the vehicle reaches a speed of 5 km/h (3 mph),
(If equipped)	Indicates that the glass hatch is not fully closed If the vehicle reaches a speed of 5 km/h (3 mph),

Warning message	Details/Actions
CHECK SONAR SYSTEM	Indicates a malfunction in the Toyota parking assists-sensor All assist-sensors flash. A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
CLEAN SONAR (If equipped)	Indicates that a Toyota parking assist-sensor is dirty or covered with ice A buzzer also sounds. → Clean the sensor.
RELEASE PARKING BRAKE (Flashes)	Indicates that the vehicle is being driven at 5 km/h (3 mph) or more with the parking brake still engaged A buzzer also sounds: → Release the parking brake.
CLEAN RADAR SENSOR (If equipped)	Indicates that the radar cruise control sensor is dirty or covered with ice A buzzer also sounds. → Clean the grill and the sensor if they are dirty.
CRUISE CONTROL NOT AVAILABLE (If equipped)	Indicates that the radar cruise control system is unable to judge vehicle-to-vehicle distance A buzzer also sounds. → Turn off second start mode. If the windshield wipers are on, turn them off or set them to a mode other than AUTO or high speed wiper operation.

Warning message	Details/Actions
BSM NOT AVAILABLE (If equipped)	Indicates that the BSM (Blind Spot Monitor) system sensor or the surrounding area on the bumper is dirty or covered with ice A buzzer also sounds. → Clean the sensor and its surrounding area on the bumper.
CHECK CRUISE CONTROL SYSTEM	Indicates a malfunction in: • The cruise control system (if equipped); or • The dynamic radar cruise control system (if equipped) Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system. A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
CHECK STEERING LOCK SYSTEM (If equipped)	Indicates a malfunction in the steering lock system A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
CHECK CLUTCH SWITCH (If equipped)	Indicates a malfunction in the clutch switch system → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
CHECK PCS SYSTEM PCS (Flashes) (If equipped)	Indicates a malfunction in the PCS (Pre-Crash Safety system) A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Warning message	Details/Actions
CHECK BSM SYSTEM (If equipped)	Indicates a malfunction in the BSM (Blind Spot Monitor) system A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
ENGINE OIL PRESSURE LOW	Indicates abnormal engine oil pressure The warning light may come on if the engine oil pressure is too low. A buzzer also sounds. → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
HIGH TRANSMISSION FLUID TEMPERATURE (If equipped)	Indicates that the automatic transmission fluid temperature is too high A buzzer also sounds. → Immediately stop the vehicle in a safe place, shift the shift lever to P and wait until the warning message and light go off, If the warning message and light go off, you may start the vehicle again. If the warning message and light do not go off, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
CHECK TRANSMISSION SYSTEM	Indicates a malfunction in the automatic transmission system A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
MOONROOF OPEN (Flashes) (If equipped)	Indicates that the moon roof is not fully closed (with the engine switch off, and the driver's door open) A buzzer also sounds. → Close the moon roof.

Warning message	Details/Actions
ENGINE OIL LOW	Indicates that engine oil level is low This message may appear if the vehicle is stopped on a slope. Move the vehicle to a level surface and check to see if the message disappears. A buzzer also sounds. → Check the level of engine oil, and add if necessary.
CHECK HEADLIGHT SYSTEM	Indicates a malfunction in the LED headlights The LED headlights will not normally illuminate when there is a malfunction, however it may be able to illuminate depending on the nature of the problem A buzzer also sounds. → Have the vehicle inspected by any autho- rized Toyota retailer or Toyota authorized repairer, or any reliable repairer immedi- ately.
CHECK HEADLIGHT SYSTEM (If equipped)	Indicates a malfunction in the automatic headlight leveling system A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
LOW WASHER FLUID (If equipped)	Indicates that the washer fluid level is low → Add washer fluid.
DRAIN WATER FROM FUEL FILTER	Indicates that the amount of accumulated water in the fuel filter has reached the specified level A buzzer also sounds. → Drain the water from the fuel filter. (→P. 559)
CHECK FUEL SYSTEM	Indicates that remaining fuel is approximately 10 L (2.6 gal., 2.2 lmp. gal.) or less A buzzer also sounds. → Refuel the vehicle.

Warning message	Details/Actions
PCS TEMPORARILY NOT AVAILABLE PCS (If equipped)	Indicates that the PCS (Pre-Crash Safety system) is not currently functional because the grille cover or the sensor is dirty → • Check the grille cover and the sensor and clean them if they are dirty. • In case of overheating, the system will become functional once the system cools down.
CHECK AIR SUSPENSION SYSTEM (If equipped)	Indicates a malfunction in the rear height control air suspension A buzzer also sounds. → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
CRAWL NOT AVAILABLE SELECT L4 AND SHIFT TO D OR R POSITION (If equipped)	Indicates that the Crawl Control is not available → Select the four-wheel driving position switch in L4 and shift the shift lever to "D" or "R".
CRAWL NOT AVAILABLE CHECK SYSTEM OPERATION CONDITIONS (If equipped)	الفن شبانه روزی: Indicates that the Crawl Control is not available → Confirm the operating conditions of the Crawl Control.
CRAWL HAS BEEN DEACTIVATED (If equipped)	Indicates that the Crawl Control is canceled while in use A buzzer also sounds. → Use Crawl Control under the proper operating conditions. Refer to the "Off-road Driving Owner's Manual" for more information regarding Crawl Control.
FUEL FILTER MAINTENANCE REQUIRED (If equipped)	Indicates a malfunction in the fuel system A buzzer also sounds. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

Warning message	Details/Actions	
T-BELT MAINTENANCE REQUIRED (If equipped)	Indicates that the timing belt is scheduled to be changed. → Have the timing belt checked and/or changed by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.	
(If equipped)	Indicates a malfunction in the four-wheel drive system if the light continues flashing → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. Refer to the "Off-road Driving Owner's Manual".	
(If equipped)	Indicates a malfunction in the rear differential lock system if the light continues flashing → Immediately stop the vehicle in a safe place and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. Refer to the "Off-road Driving Owner's Manual".	
OPERATION NOT POSSIBLE WHEN MULTI-TERRAIN SELECT ACTIVATED (If equipped)	Indicates that the VSC OFF switch is pressed or second start mode is selected while the Multi-terrain Select system is in use → While the Multi-terrain Select system is in use, vehicle stability control cannot be turned off and second start mode cannot be activated.	
MULTI-TERRAIN SELECT HAS BEEN CANCELLED (If equipped)	Indicates that the Multi-terrain Select system is canceled while in use A buzzer also sounds. → Use the Multi-terrain Select system under the proper operating conditions.	
OPERATION NOT POSSIBLE WHEN CRAWL CONTROL ACTIVATED (If equipped)	Indicates that the Multi-terrain Select system is turned on during Crawl Control operation → Turn Crawl Control off before turning on the Multi-terrain Select system.	

Warning message	Details/Actions	
SHIFT TO L4 (If equipped)	Indicates that the Multi-terrain Select system is turned on while the transfer switch is in H4 → Turn the transfer switch to L4.	
STOP THE VEHICLE AND SHIFT THE AUTOMATIC TRANSMISSION TO N (If equipped)	Indicates that the transfer switch is turned from H4 to L4 while the shift lever is not in N \rightarrow Move the shift lever to N.	
MULTI-TERRAIN SELECT NOT AVAILABLE (If equipped)	Indicates that the VSC, the 4WD system, the Multi-terrain Select system or the EFI system malfunctions → Consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.	
OIL MAINTENANCE REQUIRED SOON	Indicates that the engine oil is scheduled to be changed (1GD-FTV engine only) Comes on approximately 25000 km (15000 miles) after the engine oil is changed. (The indicator will not work properly unless the oil maintenance data has been reset.) → Check the engine oil and change if necessary. After changing the engine oil, the oil change system should be reset. (→P. 548) For Russia, Kazakhstan, Ukraine, Montenegro, Serbia and Macedonia: You have forgotten to reset the oil change system. Change the engine oil in accordance with the maintenance schedule.	
OIL MAINTENANCE REQUIRED	Indicates that the engine oil and oil filter should be changed (1GD-FTV engine only) → Have the engine oil and oil filter checked and/or changed by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. After changing the engine oil, the oil change system should be reset. (→P. 548) For Russia, Kazakhstan, Ukraine, Montenegro, Serbia and Macedonia: You have forgotten to reset the oil change system. Change the engine oil in accordance with the maintenance schedule.	

Warning message	Details/Actions
DPF FULL SEE OWNER'S MANUAL (If equipped)	Indicates that the amount of accumulated deposit in the DPF system has reached the specified level. Regenerate the filter. → P. 647
DPF FULL VISIT YOUR DEALER (If equipped)	Malfunction in the DPF system. → Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
AdBlue LEVEL LOW FILL UP AdBlue IN 2400 km SEE OWNER'S MANUAL	When AdBlue™ needs to be refilled → Have AdBlue™ refilled at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
AdBlue (If equipped)	تلفن شبانه روزی: ۱۹۲۰ ۱۹۶۸ م
AdBlue LEVEL LOW NO START IN 800 km! FILL UP AdBlue SEE OWNER'S MANUAL AdBlue (If equipped)	When AdBlue™ needs to be refilled The warning buzzer sounds. If the displayed driving distance is exceeded, the engine cannot be restarted. → Have AdBlue™ refilled at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

Warning message	Details/Actions
AdBlue EMPTY UNABLE TO RESTART ENGINE FILL UP AdBlue SEE OWNER'S MANUAL AdBlue (If equipped)	When AdBlue™ needs to be refilled The warning buzzer sounds. → If the engine is stopped, it cannot be restarted. Without stopping the engine, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
EMISSIONS TOO HIGH CHECK AdBlue VISIT YOUR DEALER (If equipped)	Exhaust gas purification system malfunction The warning buzzer sounds. → Have the vehicle inspected at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
EMISSIONS TOO HIGH NO START IN 800 km! CHECK AdBlue VISIT YOUR DEALER (If equipped)	Exhaust gas purification system malfunction The warning buzzer sounds. If the displayed driving distance is exceeded, the engine cannot be restarted. → Have the vehicle inspected at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.
EMISSIONS TOO HIGH UNABLE TO RESTART ENGINE CHECK AdBlue VISIT YOUR DEALER (If equipped)	Exhaust gas purification system malfunction The warning buzzer sounds. → If the engine is stopped, it cannot be restarted. Without stopping the engine, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately.

■Warning message in radar cruise mode (vehicles with the dynamic radar cruise control system)

In the following situations, the warning message may not be displayed even if vehicle-to-vehicle distance decreases:

- When your vehicle and the vehicle ahead are traveling at the same speed or the vehicle ahead is traveling more quickly than your vehicle
- When the vehicle ahead is traveling at a very low speed
- Immediately after cruise control speed is set
- At the instant the accelerator pedal is depressed
- Conditions that the tire pressure warning system may not function properly (vehicles with the tire pressure warning system)

 →P. 570
- If the message "DPF FULL SEE OWNER'S MANUAL" appears on the display (if equipped)

The deposit collected in the filter needs to be regenerated.

To regenerate the filter, the following driving methods are recommended*:

- By driving continuously (for example, at around 65 km/h [40 mph] for 20 to 30 minutes).
- By avoiding short trips, or by driving continuously (leaving the engine running for long periods of time).

The warning message will disappear when regeneration is complete. However, if this driving cannot be carried out, or if the message does not disappear even after driving, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately. For details of the DPF system, refer to P. 271.

*: When driving, pay sufficient attention to weather, road conditions, terrain and traffic conditions, and drive according to traffic laws.

■ Warning buzzer

In some cases, the buzzer may not be heard due to being in a noisy location or audio sound.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
	3	KEY NOT DETECTED	The electronic key was carried outside the vehicle and a door other than the driver's door was opened and closed while the engine switch was in a mode other than off. → Bring the electronic key back into the vehicle.
Once	times	(Flashes)	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was in P and the engine switch was not turned off. Turn the engine switch off. Bring the electronic key back into the vehicle.
Once	Sounds once for 5 sec- onds	KEY NOT DETECTED TURN POWER OFF (Flashes)	An attempt was made to exit the vehicle with the electronic key and lock the doors without first turning the engine switch off. → Turn the engine switch off and lock the doors again.
Once	Fa _	KEY NOT DETECTED (Flashes)	 An attempt was made to start the engine without the electronic key being present, or the electronic key was not functioning normally. An attempt was made to drive when the regular key was not inside the vehicle. → Confirm that the electronic key is inside the vehicle.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Con- tinu- ous	_	SHIFT TO P POSITION (Flashes) (If equipped)	The driver's door was opened when the shift lever was not in P and the engine switch was not turned off. → Shift the shift lever to P.
Con- tinu- ous	Con- tinu- ous	SHIFT TO P POSITION KEY NOT DETECTED (Displayed alternately) (Flashes)	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was not in P and the engine switch was not turned off. → Shift the shift lever to P. Bring the electronic key back into the vehicle.
Once	Sounds once for 5 sec-onds	KEY DETECTED IN VEHICLE (Flashes)	An attempt was made to lock the doors using the smart entry & start system while the electronic key was still inside the vehicle. → Retrieve the electronic key from the vehicle and lock the doors again.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	Sounds once for 5 sec- onds	KEY DETECTED IN VEHICLE (Flashes)	An attempt was made to lock either front door by opening a door and putting the inside lock button into the lock position, then closing the door by pulling on the outside door handle with the electronic key still inside the vehicle. → Retrieve the electronic key from the vehicle and lock the doors again.
Once	را ۲۱۰	DEPRESS BRAKE PEDAL, TOUCH ENGINE SWITCH WITH KEY (automatic transmission) or DEPRESS CLUTCH PEDAL, TOUCH ENGINE SWITCH WITH KEY (manual transmission)	 When the doors were unlocked with the mechanical key and then the engine switch was pressed, the electronic key could not be detected in the vehicle. The electronic key could not be detected in the vehicle even after the engine switch was pressed two consecutive times. → Touch the electronic key to the engine switch while depressing the brake pedal (automatic transmission) or clutch pedal (manual transmission).
Once	_	SHIFT TO P POSITION AND PUSH ENGINE SWITCH TO TURN POWER OFF	An attempt was made to turn the engine switch off when the shift lever was not in P. → To turn off the engine, first shift the shift lever to P and then turn the engine switch off.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
_	_	AUTO POWER OFF TO CONSERVE BATTERY	Power was turned off due to the automatic power off function. → Next time when starting the engine, increase the engine speed slightly and maintain that level for approximately 5 minutes to recharge the battery.
Once	—	KEY BATTERY LOW	The electronic key has a low battery. → Replace the electronic key battery. (→P. 588)
Once	Fa	DEPRESS BRAKE PEDAL AND PUSH ENGINE SWITCH TO START (automatic transmission) or DEPRESS CLUTCH PEDAL AND PUSH ENGINE SWITCH TO START (manual transmission) (Flashes)	The driver's door was opened and closed with the engine switch turned off and then the engine switch was put in ACCESSORY mode twice without the engine being started. → Press the engine switch while depressing the brake pedal (automatic transmission) or clutch pedal (manual transmission).
			During an engine starting procedure in the event that the electronic key was not functioning properly (→P. 692), the engine switch was touched with the electronic key. → Press the engine switch within 10 seconds of the buzzer sounding.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	_	STEERING LOCK ACTIVE (Flashes)	The steering lock could not be released within 3 seconds of the engine switch being pressed. → Press the engine switch while depressing the brake pedal and moving the steering wheel left and right.
Once	(,)	SHIFT TO P POSITION TO START (Flashes)	An attempt was made to start the engine with the shift lever in an incorrect position. → Shift the shift lever to P and start the engine.
Once	+ 7 1	SHIFT TO P POSITION AND PUSH ENGINE SWITCH TO TURN POWER OFF (Flashes)	An attempt was made to turn the engine switch off when the shift lever was not in P. → To turn off the engine, first shift the shift lever to P and then turn the engine switch off.

■ Warning buzzer

In some cases, the buzzer may not be heard due to being in a noisy location or audio sound.



■ While the engine oil level warning is displayed

Continued engine operation with low engine oil will damage the engine.

If you have a flat tire (vehicles with a spare tire)

Your vehicle is equipped with a spare tire. The flat tire can be replaced with the spare tire.

For details about tires: \rightarrow P. 565

A CAUTION

■ If you have a flat tire

Do not continue driving with a flat tire.


Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

Before jacking up the vehicle


- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P (automatic transmission) or R (manual transmission).
- Turn off the rear height control air suspension (if equipped). (→Refer to the "Off-road Driving Owner's Manual")
- Stop the engine.
- Turn on the emergency flashers. (→P. 614)

Location of the spare tire, jack and tools

▶ Vehicles with under floor mounted spare tire



- 1 Jack
- 3 Spare tire



- 1 Jack
- ② Spare tire

CAUTION

■Using the tire jack

Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.

- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire. Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.
- Always check that the tire jack is securely set to the jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start or run the engine while your vehicle is supported by the jack.
- Do not raise the vehicle while someone is inside.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- Vehicles with rear height control air suspension: Be sure to turn off the height control and stop the engine.


Take particular care when lowering the vehicle to ensure that no one work-تلفن شیانه روزی: 🔾 ing on or near the vehicle will be injured.


Using the jack handle


Tighten all the jack handle bolts securely using a Phillips-head screwdriver, to prevent the extension parts from coming apart unexpectedly.

Taking out the jack

- 1 Remove the cover.
- ▶ 3-door models









- 2 Unhook the rubber band and take out the jack.
 - 1 For loosening
 - ② For tightening
 - ▶ 3-door models








Taking out the tool box

1 Open the cover.




2 Take out the tool box.



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا


Taking out the spare tire cover (if equipped)

- 1 Remove the bolt cover
 - 1 Bolt cover




2 Remove the bolt which fixes the spare tire cover.





3 Unlock the latch and unhook the spare tire cover.


Opening the back door makes unlocking the latch easier.



FarmaS(

Taking out the spare tire

- ▶ Vehicles with back door mounted spare tire
- 1 Unlock the spare tire lock system.
 - 1 Insert the key into the cylinder.
 - ② Remove the key and the cylinder.




2 Turn the hold-down nuts counterclockwise with the wheel nut wrench and remove them.



تلفن شبانه روزی: ۱-۲۱-۸۸۸۶۲ ۲۲ **۰**


- 1 Assembling the jack handle.

 Remove the jack handle and the jack handle extension bar from the tool box and assemble by following these steps.
 - 1 Loosen the bolt and the screw using either the jack handle end or a screwdriver.




② Assemble the jack handle extension bar and the jack handle and tighten the bolt and the screw.

Check that the bolt and screw are firmly tightened.



2 Remove the cover.

To protect the bodywork, place a rag between the screwdriver and the vehicle body.





8


When trouble arises

- Insert the jack handle extension into the lowering screw.
 - 1 Lower
 - ② Raise


Place a rag under the jack handle extension to protect the rear bumper.








5 Pull out the spare tire and remove the holding bracket.



Replacing a flat tire

1 Chock the tires.




Flat tire		Wheel chock positions
Front	Left-hand side	Behind the rear right-hand side tire
FIONE	Right-hand side	Behind the rear left-hand side tire
Rear	Left-hand side	In front of the front right-hand side tire
	Right-hand side	In front of the front left-hand side tire


2 Pry off the wheel ornament, using the beveled end of the wheel nut wrench as shown.

To protect the wheel ornament, place a rag between the wheel nut wrench and the wheel ornament.


Steel wheels








3 Slightly loosen the wheel nuts (one turn).




- Assembling the jack handle.

 Remove the jack handle, jack handle extension bar and jack handle bar from the tool box and assemble by following these steps.
 - 1 Loosen the bolt and the screw using either the jack handle end or a screwdriver.




② Assemble the jack handle extension bar and the jack handle bar and tighten the bolts.


Check that the bolts are firmly tightened.




3 Assemble the jack handle extension bar and the jack handle and tighten the screw. Check that the screw is firmly tightened.



- 5 Position the jack at the jack points as shown.
 - ① Front
 Under the chassis frame side rail
 - RearUnder the rear axle housing



6 Raise the vehicle until the tire is slightly raised off the ground.



7 Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.



CAUTION

■ Replacing a flat tire

- Observe the following precautions. Failure to do so may result in serious injury:
 - · Vehicles with under floor mounted spare tire: Lower the spare tire completely to the ground before removing it from under the vehicle.
 - Do not try to remove the wheel ornament by hand. Take due care in handling the ornament to avoid unexpected personal injury.
 - Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven. After the vehicle has been driven the disc wheels and the area around

the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.

- Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.
 - Have the wheel nuts tightened with a torque wrench to 112 N·m (11.4 kgf·m, 83 ft·lbf) steel wheels, 103 N·m (10.5 kgf·m, 76 ft·lbf) aluminum wheels, as soon as possible after changing wheels. Failure to follow these precautions could cause the nuts to loosen and the wheel may fall off, which could lead to an accident causing death or serious injury.
 - · Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.
 - If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
 - · When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
 - · When installing the wheel nuts, be sure to install them with the tapered ends facing inward. (→P. 584)

Installing the spare tire


1 Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, and the tire to come off.




2 Install the spare tire and loosely tighten each nut by hand to approximately the same amount.


When replacing a steel wheel with a steel wheel, tighten the wheel nuts until the tapered portion comes into loose contact with the disc wheel seat.



When replacing an aluminum wheel with an aluminum wheel, turn the wheel nuts until the washers come into contact with the disc wheel.



3 Lower the vehicle.




4 Firmly tighten each nut two or three times in the order shown in the illustration.


Tightening torque


Steel wheels:

112 N•m (11.4 kgf•m, 83 ft•lbf) Aluminum wheels:


103 N•m (10.5 kgf•m, 76 ft•lbf)








Aluminum wheels





6 Stow the flat tire, tools and jack securely, and replace all covers.




A CAUTION

Stowing the flat tire

Failure to follow steps listed under stowing the tire may result in damage to the spare tire carrier and loss of the tire, which could result in death or seri-'ar masus.(


Stowing the flat/spare tire, jack and tools

- ▶ Vehicles with back door mounted spare tire
- Install the tire and loosely tighten each nut by hand to approximately the same amount.




2 Firmly tighten each nut two or three times in the order shown in the illustration.


Tightening torque: 60 N•m (6.0 kgf•m, 44 ft•lbf) Tighten the spare tire lock nut first.



- 3 Lock the spare tire lock system
 - 1 Spare tire lock nut.
 - ② Insert the key and cylinder.
 - 3 Remove the key while holding the cylinder in place. Check that the cylinder is locked securely.
- 4 Vehicles with the spare tire cover: Install the spare tire cover in the reverse order of removal.

Tightening torque: 14 N•m (1.4 kgf•m, 10 ft•lbf)






5 Stow the tools and jack securely, and replace all covers.

- ▶ Vehicles with under floor mounted spare tire
- 1 Lay down the tire with the valve stem facing up and install the holding bracket, inserting the claw into the wheel lug nut hole. Turn the jack handle extension clockwise to take up slack in the chain.


Then, check to ensure the claw is in the wheel lug nut hole and the holding bracket is centered in the wheel hub.

- 1 Holding bracket
- 2 Claw



- 2 Raise the tire.
 - Vehicles without kinetic dynamic suspension

While raising, secure the tire, taking care that the tire goes straight up without catching on any surrounding part, to prevent it from flying forward during a collision or sudden braking.



▶ Vehicles with kinetic dynamic suspension

While raising, pull the tire towards the rear of the vehicle, taking care that the tire goes up without catching on any surrounding part, to prevent it from flying forward during a collision or sudden braking.


After the tire goes half way up, check that the suspended chain is able to enter the tire hole, for proper storage.

Tightening torque:

46.6 N•m (4.8 kgf•m, 34.4 ft•lbf)

- 3 Confirm that the tire is not loose after tightening:
 - 1) Push and pull the tire
 - 2 Try rotating

Visually check to ensure the tire is not hung on surrounding parts.



If looseness or misassembly exists, repeat step 2 and step 3.

- 4 Repeat step 3, any time the tire is lowered or disturbed.
- 5 Stow the tools and jack securely, and replace all covers.
- Vehicles with spare tire lock system (vehicles with back door mounted spare tire)

Use the spare tire lock nut only for the spare tire carrier.



CAUTION

After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden braking.



NOTICE

When stowing the flat tire (vehicles with under floor mounted spare

Ensure that there is no object caught between the tire and the vehicle underbody.

When assembling the jack handle extension

Tighten all the joints securely. Otherwise the extension may come off and it may damage the paint or vehicle body.

If you have a flat tire (vehicles without a spare tire)

Your vehicle is not equipped with a spare tire, but instead is equipped with an emergency tire puncture repair kit.

A puncture caused by a nail or screw passing through the tire tread can be repaired temporarily with the emergency tire puncture repair kit.

A CAUTION

If you have a flat tire

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

Driving with a flat tire may cause a circumferential groove on the side wall. In such a case, the tire may explode when using a repair kit.


تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱۰

Before repairing the vehicle

- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P (automatic transmission) or N (manual transmission).
- Turn off the rear height control air suspension (if equipped).
 (→Refer to the "Off-road Driving Owner's Manual")
- Stop the engine.
- Turn on the emergency flashers. (→P. 614)
- Check the degree of the tire damage.

A tire should only be repaired with the emergency tire puncture repair kit if the damage is caused by a nail or screw passing through the tire tread.

 Do not remove the nail or screw from the tire. Removing the object may widen the opening and disenable emergency repair with the kit.




- To avoid sealant leakage, move the vehicle until the area of the puncture, if known, is positioned at the top of the tire.
- A flat tire that cannot be repaired with the emergency tire repair kit

 In the following cases, the tire cannot be repaired with the emergency tire
 puncture repair kit. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
 - When the tire is damaged due to driving without sufficient air pressure
 - When the tire lost air pressure due to a crack or damage in the tire sidewall
 - When the tire is visibly separated from the wheel
 - When the cut or damage to the tread is 4 mm (0.16 in.) long or more
 - When the wheel is damaged
 - When two or more tires have been punctured
 - When there is more than one hole or cut in the damaged tire

Location of the emergency tire puncture repair kit, jack and tools

▶ 3-door models



① Jack*1


③ Emergency tire puncture

2 Tool box*1,2 | __// المجانب (وزي Tool box*1,2 | __// المجانب (المجانب) المجانب (ا

*1: If equipped

^{*2:} Use of the jack (\rightarrow P. 665)

▶ 5-door models




- ① Jack*1
- ② Tool box*1, 2

- ③ Emergency tire puncture repair kit

*1: If equipped
*2: Use of the jack (→P. 665) تلفن شبانه روزی: **△۸**۸

Emergency tire puncture repair kit components




- 1 Bottle
- ② Air pressure gauge
- 3 Compressor switch
- 4 Air release cap

- 5 Stickers
- 6 Hose
- Power plug


 B Insertion key

Taking out the emergency tire puncture repair kit

- ▶ 3-door models
- 1 Remove the cover.




2 Take out the emergency tire puncture repair kit.



- ▶ 5-door models
- 1 Open the console box.




2 Take out the emergency tire puncture repair kit.



Emergency repair method

1 Pull the insertion key out of the kit.



2 Place the kit with the bottom facing upward.


Peel off the label, and push in the insertion key until a click is heard.



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا


3 Return the kit to an upright position and make sure that the compressor switch is off.


Use the kit with the top facing upward.



- Connect the power plug to the power outlet socket. (→P. 514)
 Open the cover and connect the power plug.
 - ▶ Front









Luggage compartment (DC12 V)






R

5 Remove the valve cap from the valve of the punctured tire.




6 Remove the air release cap from the hose.





7 Connect the hose to the valve.

Screw the end of the hose clockwise as far as possible.




- ▶ Left-hand drive vehicles
- ▶ Right-hand drive vehicles






- 9 Start the engine. (→P. 249)
- To inject the sealant and inflate the tire, turn the compressor switch on.

Use the kit with the top facing upward.






- Inflate the tire until the recommended pressure is reached.
 - ① The sealant will be injected and the pressure will spike to 300 kPa (3.0 kgf/cm² or bar, 44 psi) or 400 kPa (4.0 kgf/cm² or bar, 58 psi), then gradually decrease.
 - ② The air pressure gauge will display the actual tire inflation pressure about 1 minute after the switch is turned on.
 - Turn the compressor switch off and then check the tire inflation pressure. Being careful not to over inflate, check and repeat the inflation procedure until the recommended tire inflation pressure is reached.




- If the needle of the air pressure gauge reaches the red zone (450 kPa [4.5 kgf/cm² or bar, 65 psi] or more), there may be a malfunction in the tire or in the kit itself. Stop operation immediately.
- If the tire inflation pressure is still lower than the recommended level after inflation for 10 minutes with the switch on, the tire is too damaged to be repaired. Turn the compressor switch off and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- If the tire inflation pressure exceeds the recommended level, let out some air to adjust the tire inflation pressure. (→P. 686)
- Disconnect the hose from the valve on the tire and then pull out the power plug from the power outlet socket.
- To spread the liquid sealant evenly within the tire, immediately drive for about 5 km (3 miles).

4 After driving for about 5 km (3 miles), stop your vehicle in a safe place on a hard, flat surface and reconnect the compressor.




- Turn the compressor switch on and wait for several seconds, then turn it off. Check the tire inflation pressure.
 - ① If the tire inflation pressure is below 130 kPa (1.3 kgf/cm² or bar, 19 psi): The puncture cannot be repaired. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



- ② If the tire inflation pressure is between 130 kPa (1.3 kgf/cm² or bar, 19 psi) and a point below the recommended level: The tire can be repaired. Proceed to step 16.
- ③ If the tire inflation pressure is at the recommended level: Proceed to step 17.
- Turn the compressor switch on to inflate the tire until the recommended tire inflation pressure is reached. Drive for about 5 km (3 miles) and then perform step 14.

Store the kit and then attach the 2 stickers as shown.

Taking precautions to avoid sudden braking and sharp turns, drive carefully at under 80 km/h (50 mph) to the nearest authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for tire repair or replacement.




تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ م

- The sealant has a limited lifespan. The expiry date is marked on the bottle. The sealant should be replaced before the expiry date. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for replacement.
- The sealant stored in the emergency tire puncture repair kit can be used only once to temporarily repair a single tire. If the sealant in the bottle and other parts of the kit have been used and need to be purchased, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- The sealant can be used when the outside temperature is from -30 °C (-22 °F) to 60 °C (140 °F).
- The kit is exclusively designed for size and type of tires originally installed on your vehicle. Do not use it for tires that a different size than the original ones, or for any other purposes.
- If the sealant gets on your clothes, it may stain.
- If the sealant adheres to a wheel or the surface of the vehicle body, the stain may not be removable if it is not cleaned at once. Immediately wipe away the sealant with a wet cloth.
- During operation of the kit, a loud operation noise is produced. This does not indicate a malfunction.

تلفن شبانه روزى: ۱-۱۸۸۶۲ - ۲۱ م

■ If the tire is inflated to more than the recommended level

- Disconnect the hose from the valve.
- Install the air release cap to the end of the hose and push the protrusion on the air release cap into the valve to let some air out.



- 3 Disconnect the hose from the valve, remove the air release cap from the hose and then reconnect the hose.
- 4 Turn the compressor switch on and wait for several seconds, then turn it off. Check that the air pressure indicator shows the recommended level. (→P. 735)

If the air pressure is lower than the recommended level, turn the compressor switch on again and repeat the inflation procedure until the recommended pressure is reached.

■ After a tire is repaired with the emergency tire puncture repair kit

- The tire pressure warning valve and transmitter should be replaced.
- Even if the tire inflation pressure is at the recommended level, the tire pressure warning light may come on/flash. (vehicles with the tire pressure warning system)



■ Precautions for use of the sealant

- Ingesting the sealant is hazardous to your health. If you ingest sealant, consume as much water as possible, then immediately consult a doctor.
- If sealant gets in eyes or adheres to skin, immediately wash it off with water. If discomfort persists, consult a doctor.

A CAUTION

■When fixing the flat tire

- Stop your vehicle in a safe and flat area.
- Connect the valve and hose securely with the tire installed on the vehicle.
- If the hose is not properly connected to the valve, air leakage may occur or sealant may be sprayed out.
- If the hose comes off the valve while inflating the tire, there is a risk that the hose will move abruptly due to air pressure.
- After inflation of the tire has completed, the sealant may splatter when the hose is disconnected or some air is let out of the tire.
- Keep back from the tire while it is being repaired, as there is a chance of it bursting while the repair operation is being performed. If you notice any cracks or deformation of the tire, turn off the compressor switch and stop the repair operation immediately.
- The kit may overheat if operated for a long period of time. Do not operate the compressor continuously for more than 20 minutes.
- Parts of the kit become hot during operation. Be careful handling the kit during and after operation.
- Do not attach the vehicle speed warning sticker to an area other than the one indicated. If the sticker is attached to an area where an SRS airbag is located, such as the pad of the steering wheel, it may prevent the SRS air bag from operating properly.

تلفن شبانه روزیDriving to spread the liquid sealant evenly

- Drive the vehicle carefully at a low speed. Be especially careful when turning and cornering.
- If the vehicle does not drive straight or you feel a pull through the steering wheel, stop the vehicle and check the following:
 - Tire condition. The tire may have separated from the wheel.
 - Tire inflation pressure. If tire inflation pressure is 130 kPa (1.3 kgf/cm²) or bar, 19 psi) or below, this may indicate severe tire damage.

↑ NOTICE

■ When performing an emergency repair

- Perform the emergency repair without removing the nail or screw that has punctured the tread of the tire. If the object that has punctured the tire is removed, repair by the emergency tire puncture repair kit may not be possible.
- The kit is not waterproof. Make sure that the kit is not exposed to water, such as when it is being used in the rain.
- Do not put the kit directly onto dusty ground such as sand at the side of the road. If the kit vacuums up dust etc., a malfunction may occur.
- Use the kit with the top facing upward. The kit cannot work properly if it is laid on its side.

■ Handling the emergency tire puncture repair kit

- The compressor power source should be 12 V DC suitable for vehicle use.
 Do not connect the compressor to any other source.
- If gasoline splatters on the kit, the kit may deteriorate. Take care not to allow gasoline to contact it.
- Store the kit in its assigned place out of reach of children.
- Do not disassemble or modify the kit. Do not subject parts such as the air pressure indicator to impacts. This may cause a malfunction.

■ To avoid damage to the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer as soon as possible. After use of liquid sealant, make sure to replace the tire pressure warning valve and transmitter when repairing or replacing the tire. $(\rightarrow P. 567)$

If the engine will not start

If the engine will not start even though correct starting procedures are being followed (\rightarrow P. 246, 249), consider each of the following points:

The engine will not start even when the starter motor operates normally.

One of the following may be the cause of the problem:

- There may not be sufficient fuel in the vehicle's tank.
 Gasoline engine: Refuel the vehicle.
 Diesel engine: →P. 704
- The engine may be flooded. (gasoline engine)
 Try to restart the engine again following correct starting procedures.
 (→P. 246, 249)
- There may be a malfunction in the engine immobilizer system.
 (→P. 83)

The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

- The battery may be discharged. (→P. 694)
- The battery terminal connections may be loose or corroded.

The starter motor does not turn over (vehicles with a smart entry & start system).

The engine starting system may be malfunctioning due to an electrical problem such as an open circuit or a blown fuse. However, an interim measure is available to start the engine. (→P. 690)

The starter motor does not turn over, the interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- One or both of the battery terminals may be disconnected.
- The battery may be discharged. (→P. 694)
- There may be a malfunction in the steering lock system. (vehicles with a smart entry & start system)

Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer if the problem cannot be repaired, or if repair procedures are unknown.

Emergency start function (vehicles with a smart entry & start system)

When the engine does not start, the following steps can be used as an interim measure to start the engine if the engine switch is functioning normally.

- 1 Set the parking brake.
- 2 Put the shift lever in P (automatic transmission) or N (manual transmission).
- Turn the engine switch to ACCESSORY mode.
- 4 Press and hold the engine switch for about 15 seconds while depressing the brake pedal (automatic transmission) or brake and clutch pedals (manual transmission) firmly.


Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.


If communication between the electronic key and vehicle is interrupted (→P. 162) or the electronic key cannot be used because the battery is depleted, the smart entry & start system and wireless remote control cannot be used. In such cases, the doors can be opened and the engine can be started by following the procedure below.

Locking and unlocking the doors and key linked functions

Use the mechanical key (\rightarrow P. 134) in order to perform the following operations:

- 1 Locks all doors
- 2 Closes the windows and moon roof* (turn and hold)
- ③ Unlocks all doors
- 4 Opens the windows and moon roof* (turn and hold)






Starting the engine

- ▶ Automatic transmission
- 1 Ensure that the shift lever is in P and depress the brake pedal.
- 2 Touch the Toyota emblem side of the electronic key to the engine switch.

If any of the doors is opened or closed while the key is being touched to the switch, an alarm will sound to indicate that the start function cannot detect the key.



Press the engine switch within 10 seconds of the buzzer sounding, keeping the brake pedal depressed.

In the event that the engine switch still cannot be operated, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

- ▶ Manual transmission
- 1 Shift the shift lever to N and depress the clutch pedal.
- 2 Touch the Toyota emblem side of the electronic key to the engine switch.

If any of the doors is opened or closed while the key is being touched to the switch, an alarm will sound to indicate that the start function cannot detect the key.



3 Press the engine switch within 10 seconds of the buzzer sounding, keeping the clutch pedal depressed.

In the event that the engine switch still cannot be operated, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

■ Stopping the engine

▶ Vehicles with an automatic transmission

Shift the shift lever to P and press the engine switch as you normally do when stopping the engine.

▶ Vehicles with a manual transmission

Shift the shift lever to N and press the engine switch as you normally do when stopping the engine.

■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. $(\rightarrow P. 588)$

■ Alarm (if equipped)

Using the mechanical key to lock the doors will not set the alarm system. If a door is unlocked using the mechanical key when the alarm system is set, the alarm may be triggered. $(\rightarrow P. 90)$

■ Changing engine switch modes

▶ Vehicles with an automatic transmission

Within 10 seconds of the buzzer sounding, release the brake pedal and press the engine switch.

The engine does not start and modes will be changed each time the switch is pressed. $(\rightarrow P. 252)$

▶ Vehicles with a manual transmission

Within 10 seconds of the buzzer sounding, release the clutch pedal and press the engine switch.

The engine does not start and modes will be changed each time the switch is pressed. $(\rightarrow P. 252)$

■ When the electronic key does not work properly

Make sure that the smart entry & start system has not been deactivated in the customization setting. If it is off, turn the function on. (Customizable features: →P. 741)

A CAUTION

When using the mechanical key and operating the power windows or moon roof

Operate the power window or moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or moon roof.

Also, do not allow children to operate the mechanical key. It is possible for children and other passengers to get caught in the power window or moon roof.

If the vehicle battery is discharged


The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can call any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your Toyota following the steps below.


1 Confirm that the key is being carried.

When connecting the jumper (or booster) cables, depending on the situation, the alarm may activate and the doors may lock. (\rightarrow P. 92)




- 2 Open the hood. (\rightarrow P. 539)
- 3 Remove the engine cover.
 - ▶ Vehicles with 1GR-FE engine

Lift the edge of the cover to disengage the fixed pins, and then pull the cover towards you to remove it.




Lift the edge of the cover to disengage the fixed pins, and then pull the cover towards you to remove it.




- ▶ Vehicles with 1KD-FTV engine*1
- 1) Remove the bolts.






2 Raise the front of the engine cover and then pull the cover to detach it from the bracket on the rear bar as shown in the illustration.




FarmaS


- 4 Connect the jumper cables according to the following procedures:
 - 1 Positive (+) battery terminal on your vehicle
 - 2 Positive (+) battery terminal on the second vehicle
 - 3 Negative (-) battery terminal on the second vehicle
 - 4 Connect the jumper cable to ground on your vehicle as shown in the illustration.

▶ 2TR-FE engine




▶ 1GR-FE engine





▶ 1GD-FTV engine



٩

When trouble arises

- 5 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- 6 Vehicles with a smart entry & start system: Open and close any of the doors with the engine switch off.
- Maintain the engine speed of the second vehicle and start the engine of your vehicle by turning the engine switch to IGNITION ON mode (vehicles with a smart entry & start system) or turning the engine switch to the "ON" position (vehicles without a smart entry & start system).
- 8 Once the vehicle's engine has started, remove the jumper cables in the exact reverse order in which they were connected.
- 9 Vehicles with 1GR-FE, 1GD-FTV and 1KD FTV engines*1: To install the engine cover, conduct the removal procedure in reverse. After installing, check that the fixed pins are inserted securely.

Once the engine starts, have the vehicle checked at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer, as soon as possible.

- *1: Vehicles with DPF system*2
- *2: To determine whether or not your vehicle has a DPF system, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

Starting the engine when the battery is discharged (vehicles with an automatic transmission)

The engine cannot be started by push-starting.

■ To prevent battery discharge

- Turn off the headlights and the audio system while the engine is off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

■ Charging the battery

The electricity stored in the battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to start. (The battery recharges automatically during driving.)

- ■When recharging or replacing the battery (vehicles with a smart entry & start system)
 - In some cases, it may not be possible to unlock the doors using the smart entry & start system when the battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.
 - The engine may not start on the first attempt after the battery has recharged but will start normally after the second attempt. This is not a malfunction.
 - The engine switch mode is memorized by the vehicle. When the battery is reconnected, the system will return to the mode it was in before the battery was discharged. Before disconnecting the battery, turn the engine switch off. If you are unsure what mode the engine switch was in before the battery discharged, be especially careful when reconnecting the battery.

CAUTION

Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery:

- Make sure the jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- Do not allow the + and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the battery.

Battery precautions

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery:

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention. Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the battery.
- To prevent damaging the vehicle (vehicles with a manual transmission) Do not pull- or push-start the vehicle, because the catalytic converter may overheat and become a fire hazard.



NOTICE

When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fans or belt.

■ To prevent damage to the engine cover

- When removing the cover, make sure that you pull the cover towards you after lifting the front edge to remove the fixed pins.
- When installing the cover, do not force the cover or subject it to strong shocks.

If your vehicle overheats

The following may indicate that your vehicle is overheating.

- lacktriangle The needle of the engine coolant temperature gauge (\rightarrow P. 105) enters the red zone or a loss of engine power is experienced. (For example, the vehicle speed does not increase.)
- Steam is coming from under the hood.

Correction procedures

- 1 Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the engine.
- 2 If you see steam:


Carefully lift the hood after the steam subsides.

If you do not see steam:

Carefully lift the hood.


- 3 After the engine has cooled down sufficiently, inspect the hoses and radiator core (radiator) for any leaks.
 - 1) Radiator
 - 2 Radiator cooling fan
 - ③ Cooling fan (if equipped)

If a large amount of coolant leaks, immediately contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



When trouble arises

- The coolant level is satisfactory if it is between the "FULL" and "LOW"/"F" and "L" lines on the reservoir.
 - (1) Reservoir
 - ② "FULL" or "F"
 - ③ "LOW" or "L"
 - 4 Radiator cap (if equipped)




5 Add coolant if necessary.

Water can be used in an emergency if coolant is unavailable.

▶ Gasoline engine

▶ Diesel engine



6 Start the engine and turn the air conditioning system on to check that the radiator cooling fans operate and to check for coolant leaks from the radiator or hoses.

The fans operate when the air conditioning system is turned on immediately after a cold start. Confirm that the fans are operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly. (The fans may not operate in freezing temperatures.)

7 If the fans are not operating:

Stop the engine immediately and contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

If the fans are operating:

Have the vehicle inspected at the nearest authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



CAUTION

■ When inspecting under the hood of your vehicle

Observe the following precautions.

Failure to do so may result in serious injury such as burns.

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot.
- Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fans and belts. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.
- Do not loosen the radiator cap or the coolant reservoir cap while the engine and radiator are hot. High temperature steam or coolant could spray out.

NOTICE

When adding engine coolant


Add coolant slowly after the engine has cooled down sufficiently. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

- To prevent damage to the cooling system Observe the following precautions:
 - Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
 - Do not use any coolant additive.

If you run out of fuel and the engine stalls (diesel engine only)

If you run out of fuel and the engine stalls:

- 1 Refuel your vehicle.
- 2 To bleed the fuel system, operate the priming pump until you feel more resistance.



3 Start the engine. (→P. 246, 249)

If the engine does not start after the above steps have been performed, wait for 10 seconds and try step 2 and 3 again. If the engine still does not start, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

After starting the engine, depress the accelerator pedal lightly until the engine runs smoothly.



When restarting the engine


- Do not crank the engine before refueling and operating the priming pump.
 This may damage the engine and fuel system.
- Do not crank the engine for more than 30 seconds at a time. This may overheat the starter and wiring system.

- 1 Stop the engine. Set the parking brake and put the shift lever in P (automatic transmission) or N (manual transmission).
- Remove the mud, snow, or sand from around the stuck tire.
- 3 Place wood, stones or some other material to help provide traction under the tires.
- 4 Restart the engine.
- 5 Shift the shift lever to D or R (automatic transmission) or 1 or R (manual transmission) and release the parking brake. Then, while exercising caution, depress the accelerator pedal.

■When it is difficult to free the vehicle

Turn off TRC and/or VSC if these functions are hampering your attempts to free the vehicle. (\rightarrow P. 374)





CAUTION

■When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear, to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

■When shifting the shift lever

For vehicles with an automatic transmission, be careful not to shift the shift lever with the accelerator pedal depressed.

This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.



NOTICE

■ To avoid damaging the transmission and other components

- Avoid spinning the wheels and depressing the accelerator pedal more than necessary.
- If the vehicle remains stuck even after these procedures are performed. the vehicle may require towing to be freed.
- Vehicles with the multi-information display type A: When the automatic transmission fluid temperature warning light comes on while attempting to free a stuck vehicle, immediately remove your foot from the accelerator pedal and wait until the warning light turns off. Otherwise, the transmission may become damaged. (\rightarrow P. 627)
- Vehicles with the multi-information display type C: When a warning message for the automatic transmission fluid temperature is displayed while attempting to free a stuck vehicle, immediately remove your foot from the accelerator pedal and wait until the warning message disappears. Otherwise, the transmission may become damaged. (→P. 640)

Vehicle specifications

9

		(fuel, oil level, etc	.)708
		Fuel information	738
1 1	9-2.	Customization	1
	A A S	Customizable featu	res741
6/15	9-3.	Items to initialize	
		Items to initialize	751

9-1. Specifications

Maintenance data

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸ الا

Maintenance data (fuel, oil level, etc.)

Dimensions and weights

Overall length	5-door models	4780 mm (188.2 in.)*1 4950 mm (194.9 in.)*2
Overall length	3-door models	4335 mm (170.7 in.)*1 4505 mm (177.4 in.)*2
Overall width		1885 mm (74.2 in.)
Overall height*3	5-door models	1835 mm (72.2 in.)*4, 6 1845 mm (72.6 in.)*5, 6 1880 mm (74.0 in.)*4, 7 1890 mm (74.4 in.)*5, 7
	3-door models	1830 mm (72.0 in.)*6 1875 mm (73.8 in.)*7
Wheelbase	5-door models	2790 mm (109.8 in.)
Wileeibase	3-door models	2450 mm (96.5 in.)
Front and rear tread		1605 mm (63.2 in.)*8 1585 mm (62.4 in.)*9

تلفن شبانه روزی: ۱۳۹۵۸۸۶۲۰۸۸ تلفن

Gross vehicle mass 2TR-FTV e		gine	Except for 2-seat models 2900 kg (6393 lb.) 2-seat models 2830 kg (6239 lb.)
		gine	2850 kg (6283 lb.)
		ngine	2990 kg (6592 lb.)
1GD-FTV engine	5-door models	2990 kg (6592 lb.)*10 2950 kg (6504 lb.)*11 2930 kg (6460 lb.)*12	
		3-door models	2600 kg (5732 lb.)
permissible axle		Front	1450 kg (3197 lb.)
		Rear	1800 kg (3968 lb.)
Drawbar load		9,39	120 kg (265 lb.)*13 60 kg (132 lb.)*14
Towing capacity		With brake	3000 kg (6614 lb.)*13 1500 kg (3307 lb.)*14
		Without brake	750 kg (1653 lb.)




- *1: Vehicles without back door mounted spare tire
- *2: Vehicles with back door mounted spare tire
- *3: Unladen vehicles
- *4: Vehicles with rear height control air suspension
- *5: Vehicles without rear height control air suspension
- *6: Vehicles without roof rail
- *7: Vehicles with roof rail
- *8: P265/65R17, 265/65R17, P265/60R18 or 265/60R18 tires
- *9: P245/70R17 or 245/70R17 tires
- *10: Vehicles except 2-seat models
- *11: Vehicles with an automatic transmission (2-seat models)
- *12: Vehicles with a manual transmission (2-seat models)
- *13: Vehicles with model code *15 that has "W" as the last letter
- *14: Except for vehicles with model code *15 that has "W" as the last letter
- *15: The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ - ۲۱

■ Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.


This number is stamped on the front right frame.



On some models, this number is also stamped on the top left of the instrument panel.



This number is also on the manufacturer's label on the left-hand side center pillar.





■ Engine number

The engine number is stamped on the engine block as shown.

▶ 1GR-FE engine









▶ 1GD-FTV engine

KD-FTV engine





▶ Gasoline engine

Model	1GR-FE	2TR-FE
Туре	6-cylinder V type, 4-cycle, gasoline	4-cylinder in line, 4-cycle, gasoline
Bore and stroke	94.0 × 95.0 mm (3.70 × 3.74 in.)	95.0 × 95.0 mm (3.74 × 3.74 in.)
Displacement	3956 cm ³ (241.4 cu.in.) 2694 cm ³ (164.4 cu.in.)	
Valve clearance	Automatic adjustment	
Drive belt tension		

▶ Diesel engine

Model	1KD-FTV	1GD-FTV
Туре	4-cylinder in line, 4-cycle (with turbocharger)	, diesel
Bore and stroke	96.0 × 103.0 mm (3.78 × 4.06 in.)	92.0 × 103.6 mm (3.62 × 4.08 in.)
Displacement	2982 cm ³ (182.0 cu.in.)	2755 cm ³ (168.1 cu.in.)
Valve clearance (engine cold)	Intake: 0.20 — 0.30 mm (0.008 — 0.012 in.) Exhaust: 0.35 — 0.45 mm (0.014 — 0.018 in.)	Automatic adjustment
Drive belt tension	Automatic adjustment	

Fuel

▶ Gasoline engine

Fuel type		EU area: Unleaded gasoline conforming to European standard EN228 only Except EU area: Unleaded gasoline only
Research octane number		1GR-FE engine: 95 or higher 2TR-FE engine: 91 or higher
Fuel tank capacity (Refer- ence)	Vehicles with sub fuel tank system	150 L (39.6 gal., 33.0 lmp.gal.)
	Vehicles without sub fuel tank system	87 L (23.0 gal., 19.1 lmp.gal.)
➤ Diesel engine		

Fuel type		Diesel fuel only
Cetane number		48 or higher
Fuel tank capacity (Refer- ence)	Vehicles with sub fuel tank system	تلفن شائه روزي: 150 L (39.6 gal., 33.0 lmp.gal.)
	Vehicles without sub fuel tank system	87 L (23.0 gal., 19.1 lmp.gal.)
Farma5U5.com		

▶ 1GR-FE engine

Oil capacity
(Drain and refill — reference*1)

With filter
6.2 L (6.6 qt., 5.5 Imp.qt.)

Without filter
5.7 L (6.0 qt., 5.0 Imp.qt.)

■ Engine oil selection (GRJ150L-GKTEKW models*2)

*2: The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Toyota recommends the use of approved "Toyota Genuine Motor Oil". Another motor oil of matching quality can also be used.

Oil grade:

0W-20, 5W-30 and 10W-30:

API grade SL "Energy-Conserving", SM "Energy-Conserving" or SN "Resource-Conserving"; or ILSAC multigrade engine oil

15W-40:

API grade SL, SM or SN multigrade engine oil


^{*1:} The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

Recommended viscosity (SAE):

SAE 0W-20 is filled into your Toyota vehicle at manufacturing, and the best choice for good fuel economy and good starting in cold weather.

If SAE 0W-20 oil is not available, SAE 5W-30 oil may be used. However, it should be replaced with SAE 0W-20 at the next oil change.

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 0W-20 or 5W-30 engine oil is recommended.



امرادحو

Oil viscosity (0W-20 is explained here as an example):

aillas


- The 0W in 0W-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in 0W-20 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

Either or both API registered marks are added to some oil containers to help you select the oil you should use.

1 API Service Symbol

Top portion: "API SERVICE SN" means the oil quality designation by American Petroleum Institute (API).

Center portion: "SAE 0W-20" means the SAE viscosity grade. Lower portion: "Resource-Conserving" means that the oil has fuel-saving and environmental protection capabilities.



(2) ILSAC Certification Mark

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is displayed on the front of the container.

■ Engine oil selection (GRJ150L-GKTEK models*3)

*3: The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade:

5W-30 and 10W-30:


API grade SL "Energy-Conserving", SM "Energy-Conserving" or SN "Resource-Conserving"; or ILSAC multigrade engine oil

15W-40:

API grade SL, SM or SN multigrade engine oil

Recommended viscosity (SAE):

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 5W-30 engine oil is recommended.



Oil viscosity (10W-30 is explained here as an example):

- The 10W in 10W-30 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 30 in 10W-30 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.


How to read oil container labels:

Either or both API registered marks are added to some oil containers to help you select the oil you should use.

1 API Service Symbol

Top portion: "API SERVICE SN" means the oil quality designation by American Petroleum Institute (API).

Center portion: "SAE 10W-30" means the SAE viscosity grade. Lower portion: "Resource-Conserving" means that the oil has fuel-saving and environmental protection capabilities.



(2) ILSAC Certification Mark

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is displayed on the front of the container.

Oil capacity

(Drain and refill — reference*)

With filter

5.9 L (6.2 qt., 5.2 lmp.qt.)

Without filter

5.5 L (5.8 qt., 4.8 Imp.qt.)

■ Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade:

0W-20, 5W-20, 5W-30 and 10W-30:


API grade SL "Energy-Conserving", SM "Energy-Conserving" or SN "Resource-Conserving"; or ILSAC multigrade engine oil

15W-40:

API grade SL, SM or SN multigrade engine oil

Recommended viscosity (SAE):

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 0W-20, 5W-20 or 5W-30 engine oil is recommended.



ITIOIL152

9

Vehicle specifications

^{*:} The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick

Oil viscosity (0W-20 is explained here as an example):

- The 0W in 0W-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in 0W-20 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.


How to read oil container labels:

Either or both API registered marks are added to some oil containers to help you select the oil you should use.

1 API Service Symbol

Top portion: "API SERVICE SN" means the oil quality designation by American Petroleum Institute (API).

Center portion: "SAE 0W-20" means the SAE viscosity grade. Lower portion: "Resource-Conserving" means that the oil has fuel-saving and environmental protection capabilities.



تلفن شبانه روزى:

(2) ILSAC Certification Mark

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is displayed on the front of the container.

Oil capacity
(Drain and refill — reference*1)

With filter

7.0 L (7.4 qt., 6.2 Imp.qt.)

Without filter

6.7 L (7.1 qt., 5.9 Imp.qt.)

- Engine oil selection (KDJ150L-GKFEYW and KDJ150L-GKAEYW models*2)
 - *2: The model code is indicated on the manufacturer's label. (\rightarrow P. 711)

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: ACEA B1, API CF-4 or CF


تلفن شبانه روزى: ۱-۸۸۸۶۲ ۲۸ ۲۱-۲۲۰

^{*1:} The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

Recommended viscosity (SAE):

SAE 5W-30 is filled into your Toyota vehicle at manufacturing, the best choice for good fuel economy and good starting in cold weather.

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 5W-30 engine oil is recommended.





- The 5W in 5W-30 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 30 in 5W-30 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

تلفن شبانه روزی: ۱۹۰۱-۸۸۸۶۲ ۲۱ •

■ Engine oil selection (KDJ150L-GKAEY models*² except for EURO IV*³)

- *2: The model code is indicated on the manufacturer's label. (\rightarrow P. 711)
- *3: EURO IV is an emission standard. If it is not clear that your vehicle meets relevant standards, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.


"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: API CF-4, CF or ACEA B1 (You may also use API CE or CD.)

Recommended viscosity (SAE):

SAE 5W-30 is the best choice for good fuel economy and good starting in cold weather.

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 5W-30 engine oil is recommended.



Oil viscosity (5W-30 is explained here as an example):

- The 5W in 5W-30 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 30 in 5W-30 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

■ Engine oil selection (KDJ150L-GKAEY models*2 for EURO IV*3)

- *2: The model code is indicated on the manufacturer's label. (\rightarrow P. 711)
- *3: EURO IV is an emission standard. If it is not clear that your vehicle meets relevant standards, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.


"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: API CF-4, CF or ACEA B1

Recommended viscosity (SAE):

SAE 5W-30 is the best choice for good fuel economy and good starting in cold weather.

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 5W-30 engine oil is recommended.



Oil viscosity (5W-30 is explained here as an example):

- The 5W in 5W-30 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 30 in 5W-30 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

With filter 7.7 L (8.1 qt., 6.8 lmp.qt.) Without filter 7.2 L (7.6 qt., 6.3 lmp.qt.)

■ Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Toyota recommends the use of approved "Toyota Genuine Motor Oil". Another motor oil of matching quality can also be used.

Oil grade: ACEA C2

№ NOTICE


Using engine oil other than ACEA C2 may damage the catalytic converter.

تلفن شبانه روزى: ۱۹۲۰ ۱۹۸۸ - ۲۱ م

^{*:} The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

Recommended viscosity (SAE):

SAE 0W-30 is filled into your Toyota vehicle at manufacturing, and the best choice for good fuel economy and good starting in cold weather.



Oil viscosity (0W-30 is explained here as an example):

- The 0W in 0W-30 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 30 in 0W-30 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

▶ With rear heater	
With automatic transmission 14.9 L (15.7 qt., 13.1 Imp.qt.) ▶ Without rear heater 13.1 L (13.8 qt., 11.5 Imp.qt.)	
engine With manual transmission With manual transmission With rear heater 15.0 L (15.9 qt., 13.2 Imp.qt.) Without rear heater 13.2 L (13.9 qt., 11.6 Imp.qt.)	
(Reference) With automatic transmission With automatic transmission With rear heater 11.8 L (12.5 qt., 10.4 Imp.qt.) Without rear heater 10.0 L (10.6 qt., 8.8 Imp.qt.)	
engine With manual transmission With manual transmission With rear heater 11.9 L (12.6 qt., 10.5 Imp.qt.) Without rear heater 10.1L (10.7 qt., 8.9 Imp.qt.)	
Coolant type Use either of the following. "Toyota Super Long Li Coolant" A similar high-quality eth ene glycol-based non-s cate, non-amine, non-nitrit and non-borate coolant wi long-life hybrid organic ac technology Do not use plain water alone.	yl- ili- te, ith
Do not use plain water alone.	

Ignition system (spark plug of the gasoline engine)

Make	1GR-FE engine	DENSO SK16HR11
iviane	2TR-FE engine	DENSO FK20HR-A8
Can	1GR-FE engine	1.1 mm (0.043 in.)
Gap	2TR-FE engine	0.8 mm (0.032 in.)

♠ NOTICE

■ Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust the spark plug gap.

Electrical system

■ Battery

20°C (68°F):	1.250 — 1.290 Fully charged 1.160 — 1.200 Half charged 1.060 — 1.100 Discharged
--------------	---

Charging rates

	تلفن شبانه روزی 15 A max. 5 A max.
Slow charge	5 A max.

Front differential

Oil capacity arma S	1.40 L (1.48 qt., 1.23 Imp.qt.)
	Toyota Genuine Differential Gear Oil LT 75W-85 GL-5 or equivalent

^{*:} Your Toyota vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory.

Use Toyota approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for further details.

Rear differential

5-door	5-door	With rear differential lock system	2.65 L (2.80 qt., 2.33 Imp.qt.)
Oil capacity	IIIOGEIS	Without rear differential lock system	2.70 L (2.85 qt., 2.38 Imp.qt.)
3-door mod		lels	2.20 L (2.32 qt., 1.94 Imp.qt.)
Oil type and viscosity*			Toyota Genuine Differential Gear Oil LT 75W-85 GL-5 or equivalent

^{*:} Your Toyota vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory.

Use Toyota approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for further details.

Automatic transmission

Fluid capacity*	1GR-FE engine	➤ With ATF warmer 9.8 L (10,4 qt., 8.6 Imp.qt.) ➤ Without ATF warmer 9.9 L (10.5 qt., 8.7 Imp.qt.)
	2TR-FE engine	8.5 L (9.0 qt., 7.5 Imp.qt.)
Far	1KD-FTV engine	10.6 L (11.2 qt., 9.3 Imp.qt.)
	1GD-FTV engine	9.6 L (10.1 qt., 8.4 Imp.qt.)
Fluid type		Toyota Genuine ATF WS

^{*:} The fluid capacity is a reference quantity. If replacement is necessary, contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



NOTICE

■ Transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may cause shift quality, locking up of the transmission accompanied by vibration and, ultimately, damage to the vehicle's transmission.

Manual transmission

▶ 5-speed models

Gear oil capacity	2.2 L (2.3 qt., 1.9 lmp.qt.)
Gear oil type	TOYOTA Genuine Manual Transmission Gear Oil API GL-3 (GL-4) or equivalent
Recommended oil viscosity	SAE 75W-90

∧ NOTICE

Manual transmission gear oil

Please be aware that depending on the particular characteristics of the gear oil used or the operating conditions, idle sound, shift feeling and/or fuel efficiency may be different or affected. Toyota recommends to use "TOYOTA Genuine Manual Transmission Gear Oil GL-3 (GL-4) 75W-90" to achieve optimal performance.

▶ 6-speed models

Gear oil capacity	2.1 L (2.2 qt., 1.8 lmp.qt.)
Gear oil type	"TOYOTA Genuine Transfer Gear oil LF 75W" or equivalent

↑ NOTICE

■ Manual transmission gear oil (6-speed models)

Please be aware that depending on the particular characteristics of the gear oil used or the operating conditions, idle sound, shift feeling and/or fuel efficiency may be different or affected. Toyota recommends to use "TOYOTA Genuine Transfer Gear Oil LF 75W" to achieve optimal performance.

Clutch

Clutch pedal free play	5 — 15 mm (0.2 — 0.6 in.)
LEILIIG TVDA	SAE J1703 or FMVSS No.116 DOT 3 or SAE J1704 or FMVSS No.116 DOT 4

Transfer

Oil capacity	1.4 L (1.5 qt., 1.2 Imp.qt.)
Oil type*	"Toyota Genuine Transfer Gear oil LF" or equivalent
Recommended oil viscosity	SAE 75W

^{*:} Your Toyota vehicle is filled with "Toyota Genuine Transfer Gear oil LF" at the factory. Use Toyota approved "Toyota Genuine Transfer Gear oil LF" or an equivalent of matching quality to satisfy the above specification. Please contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for further details.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۸ الان

Brakes

			▶ With automatic transmission
	1GR-FE and 1KD-FTV engines		101 mm (4.0 in.) Min.
			▶ With manual transmission
			94 mm (3.7 in.) Min.
		Left- hand drive	▶ With automatic transmission
			101 mm (4.0 in.) Min.
Pedal	1GD-FTV		▶ With manual transmission
clear- ance*1	engines		94 mm (3.7 in.) Min.
unoc		Right-	•
		hand drive	101 mm (4.0 in.) Min.
	2TR-FE engine		▶ With automatic transmission
			105 mm (4.1 in.) Min.
1			▶ With manual transmission
			102 mm (4.0 in.) Min.
Pedal free play			1 — 6 mm (0.04 — 0.24 in.)
Parking brake lever travel*2		avel*2	5—7 clicks
Fluid type		~~~	 SAE J1703 or FMVSS No. 116 DOT 3 SAE J1704 or FMVSS No. 116 DOT 4

^{*1:} Minimum pedal clearance when depressed with a force of 490 N (50 kgf, 110 lbf) while the engine is running

^{*2:} Parking brake lever travel when pulled up with a force of 200 N (20.4 kgf, 45.0 lbf)

Chassis lubrication (Propeller shafts)

Spider	Lithium base chassis grease, NLGI No.2
	Molybdenum-disulfide lithium base chassis grease, NLGI No.2 or lithium base chassis grease, NLGI No.2

Steering

Free play	Less than 30 mm (1.18 in.)
Power steering fluid type	Automatic transmission fluid DEXRON® II or III



تلفن شبانه روزی: ۱۹۲۰ ۱۹۸۸ - ۲۱ م

Tires and wheels

▶ 17-inch tires (type A)

Tire size	P245/70R17 108S, 245/70R17 110S		
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire kPa (kgf/cm ² or bar, psi)	Rear tire kPa (kgf/cm ² or bar, psi)	
	220 (2.2, 32)	220 (2.2, 32)	
Wheel size	17 × 6 1/2J		
Wheel nut torque	112 N•m (11.4 kgf•m, 83 ft•lbf)		

▶ 17-inch tires (type B)

Tire size	245/70R17 110S	,
Tire inflation pressure (Recommended cold tire	Front tire kPa (kgf/cm² or bar, psi)	Rear tire kPa (kgf/cm ² or bar, psi)
inflation pressure)	200 (2.0, 29)	200 (2.0, 29) 220 (2.2, 32)*
Wheel size	17 × 6 1/2J	
Wheel nut torque	112 N•m (11.4 kgf•m, 83 ft•lbf)	

^{*:} Standard inflation for all loads including full rated loads

▶ 17-inch tires (type C)

Tire size Farma	P265/65R17 110S, 265/65R17 112S		
Tire inflation pressure (Recommended cold tire	Front tire kPa (kgf/cm ² or bar, psi)	Rear tire kPa (kgf/cm² or bar, psi)	
inflation pressure)	220 (2.2, 32)	220 (2.2, 32)	
Wheel size	17 × 7 1/2J		
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)		

▶ 17-inch tires (type D)

Tire size	265/65R17 112S		
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire kPa (kgf/cm ² or bar, psi)	Rear tire kPa (kgf/cm² or bar, psi)	
	200 (2.0, 29)	200 (2.0, 29)	
Wheel size	17 × 7 1/2J		
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)		

▶ 18-inch tires (type A)

Tire size	P265/60R18 109H, 265/60R18 110H		
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire kPa (kgf/cm ² or bar, psi) 220 (2.2, 32)	Rear tire kPa (kgf/cm ² or bar, psi) 220 (2.2, 32)	
	220 (2.2, 02)	220 (2.2, 02)	
Wheel size	18 × 7 1/2J		
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)		

▶ 18-inch tires (type B)			
Tire size	265/60R18 110H	مص سبد	
Tire inflation pressure (Recommended cold tire	Front tire kPa (kgf/cm² or bar, psi)	Rear tire kPa (kgf/cm ² or bar, psi)	
inflation pressure)	200 (2.0, 29)	200 (2.0, 29) 220 (2.2, 32)*	
Wheel size	18 × 7 1/2J		
Wheel nut torque	103 N•m (10.5 kgf•m,	76 ft•lbf)	

^{*:} Standard inflation for all loads including full rated loads

■When towing a trailer

Add 20.0 kPa (0.2 kgf/cm² or bar, 3 psi) to the recommended tire inflation pressure, and drive at speeds below 100 km/h (62 mph).

	Light bulbs	W	Туре
	Headlights Low beam (halogen bulbs*) High beam	55 60	A B
	Front fog lights*	19	С
	Front turn signal lights	21	D
Exterior	Front position lights (halogen bulbs*)	5	E
Exterior	Rear turn signal lights	21	D
	Back-up lights	16	E
	Rear fog lights*	21	E
	License plate lights		Е
6	Running board lights*	5	E
Interior	Personal/interior lights Front Page (with out personal lights)*		E F E
. 1	Vanity lights	. 8	Е

A: H11 halogen bulbs

E: Wedge base bulbs (clear)

B: HB3 halogen bulbs

F: Double end bulbs

C: H16 halogen bulbs

*: If equipped

D: Wedge base bulbs (amber)

Fuel information

Gasoline engine

▶ 1GR-FE engine

EU area:

You must only use unleaded gasoline conforming to European standard EN228.

Select unleaded gasoline with a Research Octane Number of 95 or higher for optimum engine performance.

Except EU area:

You must only use unleaded gasoline.

Select unleaded gasoline with a Research Octane Number of 95 or higher for optimum engine performance.

▶ 2TR-FE engine

EU area:

You must only use unleaded gasoline conforming to European standard EN228.

Select unleaded gasoline with a Research Octane Number of 91 or higher for optimum engine performance.

Except EU area:

You must only use unleaded gasoline.

Select unleaded gasoline with a Research Octane Number of 91 or higher for optimum engine performance.

EU area:

You must only use diesel fuel conforming to European standard EN590.

Except EU area (expect Russia):

You must only use diesel fuel that has a cetane number of 48 or higher.

Except EU area (Russia):

You must only use diesel fuel with a cetane number of 48 or higher. Your vehicle must use only diesel fuel confirming to GOST R52368-2005.

■ Use of ethanol blended gasoline in a gasoline engine

Toyota allows the use of ethanol blended gasoline where the ethanol content is up to 10 %. Make sure that the ethanol blended gasoline to be used has a Research Octane Number that follows the above.

■ If you plan to drive in foreign countries (diesel engine only)

Low sulphur diesel fuel may not be available, so please check the availability with your distributor.

■ If your engine knocks

- Consult any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

⚠ NOTICE

■ Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Gasoline engine: Do not use leaded gasoline.
 Leaded gasoline will cause the three-way catalytic converter to lose its effectiveness and the emission control system to function improperly.
- Gasoline engine (EU area): Bioethanol fuel sold under names such as "E50" or "E85" and fuel containing a large amount of ethanol should not be used. The use of these fuels will damage the vehicle's fuel system. In case of any doubt, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Gasoline engine (except EU area): Bioethanol fuel sold under names such as "E50" or "E85" and fuel containing a large amount of ethanol should not be used. Your vehicle can use gasoline mixed with 10 % max ethanol. The use of fuel with more than 10 % ethanol content (E10) will damage the vehicle's fuel system. You must ensure that refueling is carried out only from a source where fuel specification and quality can be guaranteed. In case of any doubt, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Diesel engine (EU area): FAME (Fatty Acid Methyl Ester) fuel sold under names such as "B30" or "B100" and fuel containing a large amount of FAME should not be used. The use of these fuels will damage the vehicle's fuel system. In case of any doubt, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Diesel engine (except EU area): FAME (Fatty Acid Methyl Ester) fuel sold under names such as "B30" or "B100" and fuel containing a large amount of FAME should not be used. Your vehicle can use diesel mixed with 5 % max biodiesel FAME (B5). The use of fuel with more than 5 % FAME content (B5) will damage the vehicle's fuel system. You must ensure that refueling is carried out only from a source where fuel specification and quality can be guaranteed. In case of any doubt, ask any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.
- Do not use the methanol blended gasoline such as M15, M85, M100. The use of gasoline containing methanol may cause engine damage or failure.

Customizable features

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. The settings of these features can be changed by using the steering wheel switches or at any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

It is also possible to customize certain vehicle features yourself using the menu switch and the "ENTER" switch.

Customizing vehicle features

When customizing vehicle features, ensure that the vehicle is parked in a safe place with the shift lever in P (automatic transmission) or N (manual transmission) and the parking brake set.

- Changing by using the menu switch and the "ENTER" switch
- Press and hold the menu switch to display customization mode. (→P. 121)
- Press the "ENTER" switch upwards or downwards to select the item to be customized.

 Press the "ENTER" switch to confirm.
- 3 Press the "ENTER" switch upwards or downwards to select the desired setting for the item being customized.

 Press the "ENTER" switch to confirm.

When customization is completed, press the menu switch to clear the customization screen.

Customizable features

Some function settings are changed simultaneously with other functions being customized. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer for further details.

- ① Settings that can be changed using the menu switch and the "ENTER" switch
- ② Settings that can be changed by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer

Definition of symbols: O = Available, - = Not available

■ Door lock (→P. 136, 691)

Function	Default setting	Customized setting	1	2
Unlocking using a key	All doors unlocked in one step	Driver's door unlocked in one step, all doors unlocked in two steps	_	0
Shift position linked door unlocking function*	Off	On	0	0
Driver's door linked door unlocking function*	ى: Off	تلفن شبانه روز	0	0

^{*:} If equipped

■ Smart entry & start system* and wireless remote control (→P. 159, 132)

Function	Default setting	Customized setting	1	2
Operation signal (huzzer)	l evel 7	Off	0	0
Operation signal (buzzer)	Level 7	Level 1 to 6	U	O
Operation signal (Emergency flashers)	On	Off	0	0
Time elapsed before the automatic door lock function is activated if a door is	30 seconds	60 seconds		О
not opened after being unlocked		120 seconds	_	
Open door warning function (When locking the vehicle)	On	Off	-	0
	Push and hold (Short)	Push twice		
Glass hatch opening operation		One short push	_	
		Push and hold (Long)		0

^{*:} If equipped

■ Smart entry & start system* (→P. 159)

Function	Default setting	Customized setting	1	2
Smart door unlocking	All the doors	Driver's door	0	0
Smart entry & start system	On	Off	0	0

^{*:} If equipped

■ Wireless remote control (→P. 132)

Function	Default setting	Customized setting	1	2
Wireless remote control	On	Off	_	0
Unlocking operation	All doors unlocked in one step	Driver's door unlocked in one step, all doors unlocked in two steps	0	0

■ Driving position memory* (→P. 193)

Function	Default setting	Customized setting	1	2
Selecting the door linking driving position memory with door unlock operation	Driver's door	All doors	_	0

^{*:} If equipped

■ Automatic light control system* (→P. 274)

Function	Default setting	Customized setting	1	2
, , , , , ,		Off		
Time elapsed before the headlights turn off	30 seconds	60 seconds	0	0
	-000	90 seconds		
Light sensor sensitivity	Standard	-2 to 2	0	0
Time elapsed before head- lights automatically turn on*	Standard	Long	_	0

^{*:} If equipped

^{*1:} If equipped

^{*2:} For vehicles with a smart entry & start system

■ Exterior lights* (→P. 492)

Function	Default setting	Customized setting	1	2
		Off		
Time elapsed before the exterior lights turn off	15 seconds	7.5 seconds	0	Ο
Shorts ingine tain on		30 seconds		
Running board lights	On	Off	_	Ο
Operation when you approach the vehicle with the electronic key on your person	On	Off	_	0
Operation when the doors are unlocked with the smart entry & start system or wireless remote control	On	Off	_	0
Operation when the doors are unlocked with the power door lock switch	On	Off	_	0
Operation when the door is opened	SY On	Off	_	0

[:] If equipped

Function	Default setting	Customized setting	1	2
Sensitivity of the ambient light sensor used for dimming the meter lights etc.*	Standard	-2 to 2	_	0
Sensitivity of the ambient light sensor used for brightening the meter lights etc.*	Standard	-2 to 2	-	0

■ Front automatic air conditioning system* (→P. 472)

F	unction	Default setting	Customized setting	1	2
mode link	between out- d recirculated air ed to automatic on operation	Auto	Manual	_	0
A/C auton ton operati	natic mode but- ion	Auto	Manual	_	0

^{*:} If equipped \ ___

■ Power windows (\rightarrow P. 208) and moon roof*1,2 (\rightarrow P. 212)

Function	Default setting	Customized setting	1	2
Mechanical key linked operation (close)	35 off 5.	Com	_	0
Mechanical key linked operation (open)	Off	On	_	0
Wireless remote control linked operation*1 (close)	Off	On	_	0
Wireless remote control linked operation*1 (open)	Off	On	_	0
Wireless remote control linked operation (buzzer)*1	On	Off	-	0

^{*1:} If equipped

^{*2:} The moon roof operation settings will be automatically changed when the power window operation settings are changed

■ Toyota parking assist-sensor*1 (→P. 324)

Function	Default setting	Customized setting	1 1	2
Detection distance of the front center sensor*3	Far	Near	_	0
Detection distance of the rear center sensor	Far	Near	_	0
Buzzer volume	Level 5	Level 1 to 5	_	0
Display setting	All sensors displayed	Display off	_	0

^{*1:} If equipped

■ Alarm* (→P. 90)

Function	Default setting	Customized setting	1	2
Sensitivity adjustment of the intrusion sensor when the window is open	Standard	تلفن <mark>"لىب</mark> انە روز	_	0
Deactivates the alarm when the doors are unlocked using the mechanical key (vehicles with a smart entry & start system)	aSØS.	Com	_	0

^{*:} If equipped

^{*2:} Settings that can be changed using the navigation system or multimedia system (→P. 330)

^{*3:} Settings that can be changed on vehicles with 8 sensor type system

■ Multi-information display (→P. 110, 115, 120)

Function	Default setting	Customized set- ting	1	2
		French		
		German		
		Spanish		
		Italian		
. *1		Japanese*2		
Language*1	English	Simplified Chinese*2	0	0
, , •		Traditional Chinese		
1 / 1		Russian		
	フノノブ	Turkish		
Units*1	km	km (km/L)	0	0
Offics	(L/100km)	mph (MPG)	U	O
Eco Driving Indicator Light*3	۶۲ • On ۵ : «	Off	0	0
Turn-by-turn navigation*2	On	Off	0	0
Vehicle image*2	Back door mounted spare tire image off	Back door mounted spare tire image on	0	0

^{*1:} The default setting varies according to countries

^{*2:} If equipped

^{*3:} For vehicles with the multi-information display type A and B, the setting can be changed by the "ODO/TRIP" button (\rightarrow P. 112)

■In the following situations, customize mode will automatically be turned

- A warning message appears after the customize mode screen is displayed.
- The engine switch is turned to the "LOCK" position (without a smart entry & start system) or turned off (with a smart entry & start system).
- The vehicle begins to move while the customize mode screen is displayed.



CAUTION

■ During customization

As the engine needs to be running during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



During customization

To prevent battery discharge, ensure that the engine is running while customizing features.



The following item must be initialized for normal system operation after such cases as the battery being reconnected, or maintenance being performed on the vehicle:

Item	When to initialize	Reference
Tire pressure warning system	When rotating the tires When changing the tire inflation pressure by changing traveling speed or load weight, etc.	P. 568
Engine oil maintenance data (1GD-FTV engine only)	When after changing the engine oil	P. 548
وفارا	וטרור צונו	

تلفن شبانه روزی: ۱۹۲۰ میلا - ۲۱ - ۲۲ میلانه



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

Index

What to do if... (Troubleshooting).......754
Alphabetical index758

امداد حودرو فارما

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ – ۲۱

FarmaSOS.com

For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual" for information regarding the equipment listed below.

- · Navigation system
- Hands-free system (for cellular phone)
- · Rear seat entertainment system
- · Audio/video system

What to do if... (Troubleshooting)

If you have a problem, check the following before contacting any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.

The doors cannot be locked, unlocked, opened or closed



You lose your keys

- If you lose your keys or mechanical keys, new genuine keys or mechanical keys can be made by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer. (→P. 135)
- Vehicles with a smart entry & start system If you lose your electronic keys, the risk of vehicle theft increases significantly. Contact any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer immediately. (→P. 134)



The doors cannot be locked or unlocked

- Is the key battery weak or depleted? (→P. 588)
- Vehicles with a smart entry & start system Is the engine switch in IGNITION ON mode? When locking the doors, turn the engine switch off. (→P. 252)
- Vehicles with a smart entry & start system
 Is the electronic key left inside the vehicle?
 When locking the doors, make sure that you have the electronic key on your person.
- The function may not operate properly due to the condition of the radio wave. (→P. 145, 162)



The rear door cannot be opened (vehicles with rear door child-protector lock)

■ Is the child-protector lock set? The rear door cannot be opened from inside the vehicle when the lock is set. Open the rear door from outside and then unlock the child-protector lock. (→P. 141)

If you think something is wrong



The engine does not start (vehicles without a smart entry & start system)

- Vehicles with a manual transmission Do you turn the key with the clutch pedal depressed firmly? (→P. 246)
- Vehicles with an automatic transmission Is the shift lever in P? (\rightarrow P. 246)
- Is the steering wheel unlocked? (→P. 248)
- Is the battery discharged? (→P. 694)



The engine does not start (vehicles with a smart entry & start system)

- Did you press the engine switch while firmly depressing the brake pedal? (→P. 249)
- Vehicles with an automatic transmission Is the shift lever in P? (\rightarrow P. 249)
- Is the electronic key anywhere detectable inside the vehicle? (→P. 160)
- Is the steering wheel unlocked? (→P. 254) تلفن شبانه روزي
- Is the electronic key battery weak or depleted? In this case, the engine can be started in a temporary way. (→P. 692)
- Is the battery discharged? (→P. 694)



The shift lever cannot be shifted from P even if you depress the brake pedal (vehicles with an automatic transmission)

- Vehicles without a smart entry & start system Is the engine switch in the "ON" position? If you cannot release the shift lever by depressing the brake pedal with the engine switch in the "ON" position: →P. 262
- Vehicles with a smart entry & start system Is the engine switch in IGNITION ON mode?
 - If you cannot release the shift lever by depressing the brake pedal with the engine switch in IGNITION ON mode: →P. 262



The steering wheel cannot be turned after the engine is stopped

- Vehicles without a smart entry & start system It is locked to prevent theft of the vehicle if the key is removed from the engine switch. (→P. 248)
- Vehicles with a smart entry & start system
 It is locked automatically to prevent theft of the vehicle.
 (→P. 254)



The windows do not open or close by operating the power window switches

Is the window lock switch pressed? The power window except for the one at the driver's seat cannot be operated if the window lock switch is pressed. (→P. 208)



The engine switch is turned off automatically (vehicles with a smart entry & start system)

The auto power off function will be operated if the vehicle is left in ACCES-SORY or IGNITION ON mode (the engine is not operating) for a period of time. (→P. 253)



A warning buzzer sounds during driving

- The seat belt reminder light is flashing
 Are the driver and the front passenger wearing the seat belts?
 (→P. 629)
- The brake system warning light is on Is the parking brake released? (→P. 270)

Depending on the situation, other types of warning buzzer may also sound. (\rightarrow P. 625, 636)



An alarm is activated and the horn sounds (if equipped)

Did anyone inside the vehicle open a door during setting the alarm? The sensor detects it and the alarm sounds. (→P. 90)

To stop the alarm, turn the engine switch to IGNITION ON mode or start the engine.



A warning buzzer sounds when leaving the vehicle (vehicles with a smart entry & start system)

■ Is the message displayed on the multi-information display? Check the message on the multi-information display. (→P. 636)



A warning light turns on or a warning message is displayed (if equipped)

 When a warning light turns on or a warning message is displayed, refer to P. 625, 636.

When a problem has occurred



تلفن شبانه روزی: ۵ + ۸۵ الفن شبانه روزی:

- Vehicles without a spare tire Stop the vehicle in a safe place and repair the flat tire temporarily with the emergency tire puncture repair kit. (→P. 672)
- Vehicles with a spare tire
 Stop the vehicle in a safe place and replace the flat tire with the spare tire.
 (→P. 653)



The vehicle becomes stuck

Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P. 705)

Alphabetical index

A	
A/C466, 472, 481	
Air conditioning filter	.586
Active Traction Control*1	. 372
ABS	
(Anti-lock Brake System)	. 372
Function	. 372
Warning light	
Air conditioning filter	. 586
Air conditioning	
system466, 472, 481	483
Air conditioning filter	. 586
Airbags	41
Airbag operating	
conditions	50
A total and a second of the second	
for your child	44
Airbag warning light	
Correct driving posture	34
Curtain shield airbag	
operating conditions	50
Curtain shield airbag	1
precautions	44
General airbag	
precautions	
Locations of airbags	41
Modification and disposal	3
of airbags	49
Side airbag operating	
conditions	
Side airbag precautions	44
Side and curtain shield	
airbags operating	
conditions	50
Side and curtain shield	
airbags precautions	
SRS airbags	41

Alarm	90
Alarm	90
Warning buzzer	625
Anchor brackets	77
Antennas (smart entry &	
start system)	. 159
Anti-lock brake system	
(ABS)	. 372
Function	372
Warning light	626
Armrest	. 517
Ashtray	
Assist grip	
Audio input408,	437
Audio system ^{*2}	
Antenna	
Audio input408,	
AUX port/USB port 408,	
Bluetooth [®] audio	453
CD player	. 416
iPod	
MP3/WMA disc	
Optimal use	
Portable music player	408
Radio	.411
Steering wheel audio	
switch407,	
USB memory	. 430
Automatic headlight leveling	
system	. 286
Automatic light control	
system	
Automatic transmission	. 257
If the shift lever cannot be	
shifted from P	
S mode	
AUX port408,	
Auxiliary boxes	. 503
AVS*1	

В	Center differential*1
Back door146	CD player415
Back-up lights	Chains400
Replacing light bulbs606	Child restraint system57
Wattage737	Baby seats, definition58
Battery552	Baby seats, installation71
Battery checking552	Child seats, definition58
If the vehicle battery is	Child seats, installation73
discharged694	Installing CRS with
Preparing and checking	ISOFIX rigid anchor77
before winter400	Installing CRS with
Warning light625	seat belts71
Bluetooth®	Installing CRS with
Audio system453	top straps78
Hands-free system	Junior seats, definition 58
(for cellular phone)455	Junior seats, installation75
Bottle holders501	Child safety 56
Brake	Airbag precautions44
Fluid733	Back door precautions 150
Parking brake270	Battery precautions 552, 700
Warning light625	Child restraint system 57
Brake assist372	Glass hatch precaution 156
Break-in tips221	How your child should
Brightness control	wear the seat belt38
Instrument panel light	Installing child restraints 70
control108	Moon roof precautions 216
BSM (Blind Spot Monitor) 378	Power window lock
Taimao	switch208
C	Power window

Care.....526, 530 Aluminum wheels......527

Exterior......526 Interior.....530

Seat belts.....531

Cargo hooks......505

seat belts71
Installing CRS with
top straps78
Junior seats, definition 58
Junior seats, installation75
Child safety 56
Airbag precautions44
Back door precautions 150
Battery precautions 552, 700
Child restraint system 57
Glass hatch precaution 156 How your child should
wear the seat belt38
Installing child restraints 70
Moon roof precautions 216
Power window lock
switch208
Power window
precautions211
Rear door
child-protectors141
Removed key battery
precautions591
Seat belt precautions39

Seat heater precautions...... 488

Child-protectors141	Diesel particulate filter
Back door child-protector	system271
lock149	system271 Differential*1729, 730
Cleaning	Dimension708
Aluminum wheels527	Display
Exterior526	Multi-information
Interior530	display110, 120
Seat belts531	Trip information111, 121
Clock513	Warning message636
Coat hooks517	Do-it-yourself maintenance 536
Compass123	Doors136
Condenser551	Automatic door locking
Console box498	and unlocking system 142
Cool box509	Back door146
Cooling system549	Back door child-protector
Engine overheating701	lock149
Conversation mirror512	Door glasses208
Crawl Control*1	Door lock136
Cruise control	Open door warning
Cruise control302	buzzer139
Dynamic radar cruise	Open door warning light 628
control306	Outside rear view mirrors 205
Cup holders500	Rear door child-protector 141
Curtain shield airbags41	Double locking system89
Current fuel consumption121	Driver's seat position
Customizable features741	memory 193
<u> FarmaS()</u>	Driving218
Difference	AVS switch*1
DAC (Downhill Assist	Break-in tips221
Control system)*1	Correct posture 34
Daytime running light	Procedures218
system284	Winter drive tips400
Defogger	Dynamic radar cruise
Front windshield467, 475	control306
Outside rear view	
mirrors467, 475	
Rear window467, 475	

E	
Eco Driving Indicator113,	125
Electronic key	130
Battery-saving function	162
If the electronic key does	
not operate properly	
Replacing the battery	588
Emergency, in case of	
If the electronic key does	
not operate properly	
If the engine will not start	689
If the vehicle has	
discharged battery	694
If the warning buzzer	005
sounds	625
If the warning light	625
turns on	
If you have a flat tire653,	
If you lose your keys If you think something is	754
,	623
wrong If you run out of fuel and	023
the engine stalls	704
If your vehicle becomes	704
stuck	705
If your vehicle needs to be	. 50
towed	617
If your vehicle overheats	
,	

Emergency flashers	614
Engine	050
Accessory mode 247,	
Compartment	
Engine switch246,	
Hood How to start the	539
	240
engine246, Identification number	
If the engine will not start	689
If you run out of fuel and	704
the engine stalls	704
Ignition switch	0.40
(engine switch) 246,	
Overheating	701
Engine compartment	E 4 4
cover	
Engine coolant	
Charling	
Checking	549
Preparing and checking	400
before winter	
Engine immobilizer system	
Engine oil	
Charling	
Checking	545
Preparing and checking	400
before winter	400
Engine oil maintenance	
data	E 40
data	
Engine switch246,	249
	249 492

F	
Flat tire653	672
Floor mats	32
Fluid	
Automatic transmission	730
Brake	733
Clutch	732
Steering	734
Washer	556
Fog lights	287
Replacing light bulbs	604
Switch	287
Wattage	737
Four-wheel drive system*1	
Front passenger's seat belt	
reminder light	629
Front position lights	274
Light switch	274
Replacing light bulbs	601
Wattage	737
Front seats	_
Adjustment	175
Cleaning	
Correct driving posture	34
Driving position memory	
Head restraints	193 197
Head restraints	193 197 488
Head restraints Seat heaters Seat position memory	193 197 488 193
Head restraints	193 197 488 193
Head restraints Seat heaters Seat position memory	193 197 488 193 269
Head restraints Seat heaters Seat position memory Front turn signal lights	193 197 488 193 269 602

Fuel	. 714
Capacity	.714
Fuel gauge	. 105
Fuel pump shut off system	. 624
If you run out of fuel and	
the engine stalls	. 704
Information	. 738
Refueling	. 298
Type298,	714
Warning light	
Fuel consumption	
information	. 128
Fuel filler door	. 298
Refueling	. 298
Fuel filter	
Warning light628,	628
Fuel gauge	. 105
Fuel pump shut off	
system	. 624
Fuses	. 592
G pall	
Gauges	. 105
Glass hatch	. 153
Glove box	. 497
0 0 0 000	
5.com	

Н	I
Hands-free system	Identification
(for cellular phone)455	Engine712
Head restraints197	Vehicle711
Headlights274	Ignition switch
Light switch274	(engine switch)246, 249
Replacing light bulbs599, 600	Ignition switch light492
Wattage737	Illuminated entry system 495
Headlights cleaner296	Immobilizer system 83
Heaters	Indicators98
Manual air conditioning	Initialization
system466, 481	Moon roof214
Automatic air conditioning	Power windows210
system472, 483	Tire pressure warning
Seat heaters488	system567
Outside rear view	Initiators (tire pressure
mirrors467, 475	warning system)579
Height control*1	Inside rear view mirror203
Hill-start assist control*1	Instrument panel light
Hood539	control108
Hooks V AAACV A	Intercooler551
Cargo hooks505, 506	Interior lights492
Coat hooks517	Switch 493
Retaining hooks	Wattage737
(floor mat)32	
Horn201	- J
FarmaSC	Jack Collins
	Vehicle-equipped
	jack654, 674
	Jack handle 661
	Jam protection function
	Moon roof213
	Power windows209

K
Keyless entry
Smart entry & start
system136, 146
Wireless remote
control136, 146
Keys130
Battery-saving function162
Electronic key130
Engine switch246, 249
If the electronic key does
not operate properly691
If you lose your keys754
Key number plate130
Keyless entry136, 146
Mechanical key134
Replacing the battery588
Warning buzzer139
Wireless remote control 132
KDSS*1
Warning light627

Ь		m		
			U	

L	
Lever	
Auxiliary catch lever	. 539
Hood lock release lever	. 539
Shift lever	. 257
Turn signal lever	. 269
Wiper lever	. 289
License plate lights	. 274
Light switch	. 274
Replacing light bulbs	. 609
Wattage	. 737
Light	
Engine switch light	. 492
Fog light switch	
Headlight switch	
Illuminated entry system	. 495
Interior light	
Interior light list	. 492
Luggage compartment	
light	. 493
Personal light	
Replacing light bulbs	. 596
Turn signal lever	. 269
Vanity lights	. 511
Wattage	. 737
Light bulbs	
Replacing	. 596
Wattage	. 737
Lock steering column 248	254

M	N
Maintenance	Navigation system*2
Do-it-yourself	ganon cyclem
maintenance536	
Maintenance data708	0
Maintenance	Odometer105
requirements533	Oil
Malfunction indicator	Engine oil715
lamp625	Front differential oil729
Manual transmission264	Rear differential oil730
Manual headlight leveling	Opener
dial275	Back door148
Master warning light636	Fuel filler door301
Meter105	Hood539
Indicators98	Outside rear view mirrors 205
Instrument panel light	Adjusting and folding205
control108	Blind spot monitor378
Meters105	Outside rear view mirror
Multi-information	defoggers 467, 475
display110, 120	Outside temperature
Warning lights98	display112, 123
Mirrors \\ \\ _\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Overheating, Engine701
Inside rear view mirror203	
Outside rear view mirror	
defoggers467, 475	
Outside rear view mirrors205	00
Vanity mirrors511	JS.com
Moon roof212	0.00111
Jam protection function213	
Operation212	
MP3 disc415	
Multi-information	
display110, 120	
Switching the display 111, 121	
Trip information111, 121	
Multi-terrain Monitor*1	
Multi-terrain Select*1	

^{*1:} Refer to the "Off-road driving Owner's manual".

*2: For vehicles with a navigation system or a multimedia system, refer to the "Navigation and multimedia system Owner's manual".

Р	
Parking assist sensors	324
Parking assist monitor	345
Parking brake	270
Operation	270
Parking brake engaged	
warning buzzer	631
Personal lights	492
Switch	493
Wattage	737
Pollen removal mode	476
Power heater	486
Power outlet	514
Power steering	
Warning light	626
Power windows	208
Jam protection function	209
Operation	208
Window lock switch	208

	4	٨	A	A	A	84		A A	
•	-)	-)	-/	$oldsymbol{ol}}}}}}}}}}}}}}}$	/\		7	/ \ し	J

FarmaSO

R	
Radiator	551
Radio	411
Radio data system	412
RDS	412
Rear fog lights	287
Replacing light bulbs	608
Switch	287
Wattage	737
Rear differential*1	
Rear seat	178
Adjustment	178
Rear turn signal lights	269
Replacing light bulbs	606
Turn signal lever	269
Wattage	737
Rear view mirror	
Inside rear view mirror	203
Outside rear view mirrors	205
Rear view monitor system	334
Rear window	
defogger	
Rear window wiper	295
Refueling	298
Capacity	
Fuel types298,	
Opening the fuel tank cap	301
Replacing	
Electronic key battery	
Fuses	
Light bulbs	
Tires653,	672
Wireless remote control	
battery	588
Reset the maintenance	
data	
Roof luggage carrier	230

S	
Seat belts	36
Adjusting the seat belt	37
Child restraint system	
installation	70
Cleaning and maintaining	
the seat belt	.531
Emergency Locking	
Retractor	
How to wear your seat belt	36
How your child should wear	
the seat belt	38
Pregnant women, proper	
seat belt use	
Reminder light and buzzer	
Seat belt pretensioners	37
000	200
SRS warning light	
Seat heaters	.490
Seat position memory	.490 .193
Seat heaters	. 490 . 193 178
Seat position memory	. 490 . 193 178
Seat heaters	. 490 . 193 178 178
Seat heaters Seat position memory Seats	. 490 . 193 178 178
Seat heaters Seat position memory Seats	.490 .193 178 178
Seat heaters Seat position memory Seats	.490 .193 .178 .178 70
Seat heaters Seat position memory Seats	.490 .193 178 178 191 70 .530
Seat heaters Seat position memory Seats	.490 .193 178 178 191 70 .530
Seat heaters Seat position memory Seats	.490 .193 178 178 191 70 .530 .193
Seat heaters Seat position memory Seats	.490 .193 178 178 191 70 .530 .193 .197 34
Seat heaters Seat position memory Seats	.490 .193 178 178 191 70 .530 .193 .197 34 .490

Sensor	
Automatic headlight	
system	. 284
Inside rear view mirror	. 204
Toyota parking	
assist-sensor	. 324
Rain-sensing windshield	
wipers	
Service reminder indicators	98
Shift lever	
Automatic transmission	. 257
If the shift lever cannot	
be shifted from P	. 262
Shift lock system	. 261
Shopping bag hooks	. 506
Side airbags	41
Side mirrors	
Adjusting and folding	
Blind Spot Monitor	. 378
Side turn signal lights	. 269
Replacing light bulbs	
Turn signal lever	
Smart entry & start system	. 159
Antenna location	. 159
Starting the engine	. 249
Snow tires	
Spare tire	. 653
Inflation pressure	. 735
Storage location	. 654
Spark plug	. 729
Specifications	. 708
Speedometer	. 105
Steering lock	
Column lock release 248,	254

Steering wheel200
Adjustment200
Audio switches407
Steering wheel position
memory193
Stop/tail lights
Wattage737
Storage feature496
Stuck
If the vehicle becomes
stuck705
Sun shade
Roof213
Sun visors511
Switch
"2nd START" button258
Airbag manual on-off
system54
Audio remote control
switches407, 443
AVS switch ^{*1}
BSM (Blind spot monitor)
switch378
Center differential
lock/unlock switch*1
Crawl Control ON/OFF
switch*12 rmaS
Crawl Control speed
selector dial ^{*1}
Cruise control switch302, 306
"DAC" switch ^{*1}
Door lock switches140
Driving position memory
switches193
Emergency flashers
switch614
Engine switch246, 249
Fog light switch287
Four-wheel drive control
switch*1
Headlight cleaner switch296

Heater idle up switch 468, 477
Height control button*1
Ignition switch 246, 249
Intrusion sensor cancel
switch 93
Light switches274
Moon roof switches212
Multi-terrain Monitor switch*1
Multi-terrain Select
ON/OFF switch*1
Multi-terrain Select mode
selector dial ^{*1}
"ODO TRIP" button 108, 111
Outside rear view mirror
switches205
Parking assist 324
PCS off switch 391
Power door lock switch 140
Power heater switch 486
Power window switch208
Rear differential
lock/unlock switch*1
Rear window wiper and
washer switch295
Rear window and outside
rear view mirror
defoggers switch 467, 475
defoggers switch 467, 475 Seat heater switches 490
defoggers switch 467, 475 Seat heater switches 490 Talk switch* ²
defoggers switch 467, 475 Seat heater switches 490 Talk switch *2 Telephone switches 443
defoggers switch 467, 475 Seat heater switches 490 Talk switch* ² Telephone switches 443 Tilt and telescopic steering
defoggers switch 467, 475 Seat heater switches 490 Talk switch *2 Telephone switches 443 Tilt and telescopic steering control switch
defoggers switch 467, 475 Seat heater switches 490 Talk switch* ² Telephone switches 443 Tilt and telescopic steering control switch
defoggers switch 467, 475 Seat heater switches 490 Talk switch*2 Telephone switches 443 Tilt and telescopic steering control switch
defoggers switch
defoggers switch
defoggers switch 467, 475 Seat heater switches 490 Talk switch *2 Telephone switches 443 Tilt and telescopic steering control switch 200 Tire pressure warning reset switch
defoggers switch
defoggers switch 467, 475 Seat heater switches 490 Talk switch *2 Telephone switches 443 Tilt and telescopic steering control switch 200 Tire pressure warning reset switch

Tachometer105
Tail lights274
Light switch274
Talk switch*2
Telephone switch443
Theft deterrent system
Alarm90
Engine immobilizer system 83
Tire inflation pressure581
Maintenance data735
Warning light629
Tire pressure warning
system567
Function 567
Initializing567
Installing tire pressure
warning valves and
transmitters567
Registering ID codes569
Tire pressure warning
reset switch567
Warning light629
Tires565
Chains400
Checking565
If you have a flat tire653, 672
Inflation pressure58
Replacing653, 672
Rotating tires566
Size735
Snow tires402
Spare tire653
Tire pressure warning
system567
Warning light629

	Tools654,	674
	Top strap	78
	Towing	
	Emergency towing	619
	Towing eyelet	619
	Trailer Sway Control	373
	Trailer towing	233
	Trailer Sway Control	373
	TRC (Traction Control)	372
	Transmission	
	Automatic transmission	257
	AVS switch*1	
	If the shift lever cannot be	
	shifted from P	262
l	Trip information 111,	121
Ī	Trip meters 108,	111
	Turn signal lights	269
	Replacing light bulbs 602,	606
	Turn signal lever	269
	Wattage	737
	تلفر للسانه روزي:	
	USB port	408
	·	
	V	
(Valet key	130
1	Vanity lights	
	Vanity lights	
	Wattage	
	Vanity mirrors	
	Vehicle identification	
	number	711
	VSC (Vehicle Stability	
	Control)	372

W	
Warning buzzers	625
Brake system	625
Downshifting	262
Fuel system	628
Key reminder	632
Open back door	631
Open door	
Seat belt remainder	631
Warning lights	
ABS	626
Automatic headlight	
leveling system	630
Automatic transmission	
fluid temperature	
Brake system	
Charging system	
Diesel particulate filter	
Fuel filter	
Fuel system warning light	
KDSS	
LED headlight	
Low engine oil level	
Low engine oil pressure	
Low fuel level	628
Malfunction indicator	005
lamp Master warning light	625
Open door Parking brake indicator	
PCS	
Power steering	
Seat belt reminder light	
Slip indicator	
SRS	
Timing belt replacement	
Tire pressure	
1.10 probbaro	020

Toyota parking	
assist-sensor	630
Windshield washer fluid	630
Warning reflector holder	505
Washer	289
Checking	556
Preparing and checking	
before winter	400
Switch	289
Washing and waxing	526
Weight	708
Wheels	583
Replacing wheels	583
Size	735
Window glasses	208
Window lock switch	
Windows	208
Power windows	208
Rear window	
defogger 467,	475
Windshield wiper	
de-icer 468,	476
Windshield wipers	289
Intermittent windshield	
wipers with interval	
adjuster	289
Rain-sensing windshield	
wipers	291
Winter driving tips	400
Wireless remote control	130
Locking/Unlocking136,	146
Replacing the battery	588
WMA disc	415



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸۵ ا

FarmaSOS.com

